


Harbor - Monitor Install Guide


2024 / 04 / 09

- Accordion fold
- Total width: 164mm
- Folded width: 82mm
- Height: 171mm
- Red Line: Page outline, not meant to be printed




Bi-fold


What's in the box



Harbor Monitor



USB-C Power Adapter




3ft USB-C Power Cable

LED Behaviors

- Solid Orange**
Monitor is booting up
- Slow Blinking Orange**
Boot up near completion
- Three Orange blinks, repeating**
Monitor is looking for Camera
- Three white breaths**
Successfully connected to Camera
- Three fuchsia breaths**
Connected to Harbor Systems
- Breathing white**
Battery charging
- Solid white**
Plugged in, Battery full
- Breathing red**
Low Battery
- "LED Off" is Harbor's default "all good" state**
When running on battery, we aim to keep things dark for you and your little one whenever possible.


Power on the Monitor



Insert one end of the USB-C cable into the back of the Monitor and the other end into the power adapter. LED above USB-C port will indicate charge state.

Press the Power Button on the top of the Monitor.

Connect Monitor to the Camera




Ensure both Camera and Monitor are powered on. Place Camera and Monitor close together to allow the Bluetooth connection to automatically occur.

Follow the on screen instructions and LED behaviors.

Factory reset

To factory reset, access the settings menu with the touchscreen on the Monitor.

Hinge rotation




Unfold the Kickstand to desired viewing angle.

Use Harbor Mobile App to connect to home Wi-Fi

Install the Harbor Mobile App (for iOS) to connect your Camera and Monitor to your home Wi-Fi and use your mobile device(s) to view the feed.

Scan the QR code or use your mobile browser to begin:

harbor.co/start



Pull tab attached to rear side of the last page of the bi-fold fold w/ adhesive

Safety/Compliance

Caution:

1. THIS PRODUCT DOES NOT REPLACE ADULT SUPERVISION. FOR HEALTH & SAFETY BE SURE TO CHECK ON YOUR CHILD REGULARLY.
2. This product is meant to be wall mounted and/or used out of reach from a child. Do not use where a child can access it.
3. The product should be installed or used in a location that is not easily accessible and is away from impacts or heavy vibration.
4. This product is to be used in indoor environments only.
5. Do not allow your child to play with this device or the packaging.
6. Use only the AC wall adapter that is included with your Harbor camera.
7. When installing, keep small parts out of reach from children.
8. Never plug your Harbor camera into an outlet that is accessible to your child.
9. Never attempt to service/repair/dismantle the product. This is dangerous and will void the warranty.
10. The camera and adapter may be warm to the touch. This is normal.
11. To prevent entanglement and overheating, never use extension cords.
12. Camera and Monitor use encrypted transmission over FCC managed frequencies. Ensure Wi-Fi router is password protected.
13. WARNING - Strangulation Hazard: Children have been strangled by cords. Ensure the cords is properly covered when used within 3 feet from crib.
14. Ensure the cord is covered if accessible to children Do not put the cord within 36 inches of a crib.

Ask for help!

Thank you for purchasing this Harbor product. If you experience any issues or need assistance, please contact our technical support team:


Email: support@harbor.co

Write to us: 4516 Lovers Lane, 392, Dallas TX 75225, USA

Call: +1 214-919-3432

All specifications are subject to change without notice.
Copyright © Harbor All rights reserved.

Model: M01
300-0002
REV-01



Harbor

Monitor QuickStart Guide