

Switch on or off

- 1: Press and hold key **||◀** for 4 seconds to switch on. The green light will flash, and then the red and green lights will alternate in flashing, which indicates that it has entered into the matching mode.
- 2: Press and hold Key **||◀** for 4 seconds to switch off. The red light will flash.

Matching and automatic reconnection

Matching: Press and hold Key **||◀** for 4 seconds. When the red and green lights alternate in flashing, it has entered into the matching mode. Turn on the mobile phone or other devices that are equipped with Bluetooth play function and call function, switch on the Bluetooth to search for devices with Bluetooth function, and then select BTglasses K8 K9 in the search result. After successful matching, it can play music and be used for calling.

Volume control

Volume+: Press and hold Key **◀◀**
Volume-: Press and hold Key **▶▶**

Music keys instruction

Play/Pause: Press Key **||◀** shortly

Next track: Press Key **▶▶** shortly

Previous track: Press Key **◀◀** shortly

Re-calling: Press Key **||◀** twice

Charging alert: Insert it into a USB port for charging with voltage of 5V and its light being red (charging current should not exceed 1A, and 500mA is recommended)

Charging time: about 2 and a half hours

Language Mode

Under ON state, double click the middle button to switch between Chinese and English. (If the glasses have connected with the mobile phone, please turn off Bluetooth before switching the language)

Common troubleshooting

- 1: If the Bluetooth cannot be connected with the phone, check the Bluetooth to see whether it has entered the matching mode (red and green lights alternate in flashing) and check if the Bluetooth on the phone is turned on.
- 2: If the phone can't play music, check the Bluetooth on the phone to see whether it has turned on the media audio.

If the phone can't make or receive calls, check the Bluetooth on the phone to see whether it has turned on its audio. If there's something wrong with the keypad of the phone, check the Bluetooth on the phone to see whether it has turned off the input equipment.

3: If the Bluetooth cannot be charged, check the data cable port and charger plug to see if they are connected properly. (phone charger shares a port with a computer)

Caution

1: Please use this product according to local laws and regulations: when using this product during a drive or a ride, please make sure you are sufficiently focused in order to safeguard your safety.

2: To ensure your safety, please don't listen to loud music or use two headsets at the same time in places where your safety may be at risk.

3: Don't allow children to play with this product as the small parts may scratch them.

4: Please pay attention to the tips in some specific areas like a swimming pool or gas station

5: Do not dismantle or damage the built-in battery.

6: Please charge it within 30 days if you don't use it for a long time.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.