

## Manual de instrucciones




## Productos



**Recordatorio importante:**  
Antes de instalar el casco, conecte su teléfono móvil de acuerdo con la guía rápida del manual para comprobar el efecto de sonido y el volumen. Si hay una gran diferencia en el efecto de sonido y el volumen después de la instalación en el casco, por favor, ajuste la posición del altavoz dentro del casco.

## Encender/apagar


Pulse dos veces para cambiar entre anuncios de voz en español e inglés (Desconectar Bluetooth)



## Conexión Bluetooth



## Modo de carga



## Función música



## Emparejamiento de intercomunicadores



**Condiciones de conexión del intercomunicador:** una máquina tiene que estar en modo de recepción del intercomunicador, una máquina está en modo de transmisión del intercomunicador, para poder emparejarse.


**Luces del modo de intercomunicación:** la luz indicadora verde parpadea rápidamente, entrar en el modo de transmisión, y las indicaciones de voz; la luz indicadora verde parpadea lentamente, entrar en el modo de recepción, y las indicaciones de voz; en este momento, los dos pares de conectados, conectado con éxito, la luz indicadora de intercomunicación ha sido 15 intervalos parpadeando una vez, acompañado de las indicaciones de éxito de conexión de intercomunicación, en este momento usted puede hablar para hablar llamadas. **Mantenga pulsado el volumen hacia arriba y hacia abajo para ajustar el volumen del intercomunicador**

**Primera conexión:** después de que las dos máquinas estén encendidas, pulse brevemente la tecla de intercomunicación para entrar en el modo de intercomunicación, en este momento las dos máquinas están en el mismo modo de recepción de intercomunicación, en este momento necesita pulsar prolongadamente una de las teclas de intercomunicación para hacer que entre en el modo de transmisión de intercomunicación para el emparejamiento de intercomunicación.

**Intercomunicación de nuevo a la conexión:** dos días se han conectado a la máquina, sólo tiene que encender, pulse brevemente la tecla de intercomunicación para entrar en el modo de intercomunicación, las dos máquinas se conectarán automáticamente.

## Función de teléfono


Doble clic para cambiar entre respuesta manual/automática (Cuando Bluetooth no está conectado)



## Asistente de iluminación/voz



## Lista de artículos



## Advertencia

1. No ponga el producto en el fuego abierto para evitar explosiones;
2. por favor, no desmontar el producto, para evitar daños a la electrónica del producto;
3. Por favor, no cerca de los objetos punzantes, objetos para causar daños en el producto;
4. Por favor, colóquelo en un lugar seco si no se utiliza durante mucho tiempo.

# GT1 INSTRUCTION MANUAL FOR INTERCOM VERSION

## Product overview



**Important Notice:**  
Before installing the headphones, follow the Quick Manual instructions to connect your phone and listen to the sound and volume. If there is a large difference in sound effect and volume after installing it on the helmet, please adjust the position of the speaker in the helmet.

## Power on/off

### Power on

Double-tap to toggle Spanish-English voice over (Disconnect wireless)



Long press for 3 seconds to turn on the machine



### Power off



Press and hold for 3 seconds to shut down



## Pairing






Bluetooth mode tone




## Phone features



Double-click to toggle manual auto answering (When Bluetooth is not connected)



## Lighting/Voice Assistant



## Intercom pairing





**Intercom connection conditions:** one machine needs to be in intercom receiving mode, one machine is in intercom transmitting mode, in order to be paired.

**Intercom mode lights:** green indicator light flashes fast, enter the transmitter mode, and voice prompts; green indicator light flashes slowly, enter the receiver mode, and voice prompts; at this time, the two pairs of connectivity, connectivity success, the intercom indicator light has been 1S interval blinking once, accompanied by intercom connected to the success of the prompts, at this time you can talk to talk calls. Long press the volume up and down to adjust the intercom volume

**First time connection:** after the two machines are turned on, short press the intercom key to enter intercom mode, at this time the two machines are in the same mode intercom receiving mode, at this time you need to long press one of the intercom key to make it enter intercom transmitting mode for intercom pairing.

**Talking back to the connection:** two days have been connected to the machine, just power on the machine, short press the talkback key to enter the talkback mode, the two machines will be automatically connected.

## Music features




Volume + button


Long press on the next song

Long press on the previous song


## Charging mode



When the machine is turned on, plug in the charger and the machine will automatically shut down



## List of items



## Notes

1. Do not put the product into the open flame to avoid explosion;
2. Do not disassemble the product. Avoid damage to product electronics;
3. Do not approach the sharp object, the object will cause damage to the product;
4. Do not use for a long time, please place in a dry place.

## instruction warning

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions.

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.