

E27风扇灯

尺寸：80x100mm

材质：铜版纸 单色印刷 3页2折

SOCKET FAN LIGHT

2 IN 1 LED Light & Fan



INSTRUCTION

B001

正面

SPECIFICATION

|                         |                                                          |
|-------------------------|----------------------------------------------------------|
| Product Name            | Socket Fan Light                                         |
| Product Model           | AXW-SFL001                                               |
| Light Color Temperature | 3000K-6000K                                              |
| Wind Speed              | 1-6 Gears / Natural Wind Mode                            |
| Function                | Memory Function / Time Function / Sudden Stop Protection |
| LED Light Power         | MAX 18W                                                  |
| Fan Power               | MAX 10.5W                                                |
| Voltage Input           | 110-240V                                                 |
| Access Type             | E26/E27 Lamp Holder                                      |
| Material                | Screw into any standard lamp socket                      |
| Installation Mode       | Metal+ABS+PC                                             |

PACKAGE LIST



ASSEMBLY

**NOTE:** Fan blades are packaged separately from the main power unit. Assembly is required.

Insert each blade into the tab until it clicks into place, as shown at right.

The blades can only be inserted one way.

INSTALLATION

No tools required, turn the power OFF using the wall light switch for that socket before installing the unit.

**EQUIPPED WITH SAFETY OFF FEATURE**

If the blades come in contact with an object during operation, the fan will stop.

**To restart:**

**Option A:** Turn the power OFF using the wall light switch for that socket. Wait for 4-5 seconds, then switch it back on. The last used fanlight setting will resume.

**Option B:** Just wait 35 seconds before using the remote control again.



背面


PRODUCT SIZE



INSTALLATION STEPS

1. Turn off the main power switch.
2. Install the fan blades on the main body of the fan.
3. Screw the fan into the E26/E27 lamp holder, rotate it clockwise and secure it.
4. Turn on the power switch and use the remote control to control the lights and fans.

REMOTE CONTROL INSTRUCTIONS



NOTE:

1. Timing Button: Press it to set the timer for 2 hours. Once you've pressed this button, avoid pressing any other buttons to keep the timer working.
2. Remote control code matching: Press "SETUP" button within 5 seconds after turning on the power; the LED light will flash to indicate the success of the code matching. Otherwise, turn off the lamp and repeat this step. Once successful, one remote control can control multiple fan lights.
3. The fan light can be adjusted from 1 to 6 speed, with 3 color temperatures and stepless dimming.
4. The remote control without battery (Need 2 AAA batteries).

PRECAUTIONS:

1. Please keep the fan light out of the reach of children.
2. Even if we have a sudden stop protection, to reduce the risk of injury, please do not put fingers or other things into the working fan blades.
3. For daily cleaning, you can use a damp cloth to wipe the surface without using corrosive chemicals.
4. For use in open fixtures only.
5. Do not use with dimmer.
6. Do not place objects near the device.
7. Do not use with emergency exits.
8. The LEDs are not replaceable, for indoor use only.
9. Use in open luminaire only.
10. The socket fan light is high intensity LED bulb, do not stare directly into the LED light.



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### FCC Radiation Exposure statement

The device has been evaluatec to meel general RF exposure requirement. The device can be used in porlable exposure condition without restriction.