

**Descripción del producto**

Gracias por elegir los auriculares estéreos inalámbricos NW3709, usan la última tecnología Bluetooth 5.3 y cuentan con un diseño elegante y minimalista, pueden usarse individualmente o ambos a la vez. Su sonido es de alta calidad y dispone de una estación de carga portable.

**Contenido del embalaje**

- NW3709 (auricular derecho, izquierdo y estación de carga)
- Cable USB-C
- Guía de usuario

Nota: Asegúrese de que su embalaje contiene los elementos descritos arriba. Si encuentra que falta algún elemento o está dañado, por favor, contacte con la tienda donde adquirió el producto.

**Instrucciones de seguridad y mantenimiento**

Lea la guía de usuario antes de su primer uso.

Mantenga el dispositivo lejos de zonas húmedas y de fuentes de calor. No abra las distintas partes, peligro de cortocircuito.


No introduzca nada por sus distintos orificios peligro de cortocircuito.

No cargue la estación de carga a una tensión superior a 5VDC/1A.

No cargue los auriculares en otra estación de carga que no sea la suministrada con el producto, peligro de sobretensión y cortocircuito.

Para una mejor calidad del sonido use los auriculares cerca del dispositivo Bluetooth enlazado, máxima distancia 10m.

Adecue el volumen de los auriculares para no dañar sus oídos.

**Descripción de las partes****Primeros usos**

Cargar auriculares: Coloque los auriculares en sus respectivos orificios de la estación de carga para comenzar la carga.




El indicador del auricular se iluminará en color rojo y el indicador de la estación de carga en color blanco, cuando se apaguen estará completamente cargados.

Nota: Durante su uso, cuando la batería del auricular esté baja escuchará un sonido "Battery Low" indicando que la batería está baja y debe ser cargada.

**Cargar estación de carga**

Para cargar la estación de carga conéctele el cable USB-C suministrado entre el puerto de carga USB-C de la estación de carga y un adaptador AC/DC de 5VDC/1A, 5W (No suministrado), el indicador de la estación de carga parpadeará en color rojo durante la carga y cuando el indicador esté iluminado fijo habrá finalizado la carga.



La potencia suministrada por el cargador debe ser de entre un mínimo de 2.5 vatios requeridos por el equipo radioeléctrico y un máximo de 5.0 vatios a fin de alcanzar la máxima velocidad de carga.

**Encender Apagar**

-Encender: Extraiga los auriculares de la estación de carga, se encenderán automáticamente, escuchará "Power ON" (Encendido en inglés) y "Connected" (Conectado en inglés una vez emparejado)

-Apagar: Método 1: Coloque los auriculares en la estación de carga, se apagarán automáticamente.

Método 2: Mantenga presionado el botón táctil multifunción, escuchará "Power OFF" (Apagado en inglés)

Nota: Se apagarán automáticamente cuando los auriculares estén alejados de su dispositivo Bluetooth durante 5 minutos.

**Enlazar auriculares**

Extraiga los auriculares de la estación de carga, y empezará a parpadear el indicador del auricular en color rojo y blanco, habilite la función Bluetooth en su dispositivo, busque y seleccione "NW3709" en su lista de dispositivos Bluetooth y realice la conexión y una vez emparejados escuchará "Connected" (Conectado en inglés) y se apagará el indicador.  
Nota: Una vez apagado, cuando vuelva a encenderse los auriculares se reconectarán automáticamente.

**Escuchar música:** Asegúrese de que sus auriculares estén conectados con su teléfono móvil y podrá reproducir y escuchar música de su lista de reproducción. Durante la reproducción, presione dos veces el botón táctil multifunción derecho o izquierdo para pausar la música y vuelva a reproducir presionándolo dos veces de nuevo.

Para pasar a la siguiente canción presione tres veces en el botón multifunción derecho, para pasar a la canción anterior presione tres veces en el botón multifunción izquierdo.

Para aumentar el volumen presione una vez el botón táctil multifunción derecho, para disminuir el volumen haga lo mismo en el botón táctil multifunción izquierdo.

**Realizar llamadas:** Asegúrese de que sus auriculares estén enlazados con su Smartphone y podrás responder, colgar o rechazar llamadas. Responda la llamada presionando dos veces el botón táctil multifunción derecho o izquierdo, si decide rechazar la llamada mantenga presionado el botón táctil multifunción derecho o izquierdo durante 2 segundos, si decide colgar una llamada presione dos veces el botón táctil multifunción derecho o izquierdo durante la llamada.

**Asistente Siri o Google:** Para habilitar el asistente presione el botón táctil multifunción izquierdo durante 3 segundos y suelte.

**Modo Juego o Música:** Para habilitar el modo juego presione el botón táctil multifunción derecho durante 3 segundos y suelte. Escuchará "Game Mode", vuelva a repetir este proceso para volver al modo música y escuchará "Music Mode".

**Technical support**

For more information about the installation and configuration of this product, please visit our website [www.ticnova.es/netway-innobo](http://www.ticnova.es/netway-innobo) or send an e-mail to the following address: [consultas@ticnova.es](mailto:consultas@ticnova.es)

**Soporte técnico**

Para obtener más información acerca de la instalación y configuración de este producto, por favor visite nuestro sitio web [www.ticnova.es/netway-innobo](http://www.ticnova.es/netway-innobo) o envíe un e-mail a la siguiente dirección: [consultas@ticnova.es](mailto:consultas@ticnova.es)

**Recycling:** AEE RII-RAEE 5548. In this manual, the crossed-out bin symbol indicates that the product is subject to a European directive, 2012/19/UE, electrical or electronic products, batteries, and accumulators and other accessories necessarily must be subject to selective collection. At the end of the device's useful life, make use of the recycling containers. This gesture will help reduce health risks and preserve the environment. Town halls and distributors will provide you with the essential details regarding the recycling of your old device. If this device has an internal battery, it must be removed and deposited separately for proper management. Please recycle, the packaging of this product is recyclable. The product box is made of cardboard and must be recycled in the blue container or destined for cardboard and the internal protections and bags are made of plastic and must be recycled in the yellow container or destined for plastic. We can help to conserve the planet.

**Reciclado:** AEE RII-RAEE 5548. En el presente manual, el símbolo del contenedor tachado indica que el producto está sometido a una directiva europea, la 2012/19/UE, los productos eléctricos o electrónicos, las baterías, y los acumuladores y otros accesorios necesariamente han de ser objeto de una recogida selectiva. Al final de la vida útil del dispositivo, haz uso de los contenedores de reciclaje. Este gesto ayudará a reducir los riesgos para la salud y a preservar el medioambiente. Los ayuntamientos y los distribuidores, te aportarán las precisiones esenciales en materia de reciclado de su antiguo dispositivo. Si este dispositivo lleva una batería interna, deberá extraerse y ser depositada separadamente para su adecuada gestión. Por favor recicla, el envase de este producto es reciclable. La caja del producto es de cartón y debe ser reciclada en el contenedor azul o destinado para cartón y las protecciones internas y bolsas son de plástico y debe ser reciclado en el contenedor amarillo o destinado para plástico. Entre todos podemos ayudar a conservar el planeta.



**Product description**

Thank you for choosing the NW3709 wireless stereo headphones, they use the latest Bluetooth 5.3 technology and have an elegant and minimalist design, they can be used individually or both at the same time. Its sound is high quality and it has a portable charging station.

**Contents of the packaging**

- NW3709 (Left earbud, right earbud and charging station)
- USB-C cable
- User guide

Note: Please ensure that your packaging contains the items described above. If you find any items missing or damaged, please contact the shop where you purchased the product.

**Safety and maintenance instructions**

Please read the user guide before first use.

Keep the device away from humid areas and heat sources.

Do not open the various parts, danger of short circuit.


Do not insert anything through its different holes, danger of short circuit.

Do not charge the charging station at a voltage higher than 5VDC/1A.

Do not charge the headphones in any charging station other than the one supplied with the product, danger of overvoltage and short circuit.

For better sound quality, use the headphones close to the paired Bluetooth device, maximum distance 10m.

Adjust the volume of the headphones to avoid damaging your ears.



1. Earbud.
2. Earbud indicator.
3. Eartip.
4. Charging Station indicator.
5. Charging Station.
6. USB-C charging Port.



7. Left touch multifunction button.
8. Right touch multifunction button.

**Getting started**

**Charge Earbuds:** Place the earbuds into their respective holes on the charging station to begin charging.



The headset indicator will light up in red and the charging station indicator in white, when they turn off it will be fully charged.

Note: During use, when the headset battery is low you will hear a "Battery Low" sound indicating that the battery is low and needs to be charged.

**Charge charging station**

To charge the charging station, connect the supplied USB-C cable between the USB-C charging port of the charging station and AC/DC adapter 5VDC/1A, 5W (Not supplied), the charging station indicator It will flash red during charging and when the indicator is fixed, charging is complete.

The power delivered by the charger must be between min 2.5 Watts required by the radio equipment, and max 5.0 Watts in order to achieve the maximum charging speed.

**Turn On / Off:** Turn ON:

Take out the earbuds from the charging station, they will turn on automatically, you will hear "Power ON" and "Connected" once paired.

Turn Off:

Method 1: Put the earbuds on the charging station, they will turn off automatically.

Method 2: Press and hold the multi-function touch button on each earbud, you will hear "Power OFF"

Note: They will automatically turn off when the headphones are away from your Bluetooth device for 5 minutes.

**Pair Earbuds:** Take out the earbuds from the charging station, and the earbud indicator will start flashing red and white, then enable the Bluetooth function on your device, search and select "NW3709" in your Bluetooth device list and make the connection and a Once paired you will hear "Connected" and the indicator will turn off.

Note: Once turned off, when turned on again the headphones will

automatically reconnect.

**Listen to music:** Make sure your earbuds are connected with your mobile phone and you can play and listen to music from your playlist. During playback, press two times the right or left multi-function touch button to pause the music and resume playing by pressing it two times again.

To go to the next song press the right multifunction button three times, to go to the previous song press the left multifunction button three times.

To increase the volume, press the right multifunction touch button one time, to decrease the volume, do the same on the left multifunction touch button.

**Make calls:** Make sure your earbuds are paired with your Smartphone, you can answer, hang up or reject calls.

Answer the call by pressing the right or left multi-function touch button twice, if you decide to reject the call press and hold the right or left multi-function touch button for 2 seconds, if you decide to hang up a call press the right or left multi-function touch button twice during the call.

**Siri or Google Assistant:** To enable the assistant press the left multifunction touch button for 3 seconds and release.

**Game or Music Mode:** To enable game mode, press the right multifunction touch button for 3 seconds and release.

You will hear "Game Mode", repeat this process again to return to music mode and you will hear "Music Mode".

**Declaración UE de conformidad simplificada**

Por la presente, APPROX IBERIA S.L. declara que el tipo de equipo radioeléctrico NW3709 es conforme con las Directivas 2014/53/EU y 2011/65/EU con la enmienda (EU) 2015/863.

El texto completo de la declaración UE de conformidad está disponible en la dirección de internet siguiente: <https://bit.ly/3QhiADH>

**EU Declaration of conformity simplified.**

Hereby, APPROX IBERIA S.L. declares that the radio equipment NW3709 is in compliance with Directives 2014/53/EU and 2011/65/EU its amendment (EU) 2015/863.

The full text of the EU declaration of conformity is available at the following internet address: <https://bit.ly/3QhiADH>

NW3709

AURICULARES TWS  
NETWAY X130 BLUETOOTH

GUÍA DE USUARIO  
USER'S GUIDE

Leer las instrucciones  
antes de usar.  
Read the instructions  
before using.

ticnova.es

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.