




Size:90x120mm



USER MANUAL
KIDS KARAOKE MIC



Power ON/OFF Key
Short press: Play/pause while music is playing
Long press: 3 seconds to turn ON/OFF
Double clicks: Turn on/off two microphones connected to each other

M Key (Modes switch)
Short press: Toggle switch microphone Playback mode/LINE IN mode /Bluetooth mode
Long press: Switch the flashing modes of light

Volume Up and Down keys
△ :Short press the head volume plus,Double click the reverberation volume plus
Long press the music volume plus
▽ :Short press the head volume reduction,Double click reverb volume reduction
Long press music volume reduction

Voice Changing key
Short press: Voice changing effects switch to be Male voice /Female voice/Baby voice/Monster voice/Original voice
Double clicks: original /accompaniment

5V charging/AUX
Switch to LINE IN mode then use LINE IN cable, the end of Type-C to plug into AUX port on the bottom of microphone, and using the 3.5 mm plug (the other end of same cable) to connect with mobile phone to start your recording or singing.

Earphones jack
Connect to a 3.5 mm earphone.

Note: On LINE IN mode, the speaker volume increase or decrease is invalid.

Product	KIDS KARAOKE MIC
Model	L8
Bluetooth Version	V5.3
Rated Power	5W
Weights	270G
Size	210*87MM
Battery	1200 mAh
Charging	DC 5V - 0.5A

PAIRED WITH DIGITAL DEVICES


- Long press the power button for 3seconds.Then the blue light flashing and speaker is waiting for connection.
- Turn on the Bluetooth connection of your devices to search for "L8" and click "Connect".
- The speaker will play the sound of 'dong', then the blue light is steady on. That means the connection is successful.If the connection is not successful. the blue light blinks slowly.
- After pairing, press the Play button to play or pause the music.

Battery Charging


The red light indicator will be steady on during charging and will be off after battery is fully charged. When the battery is low, the battery alarm sound will be broadcasted for three times , and the system will be shutdown at the fourth alarm . Please use a DC- 5V power adapter for charging .Improper power adapter such as 9V or 12V Quick charger may cause hardware damage or other faults.

Matters need to be attention

- Wireless signal transmission including Bluetooth is greatly affect by the surrounding environment such as metal, tree, human body,..etc.. and the appropriate distance is also affected.
- Do not charge the battery under fire and high temperature conditions!
- Do not use the speaker where to close the heat sources(such as fire or heater)
- Do not place the product in a heat source , such as to keep under the strong sunlight or outdoor car exposed under the sunlight, which will degrade the battery performance or battery life.
- If you don't use it for a long time,ensure that the battery level is above 50%,and then store it safely. It is recommended to store the product in indoor warehouse with humidity less than 75% at 25°C to minimize the capacity attenuation of the battery cell. During the transportation, the products should be protected from rain and water,and should not be kept in high temperature environment for along time.



MANUAL DE USUARIO
MICROFONO INALAMBRICO
KARAOKE



Boton de encendido/apagado
Pulsación breve: reproducir/pausar mientras se reproduce música
Pulsación larga: 3 segundos para encender/apagar.
Doble clic: enciende/apaga dos micrófonos conectados entre sí

Boton M (Interruptor de modos)
Pulsación corta: interruptor de palanca del micrófono
Modo de reproducción/modo LINE IN/modo Bluetooth
Pulsación larga: cambia los modos de luz intermitente.

Botones para subir y bajar volumen
△ :Presione brevemente el volumen de la cabeza más
Haga doble clic en el volumen de reverberación más
Mantenga presionado el volumen de la música más
▽ :Presione brevemente la reducción del volumen del cabezal.
Reducción del volumen de reverberación con doble clic
Reducción del volumen de la música con pulsación larga

Boton de cambio de voz
Pulsación breve: los efectos de cambio de voz cambian para ser voz masculina/voz femenina/voz de bebé/voz de monstruo/voz original
Doble clic: original/acompañamiento

Carga de 5 V/AUX
Cambie al modo LINE IN, luego use el cable LINE IN, el extremo del tipo C para conectarlo al puerto AUX en la parte inferior del micrófono y use el enchufe de 3,5 mm (el otro extremo del mismo cable) para conectar con el teléfono móvil para iniciar su grabar o cantar.

Auriculares
Conéctelo a un auricular de 3,5 mm.

Nota: En el modo LINE IN, el aumento o disminución del volumendel altavoz no es válido.

Producto	MICROFONO INALAMBRICO KARAOKE
ModelO	L8
Bluetooth	V5.3
Potencia	5W
Peso	270G
Medidas	210*87MM
Bateria	1200 mAh
Carga	DC 5V - 0.5A

Emparejamiento con otros dispositivos

- Mantenga presionado el botón de encendido durante 3 segundos. Luego, la luz azul parpadea y el altavoz está esperando la conexión.
- Encienda la conexión Bluetooth de sus dispositivos para buscar "L8" y haga clic en "Conectar".
- El altavoz reproducirá el sonido de 'dong' y luego la luz azul permanecerá encendida. Eso significa que la conexión se realizó correctamente. Si la conexión no se realizó correctamente, la luz azul parpadea lentamente.
- Después del emparejamiento, presione el botón Reproducir para reproducir o pausar la música.

Carga de Bateria

El indicador de luz roja permanecerá fijo durante la carga y se apagará después de que la batería esté completamente cargada. Cuando la batería está baja, el sonido de la alarma de batería se transmitirá tres veces y el sistema se apagará a la cuarta alarma. Utilice un adaptador de corriente CC de 5 V para cargar. Un adaptador de corriente adecuado, como un cargador rápido de 9 V o 12 V, puede causar daños al hardware u otras fallas.

Cuidados

- La transmisión de señal inalámbrica, incluido Bluetooth, se ve afectada en gran medida por el entorno circundante, como metal, árbol, cuerpo humano, etc., y la distancia adecuada también se ve afectada.
- ¡No cargue la batería en condiciones de fuego o altas temperaturas!
- No utilice el altavoz cerca de fuentes de calor (como fuego o calentador).
- No coloque el producto en una fuente de calor, como mantenerlo bajo la luz solar intensa o en un automóvil al aire libre expuesto a la luz solar, lo que degradará el rendimiento o la duración de la batería.
- Si no lo usa durante un período prolongado, asegúrese de que el nivel de la batería esté por encima del 50 % y luego guárdelo de forma segura. Se recomienda almacenar el producto en un almacén interior con una humedad inferior al 75 % a 25 °C para minimizar la atenuación de la capacidad de la celda de la batería. Durante el transporte, los productos deben protegerse de la lluvia y el agua, y no deben mantenerse en ambientes con altas temperaturas durante mucho tiempo.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.