



BT18 User Manual

1) Androld smart phone: the cap will be alarming with "DONG, DONG..." while somebody calling.

IPhone: the Headset will be alarming with phone calling muss which is the same as the phone calling muss which is the same as the phone calling muss the phone press the power button one time to pick phone or the process.

phone up.

3) Henglary Press the button again to hanging.

4) Redial phone function: Press the button two times to redial the most excertly phone number directly.

5) Prome number broadcasting: somebody call you, the desire will sound broadcast the calling phone number, and the user will easy to know who calling.

Power save mode The device will be off automatically after 5 minutes if no working device paired.

Low power warning The device will be with the sound remind of "power low" while is working, it seems the power not enough, need to be

Power Off

Press the button 3 seconds again, the device closed with the sound reminder of "power off", and the LED indicator off.

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two

- Net8s, Operation is suggest on the response, we conditions:

 ordinary of the state curiount to Part 15 of the PCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. The equipment generates uses and can relative radio accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference are find communications. However, there is no guarantee that interference are find communications, however, there is no guarantee that interference and are obtained to the communication of the communication oursuant to Part 15 of the FCC Rules. These limits

Micro-USB to USB charge cable Wirelessly listen to music with integrated

Wireless Earphone

User manual

technology,

Fashion design, let music surrounding your life any

These instructions are for your safety. Please read through them thoroughly before use and retain for future reference.

- Hands free function, truly free your hand.
- Set-in rechargeable Li-ion battery, long stand-by and
- Sekin rechargeable Li-on battery, long stand-by and working time,
 Support power displaying on iPhone, easy to know when will to be charged.
 DIY design, available to be detachable when you want.
 Sound reminder function, easy to set the device according to sound remind.
- Please make sure the charging time is about 2 hours at the first time.

RF warning statement The device has been evaluated to meet general RF exposure requirement, The device can be used in portable exposure condition without restriction. Do not throw the device in a fire, battery may explode or

- |cak.

 The Helmet with the electronic core shall not exposed to excessive heat such as burning sun, fire or the like.
- Do not replace the set in rechargeable Lition battery along

AIIII

SPECIFICATIONS

- Frequency: 2.402GHz-2.480GHz
 Range: 30-40 meters (depending on device)
 Transmission distance of Microphone: £1 meter
 LHon battery: 3.7V/1000mA
- LHon battery: 3,7V/1000m
 Playback time: ≤4hrs
 Charging Volkage: 5V
 Charging time: ≤1 hrs
 Standby time: ≤240 hrs
 Connection name: BT=18

Pairing
1. Press the BUTTON 3 seconds with the sound reminder
of "power on" and the sound
reminder of "pairing", then seek the Connection name
of "BT-18" to pair,

2. Automatically repair

If your device is the latest recent paired device, the headset will be automatically re-paired with your device when the device open it again. 3. Automatically search

The device will be automatically into pairing mode again once the paired device is off.

Broadcasting/Pause

Press button to pause the song, press it again to continue

Upper song/decrease the sound press'-" one time for upper song, continue press the button to decrease the sound.

E 6 6

Off Road FLIP UP Half Face Full Face

talacion universal

Next song/increase the sound
Press "+" one time for next song, continue press the button
to increase the sound.





Fig.5













Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice. Attention should be drawn to the environmental aspects of battery disposal.



Note: the Device can not be music playing or call answering while it is charging.

And then, put the suitable position, try to put the helmet on the head so that the device is on suitable position, you can modify the position by hand in order to well use it. eference, Fig. 3)

step i Take out the Wireliess part from the color box, and find out the two earphone, put the earphone into the both sides of the ear position via magic tape (reference, Fig. 2)

Note: the Device will need to be fully charged prior to initial userspapers. J hours, initial userspapers. J hours in the charge cable to the neurosciells prior in the Capffig. 1).

2. Connect the USB and of the charge cable to the neurosciells prior in the Capffig. 1).

3. The LDD midstaler (Fig. 1) will turn sold RED while charged cable to the computer or obspirence including and will knaped.



Move the clip and align it on the left side of the helmet Edge in.

Adjust the position of Bluetooth core from left to right Then lock the upsetting wire and fix it.

Fig.3









