

ZANSONG®

MODEL: S99

User Manual

PROFESSIONAL ACTIVE SPEAKER



Silakan baca petunjuk dengan seksama sebelum menggunakan

Product Features

Product Features.....1
Instructions.....2
Function Operational manual.....3-7
Technical Indicators.....8
Packing list.....8
Ordinary fault diagnosis and self repairing.....9

Product Features

Dear customers:

Thank you for choosing our microphone , the multifunctional microphone can be used for teaching, tour guide, speech and shopping guide, apply to school, supermarket, tour, indoor and outdoor activity and so on. It's small and portable, the sound is clear and loud, operation is simple, with large capacity Li-ion battery, can play long time.

Flammable and Explosive area

Please turn off your microphone at the flammable and explosive area, in order to avoid explosion or fire, please comply with user manual and related marks.

Flammable and Explosive area include the followings but not only those area:

1. Gas station
2. Fuel section (such as capsule under the deck of boat)
3. Facility of transportation and store for flammable or heavy chemicals
4. The area with dangerous of explosion marks
5. The area with 'turn off the two way radio apparatus' marks
6. USB port cannot be used as power output , the voltage is for data transmission only .
7. High capacity Lithium battery is installed inside the machine, , it cannot be exposed to the sun, fire and other overheated environment .
8. The model is suitable for using at non-tropical climates area.

Instructions:

INSTRUCTIONS:

1. Take out the main machine, set up the belt (there are two iron on the opposite sides of main machine), put the main machine on your shoulder, you can adjust the length of belt to put the main machine on the suitable position.
2. Put the headset microphone on your head, adjust it to 1-2cm from your mouth, put the microphone head into the main machine's MIC jack, then slowly adjust the volume to your satisfied volume.
3. When play music, adjust the master volume, avoid to play in the loudest sound for long time, or it will make you feel upset and speed the ageing of components.

PLEASE ATTENTION:


1. For the best sound effect, we suggest charge the power full for the first time using.
2. When it is in FM radio , it cannot use microphone .
3. when LED display screen's 'lack of power' symbol appears flashing, please recharge in time, or it will happen no voice.

Function Operational Manual

PRODUCT FEATURES

1. Adopt the latest decoding chip , support USB , TF and BT
2. Dual power mode , DC-5V and lithium battery .
3. Support PC , MP3,MP4, and 3.5MM input of mobile .
4. Support Karaoke .
5. Support recording .

Function Operational manual:



Function Operational manual:

1. Echo
2. Master volume & ON/OFF
3. Microphone
4. USB port
5. TF jack
6. AUX IN
7. Mode : Press is switch USB , TF , AUX IN , BT function , long press is for search BT .
8. Recording: Short press is play recording file . Long press is for recording function.
9. Previous: When read USB/TF card , choose the previous song and then short press Long press is for volume down.. when FM works, short press is for previous channel , when BT works , short press is for previous song .
10. PLAY/PAUSE: When read USB/TF card , show press is for play/pause, long press is for repeat , when FM works, show press is for mute, long press is for searching channel automatically.
11. NEXT: When read USB/TF card , choose the next song and then short press Long press is for volume up. when FM works, short press is for next channel, when BT works , short press is for next song .
12. REC MIC
13. DC 5V
14. LED light


Function Operational manual:

BT operation method

When turn on the power and the speaker will automatically prompt for BT status .

Open the BT in your mobile , search model no. ,the phone shows a "didi" prompt for the successful sound ,then it is connect BT successful .

Function Operational manual:



1. REC
2. MODE
3. Play/Pause: press it is for switch of play and pause; when FM radio works, press it is for searching channel automatically; long press it is for Enter/Exit play recording files;
4. Channel-: when FM works, press it is for previous radio station;
5. Channel + : when FM works, press it is for next radio station;
6. Mute: when press it, the sound disappear, when press it again, recover the sound;
7. Volume -: press it is for volume down;
8. Repeating mode: press it is for choosing the repeating mode, switch between one song repeat and all songs repeat;
9. Volume + : press it is for volume up, the maximum volume is 31.
10. Previous song: press it is for previous song;
11. Next song: press it is for next song;
12. 0-9 number key: you can choose songs or FM program just by pressing number key, for example, if you want to listen the 3th song, just need to press the number key "3", the LED screen will display "0003", after 3 seconds it will play the 3th song; If you want to list the 12 th song, please press number key "1" firstly, then press number key press number key "2", it will switch to 12 th song, you can use similar way to choose any song.

Technical Indicators

Output power.....	20W
Frequency.....	100Hz-15KHz
Input impedance.....	10k Ω
Output impedance.....	3 Ω
Speaker size.....	6.5"
Input power.....	DC-5V

Packing list

Speaker.....	1pc
Adaptor	1pc
User manual.....	1pc
Remote control	1pc
Wireless Microphone.....	2pcs

Ordinary fault diagnosis and self repairing

Common problem's self solve

1. When it turns on, microphone has no voice?
 - a. If the LED is off, battery has no power , please recharge
 - b. If the LED is on, you can check if the microphone insert a wrong place.
2. Microphone has obvious screaming
 - a. Please check if wear the head microphone right, the microphone cartridge head should face the direction of mouse.
 - b. When the space become smaller, please turn down the volume to reduce the screaming caused by echo.

Matters need attention

1. In order to avoid the damage of battery, we suggest use our original charger.
2. For the best loudspeaker effect, please speak to the microphone cartridge head, if has screaming
3. Please don't insert and extract earphone jack, in order to avoid bad contact, cables should insert to right hole.
4. In order to keep the battery life, we suggest to recharge after using up the battery, frequent recharge will accelerate battery chip ageing. If don't use for a long time, please recharging every two month.
5. Please don't put main machine and the bank card or magnetic goods together, in order to avoid the trouble caused by loss of magnets.
6. The accessories is designed according to operational need, if you need to replace them please use original, for the best working conditions.
7. LED display screen's 'lack of power' symbol appears flashing, please recharge, otherwise it will shut down automatically.
8. The model is suitable for using at non-tropical climates area.

FCC Warning Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.

This equipment should be installed and operated with minimum distance 5mm between the radiator & your body.