# Smart Boxing

# **New generation · Trendy gameplay**

Using a new type of induction counting, through the combination of rhythm and boxing movements, it stimulates the body's potential and improves reaction ability.



### **Function Description**

- 1. Long press the middle touch switch (long press has digital tube timing effect); short press to adjust
- The volume is switched cyclically between 0 and 3 levels.
- 2. After turning on the machine, touch the left side to adjust the speed, and the digital tube displays H1~H15; touch the right side to adjust the mode, and the digital tube displays P1~P15. The hitting position will be different in different modes. 3. When you hit the correct position within the limited time, the hit position indicator light will go out, the hit indicator light will light up briefly, and a hit sound effect will sound. Then the foot quickly switches to the next striking position. When hitting the wrong position within the limited time, a hit will be issued.
- Wrong sound effects.
- 4. After using a mobile phone or other electronic device to connect to the Bluetooth of the product, you can replace the device.
- Prepare your own background music to play music from your mobile phone or other electronic devices.
- 5. If there is no hitting action within 3 minutes, the system will automatically shut down and enter low power.
- consumption mode.
- 6. The charging voltage is 5V-USB charging. When the power is turned off and charged, the digital tube will display charging.
- Animation; no charging animation when not charging or after fully charging.
- 7. When the battery voltage is lower than 3.3V, the system will display abnormally or automatically shut down.
- Phenomenon. If these phenomena occur, please charge in time.

# **Troubleshooting**

- 1. No light and sound: The product is not turned on or the battery is low. Short press the power button or charge the product.
- 2. The light flashes: the battery power is too low, please recharge this product.
- 3. Short press the switch cannot turn on: long-term inactivity may cause chip defects, please press the switch key repeatedly.
- 4. Impact sound inside the equipment: It is emitted by the internal active stressed structure and is a normal phenomenon.


## Product description

Product name: Smart music boxing target


Product material: carbon fiber+pp

Applicable: professional

training/children/amateur fitness









## **Installation Notes**

#### Installation method 1:

- 1. First, fix the No. 2 and No. 3 holes of the bracket to the two holes on the back of the boxing target with flat-head screws.
- 2. Draw the No. 1 and No. 4 holes of the bracket on the wall, drill the holes with an impact drill, and use expansion screws

Fixed on the wall.

3. Before using the product, please make sure it is installed firmly.

#### Installation method 2:

- 1. First, peel off the double-sided tape on half of the EVA.
- 2. Align the EVA sticker on the back of the product.
- 3. Tear off the double-sided tape on the lower part of the EVA sticker.
- 4. Place it in place and stick it firmly on the wall.

#### Installation method 3:

- 1. Align the adhesive Velcro on the back of the product.
- 2. Tear off the double-sided tape on the upper part.
- 3. Place it in position and align it with the wall.

## Things to note

- 1. Please fix this product on a strong and reliable wall. When hitting, please hit within the hitting area.
- Hitting, it is strictly forbidden to hit the corner area to avoid hand injury or equipment damage.
- 2. This product is suitable for adults. Children should use it under adult supervision.
- 3. Beginners should not hit too hard to avoid hand injuries. The first thing to pay attention to during exercise is
- Safety, leg strikes and knee strikes are strictly prohibited.
- 4. It is strictly prohibited to hit the speaker area.
- 5. If the device cannot be turned on or has abnormality, please check whether the battery is too low and charge it in time.
- The duration should not exceed 8 hours. If not used for a long time, it is recommended to charge once every 1-2 months.
- 6. This product is not waterproof. When wiping the boxing target, use a dry cloth and do not get it wet.
- 7. Please keep the instructions properly for emergency use.





#### **FCC Statement**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- •Reorient or relocate the receiving antenna.
- •Increase the separation between the equipment and receiver.
- •Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- •Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

#### RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.