

Smart Projector



on

This manual is for reference only. It is subject to change without prior notice. Hotack reserves the right of final interpretation of the information contained in this manual.

ector is non dustproof or waterproof.

to reduce the risk of fire and electric shock, do
the projector to rain and fog.

use the original power adapter. The projector
work under specified rated power supply.

projector is working, please do not look directly
at the projector. The strong light will flash your eyes and cause
harm. Children should use the projector under the
supervision of adults.

Never cover the vents of projector. Heating will reduce
the life of projector and cause danger.

Always clean projector vents, or dust may cause
malfunction.

Do not use the projector in greasy, damp, dusty or smoky
environments. Oil or chemicals will cause malfunction.

Handle with care during daily use.

Turn off the power if the projector is out of use for
long periods of time.

Professionals are forbidden to disassemble the
projector for testing and maintenance.





Focus Wheel

A close-up photograph of the camera lens on the yellow sensor unit. The lens is a black, circular component mounted on a yellow base. An arrow points to the lens, and the word "Lens" is written next to it.



and Functions | App Store



can be ins
after insta
the mark
d convenie



100




Ergonomics in Design 2008, 27(1), 101–110



ng, WIFI “(

10 of 10

Language Settings



Other Setti

