

# M52使用说明书




使用前请仔细阅读说明书，并妥善保管

## 佩戴方法



像佩戴耳夹一样将夹耳式耳机夹在耳朵上。佩戴好后调整耳机的位置直至调整到音效最为清晰的位置。

## 触摸的位置和操作方式



触摸位置 触摸位于左右两只耳机的上侧。您可以通过轻触触摸来执行基本操作。

## 耳机配对

把两只耳机从充电仓分别取出，两只耳机会自动开机并进行配对，配对时，左、右耳机红灯指示灯交替闪烁，当一只耳机红灯指示灯交替闪烁，另一只耳机红灯指示灯熄灭，表示耳机配对成功，打开手机蓝牙功能，搜索“M52”并点击连接，连接手机后两只耳机都不闪烁。

## 操作功能说明

1. 开机  
方式一：从充电仓拿起耳机自动开机  
方式二：长按耳机2秒开机
2. 关机  
方式一：放进充电仓自动关机  
方式二：开机状态下长按3秒关机
3. 音乐播放  
暂停/播放：双击任意一个耳机  
上一曲：双击左耳耳机  
下一曲：双击右耳耳机  
音量加：三击右耳耳机  
音量减：三击左耳耳机  
召唤 Siri：长按任意一个耳机2秒
4. 电话模式  
接听/挂断电话：双击任意耳机  
拒接电话：单击任意耳机
5. 单耳连接使用：从充电仓单独拿出一个耳机，耳机自动开机闪烁红灯，打开手机蓝牙功能，搜索“M52”并点击连接即可。
6. 中英文切换  
未连接蓝牙状态下双击切换中英文默认英文。

## 关于充电

耳机充电：耳机放置进充电仓，耳机充电指示灯红灯常亮，充电仓L/R指示灯亮起闪烁，提示：充电仓电量低于20%，充电仓数显屏亮起闪烁，为保持设备正常工作，请尽快给充电仓充电。  
耳机充满：耳机充满后，耳机充电指示灯灯熄灭，充电仓数显屏熄灭，充电仓给耳机充电；耳机放置进充电仓，充电仓电量亮起，L/R指示灯亮起闪烁。

充电仓充电：将Type-C充电线插入充电仓Type-C充电口，充电仓数显屏未显示数字时，充电仓显示100。  
支持协议：iOS系统同步显示，安卓系统可加减音量但手机无显示。  
耳机电量显示：手机右上角可显示耳机真实电量。  
耳机低电量警告：当耳机电池电压低于3.3V时，每分钟提示一次，直到耳机关机。

## 产品描述

- 产品型号：M52
- 蓝牙版本：V5.3
- 支持协议：BR+EDR+BLE
- 工作电压：3.1V-4.2V
- 充电电压：5V-1A
- 耳机电池容量：30mAh
- 收纳仓电池容量：200mAh
- 传输距离：10m
- 通话时间：4小时
- 播放时间：4小时
- 耳机充电时长：1-1.5小时
- 收纳仓充电时长：1-2小时
- 支持系统：所有蓝牙功能设备与手机
- 包装清单：充电仓\*1，耳机：L/R，数据线\*1，说明书\*1

## 常见问题：

- Q: 充电仓不进水？  
A: 请更换一条数据线尝试一下，或检查接口是否接好。
- Q: 耳机充不进电？  
A: 确认充电仓有电，把耳机多拿几次用手把耳机压好让充电触点充分接触。
- Q: 耳机信号不稳定或耳机没声音？

- A: 请按正确方式佩戴耳机，使用时不要堵塞或阻碍物，户外使用时请尽可能将手机前置口袋。
- Q: 搜索蓝牙时出现两个“M52”配对名？  
A: 需要将手机设备上两个配对名删除，然后从充电仓取出重新配对，然后连接手机
- Q: 接听电话声音小或不清晰？  
A: 请尽量把耳机或手机音量调到最大，并且手机不要离耳机太远。
- Q: 如何把两只耳机分别连到两部手机使用？  
A: 将一只耳机从充电仓取出，自动开机闪烁红灯，打开手机蓝牙搜索M52连接即可连接成功不闪烁。第一只耳机与第一部手机连接成功后，再开第二只耳机与第二部手机连接。
- Q: 耳机不充电  
A: 耳机充电铜柱或充电仓充电顶针脏污，用酒精或清洁剂清洗

## 注意事项：

1. 请在有效环境(无阻碍10米)中使用本产品，超过有效距离可能会出现卡顿及延迟，请按说明书正确使用。
2. 给充电仓充电时需使用5V/1A的充电器，请勿使用电压高于5V的快速或其它充电器。
3. 请尽可能的远离WiFi及路由器等高频发射设备，以免影响蓝牙信号接收。
4. 请勿以任何理由拆除或改装耳机，勿让耳机接触腐蚀性液体，否则可能导致耳机故障及烧蚀，这些都不在保修范围。
5. 请勿在雷暴天气下使用此设备，雷暴可能导致设备工作不正常，并增加触电危险。
6. 请避免靠近儿童或动物的眼睛使用此设备灯光。
7. 请勿将设备置于温度过高或过低(0度以下及45度以上)的环境使用。

## 警告！

此产品含内置锂电池，请勿将此产品暴露在强烈的日照下，火烤或扔入火中，以免爆炸。  
如果电池更换不当会有爆炸危险，只能用同样类型或等效类型的电池来更换。




型号  
(MODEL)  
检验员  
(CHECKER)  
生产日期  
(CHECKER)

# M52 User's Manual




Please read the instructions carefully and keep them properly before using the product.

## Wearing method



Clip the earphones on the ear galleys as if wearing an ear clip. After wearing, adjust the position of the headset until it reaches the sound effect. The clearest position.

## Touch position and operation mode



The touch is located on the upper side of the left and right headphones.

You can perform basic operations through fingertip touch.

## Headset pairing

Take the two earphones out of the charging compartment respectively, and the two earphones will automatically turn on and pair. When pairing, the red and blue indicator lights of the left and right earphones will flash alternately. When the red and blue indicator lights of one earphone will flash alternately, and the red and blue indicator lights of the other earphone will turn off, it indicates that the earphones have been paired successfully. Both headphones do not flash when connected to the phone.

## Description of operating functions

1. Start up  
Method 1: Pick up the headset from the charging chamber and start the machine automatically  
Method 2: Press and hold the headset for 2 seconds to turn it on
  2. Shutdown  
Mode 1: Put it into the charging chamber and shut it down automatically  
Mode 2: Press and hold for 3 seconds to turn off the machine when the machine is turned on
  3. Music playing  
Previous: Double click left earphone. Next: Double click on the right earphone. Volume plus: Hit the right earphone three times, Volume reduction: Hit left earphones three times.  
Summon Siri and long press any headset for 2 seconds
  4. Telephone mode  
Answering call: Double click on any headset  
Reject calls: Click any headset
  5. Use of single ear connection: take out a headset separately from the charging compartment, the headset will automatically turn on and flash the red and blue lights, turn on the Bluetooth function of the phone, search for "M52" and click Connect.
  6. Switch between Chinese and English  
When Bluetooth is not connected, double-click to switch between Chinese and English. The default is English.
- ## About charging
- Earphone charging: The earphone is placed into the charging bay, the earphone charging light is steady red, and the L/R indicator light of the charging bay is blinking. Tip: When the battery capacity of the charging bin is lower than 5%, the digital display screen of the charging bin lights up and flashes. In order to keep the device working normally, please charge the charging bin as soon as possible. Earphone fully charged: After the earphone is fully charged, the earphone charging indicator light is red and the digital display screen of the charging bin is off.

Charging bin Charge the earphone: the earphone is placed into the charging bin, the number of the charging bin lights up, and the L/R indicator light flashes.  
Charging bin: Insert the Type-C charging cable into the Type-C charging port of the charging bin, the number at the end of the digital display screen of the charging bin flashes, and the fully charged display is 100.  
Volume display: iOS system synchronous display, Android system can increase or decrease the volume but the phone does not display.  
Headset power display: The upper right corner of the phone can display the headset real power.  
Earphone low battery warning: When the earphone battery voltage is below 3.3V, it will prompt you every 5 minutes until the earphone is turned off

## Product Description

- Product model: M52
- Bluetooth version: V5.3
- Support protocol: BR+EDR+BLE
- Working voltage: 3.1V-4.2V
- Charging voltage: 5V-1A
- Headset battery capacity: 30mAh
- Storage box battery capacity: 200mAh
- Transmission distance: 10m
- Talk time: 4 hours
- Playback time: 4 hours
- Charging duration of headset: 1-1.5 hours
- Charging time of storage box: 1-2 hours
- Support system: all Bluetooth functional devices and mobile phones
- Package list: charging chamber \* 1, earphone: L, R, data cable \* 1, instruction manual \* 1

## Common problem:

- Q: Can't charge the charging chamber?  
A: Please try to replace a data cable, or check whether the interface is connected properly.
- Q: Does the headset charge?  
A: Confirm that the charging chamber is powered, hold the headset for several times, and press the headset with your hand to make the charging contact fully contacted.
- Q: The headset signal is unstable or the headset has no sound?  
A: Please wear the headset in the correct way. No partition or obstacle is allowed during use. Please put the phone in the front pocket as much as possible.

possible when using outdoors.

- Q: Two "M52" pairing names appear when searching Bluetooth?  
A: You need to delete the two pairing names on the mobile phone device, take them out of the charging bin and reconnect them, and then connect the mobile phone.
- Q: Is the voice of answering the phone low or unclear?  
A: Please try to turn the volume of the headset or mobile phone to the maximum, and the mobile phone should not be too far away from the headset.
- Q: How to connect two earphones to two mobile phones?  
A: Take a headset out of the charging bin, automatically turn on the phone and the red and blue lights flash, then turn on the mobile phone Bluetooth search M52 connection (successful connection: no flashing). After the first headset is successfully connected to the first phone, turn on the second headset to connect to the second phone.
- Q: Earphones do not charge  
A: The earphone charging copper column or charging bin charging thimble is dirty, clean with alcohol or detergent

## matters needing attention:

1. Please use this product in an effective environment (10 meters unobstructed). If it exceeds the effective distance, it may be stuck and disconnected. Please use it correctly according to the instructions.
2. When charging the charging cabin, a 5V/1A charger should be used. Do not use a fast charger or other chargers with a voltage higher than 5V.
3. Please keep away from high-frequency transmitting devices such as WiFi and router as far as possible to avoid affecting the Bluetooth signal reception.
4. Do not remove or modify the headset for any reason and do not let the headset contact corrosive liquid, otherwise it may lead to headset failure and burning, which is not covered by the warranty.
5. Do not use this equipment in thunderstorm weather. Thunderstorms may cause abnormal operation of the equipment and increase the risk of electric shock.
6. Please avoid using this device near the eyes of children or animals.
7. Do not use the equipment in an environment where the temperature is too high or too low (below 0°C and above 45°C).

## Warning!

This product contains a built-in lithium battery. Please do not expose this product to strong sunlight, fire or throw it into the fire to avoid explosion. If the battery is not replaced properly, there will be an explosion hazard. Only the same type or equivalent type of battery can be used for replacement.



型号  
(MODEL)  
检验员  
(CHECKER)  
生产日期  
(CHECKER)

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

The device has been evaluated to meet general RF exposure requirements, the device can be used in portable exposure condition without restriction