# 单页尺寸: 55x91MM

# DISNED Bluetooth earphones



## User Manual

Please read the instruction manual before use

## B1

#### Summary

TWS wireless Bluetooth headset supports mobile phones, tablets and laptops Bluetooth devices such




#### How to match the device

- When using for the first time, open the cover of the charging compartment, open the Bluetooth matching search of the mobile phone, click the Bluetooth matching name searched on the mobile phone: 951, and select it to complete
- After there is matching record, the cover will be automatically connected (the Bluetooth of the mobile phone is on), and it is no need for manual matching search.
- Note: if the indicator light of the charging compartment is not on, please use the Type-C cable to charge the charging box, and the **orange** light flashes.

### B2

### **Function overview**



## Function

#### When the cover is opened, the headset will be power on automatically.


Put the headset back into the charging box and it will be power off automatically when the cover is closed.

#### Connection back

After opening the cover, it is automatically connected back to the design of the last connection.

### **B3**


 Callrejection: Long press the left/rightear for 2 seconds, or reject the call with the mobile phone



• Answer / end : click the left / right ear, or answer the call with your mobile phone




Pause / play: clickthe left / right ear to pause / play music




### **B4**


 Switch between previous and next track: previous track: double click the left ear touch area Next track: double click the right ear touch area



Volume up and down: Volume -: three clicks on the left ear touch area Volume +: three clicks on the right ear touch area



• Voice assistant: long press the left / right headphones for 2 seconds to start the voice function



### B5

#### Charge the headset

- Put the earphone back into the charging compartment and close the cover to charge automatically. The Green light in the charging compartment is long on.
- When the power of the headset is too low, the headset will have a prompt tone (Beep).

### Charge the charging box

• Please use Type-C charging wire to charge. When charging, the Orange light flashes. When the charging box is full, the green Orange long on

## Note: Please use the 5V/1A charger when charging the product.

#### Product parameters Model: 951

- Bluetooth version: V5.4
- Transmission range: 10M (straight and barrier free)
- Headsetcharging time: about 1 hours
- Charging time of charging box: about 1 hour
- Music playing time: 4-5 hours
- Headset battery capacity: 3.7V/28MA
- Battery capacity of charging box: 3.7V/180 MA

Please properly arrange the use time and adjust the volume. Using headphones for a long time may damage your hearing."

# B6

- 1. Before using the earphones, please read the manual carefully and keep it for future reference.
- 2. The earphones need to be fully charged prior to first-time  $3. If the \, ear phones is \, left unused for over two weeks, please$ recharge it periodically.
- 4.Please use the chargers made by qualified manufacturer.
- 5.If the mobile phone cannot find the Bluetooth headset, please checkwhether the headset is on Pairing status. If not connected for a long time, the headset will exit pairing mode.

### WARNING

- (1) Never disassemble or modify your earphones for any reasons to avoid any damages and danger.
- (2) Do not store the earphones in extreme temperatures (under O to 45)
- (3) Avoid using the indicator close to the eyes of children or animals. (4) Do not use this earphones during a thunder storm to
- avoid irregular function and increased risk of electricshock
- (5) Do not use harsh chemicals or strong detergents to clean the earphones6 Keep the earphones dry c (6) Keep the headset and charging box dry.

## B7

### **FCC Caution:**

- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause
- Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular
- If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for
- The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

# DISNEW 蓝牙耳机



#### 使用说明书 使用前请阅读使用说明书

## **A1**

TWS无线蓝牙耳机支持手机、平板电脑、笔记本 电脑等蓝牙设备



- 首次使用时打开充电仓盖子,打开手机蓝牙配对搜索,点击手机上 搜索到的蓝牙配对名:951,选择并完成配对。
- 已有配对记录后,开盖自动连接(手机蓝牙打开状态),无需手动

注意:如果充电仓指示灯没有亮,请用Type-C线给充电 盒充电, 橙灯闪烁。



## 功能



## 功能

开机 开盖, 耳机自动开机。

## 关机.

将耳机放回充电盒内,合盖自动关机。

开机自动与最后一次连接的设备回连。

## A3

●来电拒接:长按2秒左/右耳,或用手机拒接通话



●接听/挂断:单击左/右耳,或用手机接听电话



●暂停/播放:单击左/右耳暂停/播放音乐



## A4

●切换上下曲: 上一曲: 双击左耳触摸区域 F一曲: 双击右耳触摸区域



●音量加减:音量-:三击左耳触摸区域 音量+:三击右耳触摸区域



●语音助手:长按2秒左/右耳机启动语音功能



# 给耳机充电

- 把耳机放回充电仓,合盖自动充电。充电仓绿灯长亮。
- 耳机电量过低时,耳机会有提示音(嘟嘟)。

### 给充电盒充电

● 请使用Type-C充电线充电。充电时,橙灯闪烁。 充电盒充满时, 橙灯长亮。

注: 给本产品充电时, 请使用5V/1 A的充电器。 特别注意: 不要使用超过5V/1A的快充充电器, 以免对充电 盒照成损坏。

### 产品参数

- 펜号:951
- 蓝牙版本: V5.4 ● 传输范围: 10米 (直线无障碍)
- 耳机充电时间: 约1小时
- 充电仓充电时间:约1小时 ● 音乐播放时长: 4-5小时
- 耳机电池容量: 3.7V/28毫安
- 充电盒电池容量: 3.7V/180毫安

请妥善安排使用时间,和声音大小。长时间使用耳机 可能会损坏您的听力。

- 1.在使用耳机之前,请仔细阅读使用说明书并妥善保 管留作日后参老.
- 2.在第一次使用耳机之前,耳机必须要充满电。
- 3 如果耳机闲置超过30天。请定期充电。
- 4.请使用合格制造商生产的充电器。
- 5.如果手机无法搜索到蓝牙耳机,请检查耳机是否在 配对状态。如果长时间未连接,耳机将退出配对模式。

- (1)不得以任何理由拆卸或改装您的耳机,以免造成任 何损坏和危险.
- (2)不要将耳机存放在极端温度下(正常存储温度: -5到 45摄氏度之间)。
- (3)避免将指示灯靠近儿童或动物的眼睛。
- (4)避免在雷雨期间使用耳机,以避免耳机功能混乱和 增加触电风险。
- (5)请勿使用刺激性化学品或强力清洁剂来清洗耳机。 (6)保持耳机和充电盒干燥。

