版本	日期	更新内容
V01	2024/05/14	初版


产品手册 N160MU2系列


一、免责声明 • 本产品手册没有任何形式的担保、立场表达或其他暗示。若有任何因本产品手册 所提到的产品规格和资讯所引起直接或间接的信息流失或事业终止,本公司及所 属员工恕不为其承担任何责任。 • 请务必使用本产品所附的原装电源适配器,对于任何第三方电源适配器引起的问 题或故障, 本公司不承担任何责任。 • 用户可以使用第三方提供的音乐视频、图片和软件,但对于版权问题或软件故障 ,我们不承担任何责任。 • 如果产品出现故障,我们将严格遵守保修条款,但是在使用过程中可能造成财产 损失或经济损失,我们将不承担任何责任。 • 本产品随附出厂时内置的软件,可以在实际测试后使用。如果在寻找兼容性或其 他问题时删除或不删除,不会对本产品造成任何影响,且这也不属于产品质量问 • 产品手册所提到的产品规格和资讯仅供参考使用,包括产品硬件和软件内容。 • 本公司保留对产品进行改进的权利,产品规格和设计如有变更,其内容也会随时 更新, 恕不另行通知, 请以实物为准。 • 本公司保留对产品手册解释和修改的权利。



• 请将塑料包装袋放在婴儿与儿童接触不到的位置。

— 02 —










— 01 —




— 07 —

Please purchase and use memory and hard drives from reputable brands.

— 08 —

kitchens, basements, or pools.

· Avoid placing the device near water sources or in damp areas such as bathrooms,





● 摄像头

❸ 麦克风

● 显示器

❸ 指示灯

7 键盘

8 触控板

● 耳机接口

⑩ USB-A接口

② 摄像头指示灯

画面显示。

6 指纹电源键


进行拍照或视频交流。



Disclaimer
 This product manual makes no guarantee, express or implied, regarding the accuracy, completeness, or reliability of any information or statements provided herein. The company and its employees shall not be liable for any direct, indirect, incidental, special, or consequential damages arising out of the use or inability to use this manual or the products described herein.
 It is essential to use the original power adapter provided with this product. The company shall not be liable for any issues or malfunctions caused by third-party power adapters.
 Users may utilize third-party-provided music, videos, images, and software. However, we do not assume any responsibility for copyright issues or software malfunctions.
 In case of product malfunction, we will strictly adhere to the warranty terms. However, we shall not be liable for any property damage or economic loss incurred during use.
 The software pre-installed in the product at the time of manufacture is intended for use after actual testing. Removing or retaining this software during compatibilit testing or for any other reason will not affect the product, and it does not constitute


— 07 —

• Ensure the device is placed on a stable surface; dropping it may cause personal injury or damage to the device. · Store and use the equipment in a cool, dry, and well-ventilated area, away from radiation sources and heat sources. • Do not cover or block the ventilation holes on the casing. Do not place it on beds, sofas, blankets, or similar surfaces. The voltage range for operating the device is indicated on the rear shell label. If unsure about the supplied voltage, consult the dealer or local power company. · When the device is not in use for an extended period, disconnect the power to prevent damage from lightning strikes during thunderstorms and abnormal power voltages. Use a reliable grounded socket and avoid overloading it, as it may cause fires or electric shocks. • Do not insert foreign objects into the device, as it may cause fires or electric shocks. • Do not dismantle or repair the product yourself to avoid the risk of electric shock. If a product quality issue. there is a malfunction, contact the after-sales service personnel directly. • The product specifications and information provided in this manual are for Avoid excessive pulling or twisting of the power cord. reference only, including both hardware and software content. • If the adapter power cord is damaged, it must be replaced with a specialized • The company reserves the right to improve the product. Changes to product component purchased from its manufacturer or repair department. specifications and design may occur without prior notice, and the content will be To minimize interference with wireless radios and other electronic devices, use updated accordingly. Please refer to the actual product for details. peripherals that meet standards and shielded cables between system components. • The company reserves the right to interpret and modify the product manual. Product storage temperature: -15°C to 45°C. Only use batteries approved by the manufacturer. Replacing with the wrong battery model may compromise safety measures, leading to risks such as explosions or fires. Do not expose the battery to extremely high temperatures, such as sunlight, fire, microwave ovens, or ovens, as it may cause explosions or leakage of flammable liquids or gases. • Do not disassemble, crush, squeeze, or cut the battery, as it may cause explosions. · Do not expose the battery to extremely low pressure, as it may cause the battery to explode or leak flammable liquids or gases. — 01 — — 02 —




Camera Take photos or video exchanges.	USB-A port Connect external devices such as mobile phones and USB flash drives to transfer data.
Camera indicator light When the camera is turned on, the indicator light is solid white.	SD card slot Read and write SD card.
Microphone Use the microphone for video conferencing, voice calls, or recording.	DC charging port DC power adapter for charging.
Display The screen is displayed.	Charging indicator light The red light lights up when charging The green light turns on when fully charged
Indicator lights 	 USB-C port Connect the power adapter to charge the computer.
Fingerprint power key After entering your fingerprint, you can power on and unlock with on without entering a password, which is fast and safe.	₲ HDMI port
Keyboard Keyboard layout and content may vary by country and region, pleas to the actual situation. Touchpad Similar to the function of a mouse, it is more convenient to control the	transfer data. • Connect to a monitor, support projection, and monitor expansion. (Only some models are configured with this interface, please refer to the
computer. Headphone jack	Speakers Speaker sound hole.
Connect headphones.	Note: The functions and interfaces mentioned in the above content may have certain differences due to support of the actual model version. Please refer to the actual situation.

Size 360 x 243 x 18 mm Weight 1.79 kg (Some models have different configurations, please refer to the actual situation.) Rated input 19Vdc, 3.42A (Some models have different configurations, please refer to the actual situation.) Display 16 inch 16:10 in Electrical and Electronic Products" of China Mainland, the finames and contents of hazardous substances that may be considered to the actual situation.) Component Name (Pb) (Hg) (Cd) (Cr(VI)) Circuit Name Circuit Name Circuit Name Circuit Name Name Circuit Name Name Name Name Name Name Name Name	contained in this p
please refer to the actual situation.) Rated input 19Vdc, 3.42A (Some models have different configurations, please refer to the actual situation.) Display 16 inch 16:10 Component Name (Pb) (Hg) (Cd) (Cr(VI)) Circuit Name Circuit Name Circuit Name Name Circuit Name Name Circuit Name Name Name Circuit Name N	(PBB) (PBD
Rated input 19Vdc, 3.42A (Some models have different configurations, please refer to the actual situation.) Display 19Vdc, 3.42A (Some models have different configurations, please refer to the actual situation.) Circuit Roard Metal	, , ,
configurations, please refer to the actual situation.) Circuit Board X O X Display 16 inch 16:10	0 0
	0 0
Casing X O X	0 0
Keyboard Three-level backlit keyboard (the configuration of some models is different, please refer to the actual situation.) Metal Casing	0 0
Ni-Fi Built-in wireless card Fasteners O O X	0 0
Fingerprint power key One-click power-on to unlock and enter the system. Nebcam 720P Power Supply O O X	0 0
Audio Built-in multimedia speakers Mounting Hardware O O X	0 0
Operating temperature 5~45°C Cables X O O	0 0
Operating humidity In non-condensing state5%~85% Connectors X O X	0 0
Packing list Laptop × 1; Adapter × 1; Product Manual× 1.	0 0



The environmental protection use period refers to the period during which hazardous substances or elements contained in microcomputers (excluding batteries) and their accessory components will not leak under normal use conditions, and the use of the product by users of electronic information products will not cause serious pollution to the environment or cause serious damage to their personal or property.	China RoHS Conformity Assessment System Identification
Under the conditions described in the manual, this electronic information product contains toxic and hazardous substances or elements that will not leak and cause environmental pollution or serious harm to personal or property for a period of 10 years. This product is only suitable for use below 2000m.	GB 4943.1-2022 Warning Requirements For Class I equipment, use power plugs and grid connections with protective grounding. When installing in buildings, ensure that the distribution system can provide a circuit breaker with a rated voltage of 120/240V and a maximum of 20A.
This product is only suitable for use in non-tropical regions and is classified as Grade A. In living environments, this product may cause radio interference. In such cases, users may need to take feasible measures to address the interference.	Attention: Only applicable to products with batteries. Replacing with the wrong type of battery pack may result in loss of safety protection.
The Management Measures for the Restriction of Hazardous Substances in Electrical and Electronic Products require the following statement: This electronic product contains certain hazardous substances, which can be safely used during the environmental protection use period. After the environmental protection use period expires, it should be recycled through the recycling system.	Placing battery packs in fire or ovens, or mechanically squeezing or cutting them, may cause explosions. Placing battery packs in extremely high-temperature environments may cause them to explode or leak flammable liquids or gases. Battery packs subjected to extremely low air pressure may explode or leak flammable liquids and gases.
Indicative Notes on the "Regulations on the Management of Recycling and Disposal of Waste Electrical and Electronic Products"	There is a risk of fire or explosion if the wrong type of battery pack is used for replacement. Only applicable to products with button batteries. Do not swallow button batteries. This product (the remote control device provided with this product) contains button batteries. If a button battery is swallowed, it can cause severe internal
In order to better care for and protect the earth, when users do not need this product or the product life has expired, please abide by the relevant national laws and regulations on the recycling and disposal of waste electrical and electronic products, and hand them over to a manufacturer with nationally recognized qualifications at that time for recycling. Improper use or disposal can have an impact on the environment and human health.	
Chinese Environmental Labeling Product Advisory Instructions: a. The statement that the product achieves zero energy consumption only when not connected to any external power source. b. Ensure that replacement parts are provided within 3 years after the product is sold (only applicable to models certified by the Chinese environmental labeling).	burns within 2 hours and may lead to death. Keep new and used batteries away from children. If the battery compartment does not close securely, stop using the product and keep it away from children. If you think a battery may have been swallowed or lodged in any part of the body, seek medical attention immediately.
— 09 —	— 10 —



FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference..

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

Specific Absorption Rate (SAR) information:

This Notebook computer meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.

FCC RF Exposure Information and Statement

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: N16U2-AN (FCC ID: 2BGOP-N16U2-AN) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use at the when properly worn on the bodyis 0.697W/kg. This device was tested for typical body-worn operations with the back of the Notebook computer kept 0mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 0mm separation distance between the user's body and the back of the Notebook computer. The use ofbelt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposurerequirements, and should be avoided.