

**WARNING:**  
CHOKING HAZARD Small parts.  
Not for children under 3 years.



MICROFON MICROFONO MICROPHONE MICROFOON MICROFONE



GB

I. Buttons Operation

1. **O**: Long press: ON/OFF. Bluetooth will automatically turn on when the device is powered up.  
Short press: To disconnect Bluetooth, item can continue to be used as standalone microphone.
2. **~**: Press: For Previous song
3. **~**: Press: For Next song
4. **\*#\***: Short press: Play/pause  
Long press: Light function control ON/OFF and change volume.

5. **MIK/O MIC/Replay**

- Short press: Change Karaoke vocal mode ON/OFF
- Long press: To change voice fx - 5 options
6. **VOL +**: Volume level up
7. **VOL -**: Volume level Down
8. **MIC + and MIC -**: Microphone Volume Increase/Decrease
9. **REMIX**: Press to create echo/ remix to voice.

II. Multi-Function Operation

• Wireless Karaoke

1. Turn on the Microphone using the ON/OFF button, the device will automatically connect the Bluetooth device is ready to pair.
2. Open your Bluetooth settings on your phone/device and search for 'Barbie Microphone'. Click to connect. Once connected the microphone will automatically pair with the device successfully.
3. Select your music playing application on your Phone device to play music through your microphone and sing along to your favourite songs.

WARNING: Not suitable for Children under 36 months. Small Parts. Choking Hazard. Please retain this information for future reference. Colour and Contents may vary. Adult supervision required.

The toy contains small parts and batteries. The toy must be regularly examined for damage to the supply cord, plug, enclosure or other parts, and in the event of damage, it shall not be used until the damaged has been repaired.

Misuse of transformer can cause an electric shock.

This toy contains batteries that are non-replaceable.

WARNING: For the purposes of recharging the battery, only use the detachable supply unit provided with this toy.

This toy is only to be connected to equipment bearing either of the following symbols:



Help the Environment by disposing of batteries responsibly. The wheelie bin symbol indicates that the batteries must not be disposed of in the normal household/domestic waste as they contain substances which can be damaging to the environment and health.

AGES 6+

• Recording with mobile phone

1. Open the Karaoke software using the recording function on the mobile phone, record the song according to the instruction of the Karaoke software and then save favorite song and start singing.
2. Test and save the song. According to the instructions of Karaoke software.

Note: This microphone can support both Android mobile phone (Above Android 4.2) and iPhone iOS system/Above iOS 6.0.

• Additional Features

- For iPhone iOS system only - selfie function
1. Connect to Bluetooth on your phone
2. Turn Camera on your phone and change to selfie mode, press the volume up/down buttons to take a selfie.

GB

"This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation."

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna; Increase the separation between the equipment and receiver; Connect the equipment into an outlet on a circuit different from that to which the receiver is connected; Consult the dealer or an experienced radio/TV technician for help.

FR

Cet appareil est conforme à l'article 15 du Règlement de la FCC. Son utilisation est soumise aux deux conditions suivantes: (1) cet appareil ne doit causer aucun interférence nuisible, et (2) cet appareil doit accepter toute interférence reçue, y compris les interférences susceptibles de provoquer un fonctionnement indésirable.

**Remarque:** Cet appareil a été soumis à des tests et il a été jugé conforme aux seuils pour un appareil numérique de classe B, conformément à la Partie 15 des règles FCC. Ces seuils ont pour but de protéger les utilisateurs contre les interférences nuisibles dans une installation domestique. Cet appareil génère, utilise et peut émettre des interférences radio et peut provoquer des interférences nuisibles avec les communications radio si l'il n'est pas installé et utilisé conformément aux instructions. Il n'y a toutefois aucune garantie que les interférences ne se produisent pas dans une installation particulière. Si ces interférences perturbent la réception du signal de télévision ou radio, ce que vous pouvez faire pour corriger l'interférence est de débrancher l'appareil et de le rallumer, nous invitons l'utilisateur à corriger l'interférence en essayant l'une ou plusieurs des solutions suivantes :

Réorientez l'antenne de réception ou déplacez l'appareil.

Augmentez la distance de séparation entre l'appareil et le récepteur.

Si l'antenne de réception est reliée à un autre circuit que celui auquel le récepteur est raccordé.

Contactez le revendeur ou un réparateur TV/radio pour obtenir de l'aide.

ES

Este dispositivo cumple con el apartado 15 de las Normas de la FCC. Su funcionamiento es sujeto a las dos condiciones siguientes: (1) este dispositivo no debe causar interferencias perjudiciales y (2) este dispositivo debe aceptar las interferencias recibidas, incluidas aquellas que puedan causar un funcionamiento indeseado.

**Nota:** Este equipo ha sido probado y se encontró que cumple con los límites para un dispositivo digital de Clase B, de acuerdo con la Parte 15 de las Reglas de la FCC. Estos límites están diseñados para proteger a los usuarios contra las interferencias perjudiciales en una instalación residencial. Este equipo genera, utiliza y puede emitir energía de radiofrecuencia y si no es instalado y utilizado de acuerdo con las instrucciones, puede causar interferencia nociva a las comunicaciones. Sin embargo, no hay garantía de que no ocurra interferencia en una instalación particular. Si esta interferencia perturba la recepción del señal de televisión o radio, lo que puede determinarse encendiendo y apagando el equipo, se invita al usuario a intentar corregir la interferencia usando una o más de las siguientes medidas:

-Ajustar la antena receptora.

-Aumentar la separación entre el equipo y el receptor.

-Conectar el equipo a un tomacorriente en un circuito distinto a aquel en donde está conectado el receptor.

-Consultar al vendedor o a un técnico experto en radio/TV.



© MGA Entertainment, Inc.  
LOL SURPRISE! is a trademark of MGA in the U.S. and other countries. All logos, names, characters, likenesses, images, slogans, and packaging appearance are the property of MGA. Used under license by Sinco Toys Ltd.

Manufactured and Distributed by: Sinco Toys Ltd., 31 Bury Old Road, Prestwich, Manchester, M25 1JA, United Kingdom, info@sinicotours.com  
Singleton Trading B.V., Goeman Borgesiuslaan 77 3515 Et Utrecht Netherlands

FC Sinco Toys Ltd.  
LOL664057  
Made in Dongguan, China.

