

**FCC Caution:**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.


If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.




**1. Product structure**



Product Name	Wireless headphones
Version	5.4
Power consumption	300mA
Transmission radius	10m
Music time	About 4 hours
Charging interface	USB Type-C
Charging time	About 1.5h

**2. Pairing**




- Open the box, the headphones will automatically turn on and pair left and right.
- Open the that you want to connect to the device, select "XXXXXX" from the list, and pairing is successful.

**Attention:**


- There is a button at the bottom of the box, which can be clicked to light up the screen; Long press for 10 seconds to restart the box.
- Double clicking the screen within 0.5 seconds can also light up the screen.


**3. Usage**



- Use one hand to hold the ear and hang it on it like wearing an earring.
- First, hang it above the ear and move it up and down to adjust to the best listening sound position of the sound.

**4. Up to 12 functions**






**Notes:**

Please follow the following precautions to avoid injury and property damage. Long term use of high volume can stimulate the ears and may lead to cognitive effects such as reduced hearing. To better protect both ears and hearing, please pay attention to preventing situations where the volume is too high. According to the different Bluetooth devices connected to this device, there may be a phenomenon of speaking during calls. Please keep an appropriate volume at all times. Please gradually increase the volume as sudden increases may damage the ears. If you experience skin allergies or other symptoms while using this device, please stop using it as soon as possible and consult a doctor, or contact a repair center or the seller at the time of purchase for further consultation.

- Please do not place the earphone body in the back pocket to avoid compression, deformation, or other malfunctions when sitting down.
- Please do not use this device near medical devices, as radio waves and other influences may cause malfunctions in pacemakers or other medical electronic devices.
- Please do not use this device in crowded vehicles or other miscellaneous places, or in the interior of medical institutions.
- Please do not use this device in a timely manner Post service center or specialized store at the time of purchase. Please do not expose this device to high temperatures or heating equipment, such as near flames, direct sunlight, or high temperatures.

The use of radio waves and other factors may cause accidental operations and accidents.

**5. Position and operation method of operation buttons**



The touch panels are located on the front sides of each side. By touching the control panel, it is possible to Basic operations.  
Note that it is not a button-operation and requires gentle touch of the control panel.

**6. Operation List**

pair	When the headphones are turned on, they will pair left and right on their own.
Power ON/OFF	After the pairing is completed, W11 can be found on the Bluetooth interface of the Android/iOS phone. The earphones automatically turn on when the charging compartment is opened, and the earphones automatically turn off when the charging compartment is closed (Power ON/Power OFF).
Music: Play/Stop Call answering/hanging up	Click on a left and right touch panel
Previous song	Double click on the left ear touch panel
Next piece of music	Three strikes on the left ear increase the sound.
Volume increase	Strike the right ear three times to reduce the sound.
Volume reduction	Slide down either side of the headphone touch panel
Summoning Voice Assistant	Long press the left and right touch panel 2S to trigger Siri
Noise reduction mode switching standby mode	Four Click Any Earphone Touch Panel Enter mode: press the button of the earphone three times to move and press for 10 seconds. The LED light flashes the standby mode. Release mode: press the button of the earphone 5 times to start the standby mode.

**Warning:**

Please pay attention to the following precautions to avoid death or serious injury caused by fire, electric shock, heat, fire, etc. Do not directly touch the charging battery with your hands to prevent liquid leakage. If the leaked liquid accidentally enters the eyes, to avoid the possibility of blindness, please do not rub your eyes. Immediately rinse thoroughly with clean water and seek medical treatment promptly. If the leaked liquid accidentally touches the body or clothing, to avoid possible burns or other injuries, please use immediately wash with water or other ingredients. If there is inflammation or other damage to the skin, please seek medical treatment promptly. Please use the attached (USB) type-C accessory for charging. Damage, battery leakage, overheating, and other situations may cause fire and other injuries, resulting in surrounding pollution and damage injury. Do not disassemble this machine on your own to avoid malfunctions or electric shock. If you need to replace the rechargeable battery, inspect or repair it, please contact the seller in a timely manner Post service center or specialized store at the time of purchase. Please do not expose this device to high temperatures or heating equipment, such as near flames, direct sunlight, or high temperatures. Use, store, and place in high-temperature areas such as the interior of the car.