

# Bluetooth audio INSTRUCTIONS

Thank you for choosing our products and I hope you enjoy your musical journey

## SAFETY INSTRUCTION

PLEASE READ THIS MANUAL CAREFULLY BEFORE USE AND KEEP IT FOR FUTURE REFERENCE

1. Keep away from heat, sun exposure and sharp objects.
2. Stay away from the open fire.
3. Don't insert any metal objects. Avoid short circuit.
4. Don't repair the product by yourself, but contact the authorized repairer.
5. Avoid products from getting caught in the rain, Spray.
6. If the product is overheated. Damaged or fell into liquid. Please stop using.
7. Use products according to standards and regulations.

## PACKAGING ACCESSORIES

01. Bluetooth audio\*1
02. TYPE-C charging cable\*1
03. Product description\*1

## INTERNAL BATTERY

01. Built-in rechargeable battery takes 2-3 hours to complete the charging and discharge cycle.
02. Don't continue charging a fully charged battery. Overcharging will shorten the battery life.
03. If the full load is placed, it may be a little lost.
04. Placing the product in a place that is overheated or too cold will shorten the product life.

## CHARGING FUNCTION

01. Plug in TYPE-C charging cable, charge the other end, plug in DC 5V=1A charger.
02. The product's LED charging indicator light is always on in red, that is, the sound is charging normally.
03. When the product is fully charged, the LED red light is off.

## PAIRING CONNECTION

01. Open a Bluetooth stereo, connect to Bluetooth, long press "down" key, hear "ding" After that, open another Bluetooth stereo, and long press "down" to hear the "ding" sound Bluetooth audio connection successfully, long press any "down" key again. Disconnect the couplet.



## OPERATION FUNCTION

- ① Power on / sound plus / subtract
  - ② The last song
  - ③ The next song
  - ④ TYPE-C charging port
  - ⑤ The USB superior disk port
  - ⑥ LED charge lamp
  - ⑦ TF card port
  - ⑧ The AUX audio access port
01. Turn on the shutdown button clockwise to the right, prompt "Bluetooth mode" to enter Bluetooth mode;
  02. ② Short press on the last song, long press to pause / play
  03. ③ Short press the next song, long press the switch couplet mode
  04. ④ The speaker can be charged through the TYPE-C charging cable
  05. ⑤ Judge whether the charging state is normal, the red light is charging, and the full light is off
  06. ⑥ When boot, audio from the TF card plays automatically when the TF card is inserted
  07. ⑦ In the boot state, the audio in the optimal disk is automatically played when the USB optimal disk is inserted
  08. ⑧ When turned on, insert the audio line automatically into AUX mode

## TROUBLESHOOTING

Failure phenomenon	Possible reasons	Solution
Unable to search Bluetooth	The battery is not powered off	Charge the audio
Unable to pair Bluetooth	The audio has been paired with another device and has not entered pairing mode	Turn off other paired devices Search again and pair

## TECHNICAL SPECIFICATIONS

Bluetooth version	BT5.0
Pair Name	BT_SPEAKER
Bluetooth receiving distance	Straight line obstacle free 10m
Speaker	5205w
Battery	3.7V/500MAH
Charging voltage	DC 5V-1A
Charging duration	3H
Working hours	Maximum volume ≥ 3H, minimum volume ≥ 6H (Note: The time will vary depending on the type of mobile phone and the actual situation.)

## FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC IDENTIFIER: 2BGN-MMJJS12