


# 产品规格 ⊢40mm-



中号心形肛塞







- 1:长按2秒开机,开机后进入自检模式(所有灯光闪烁一些,马达短 暂震动一次)。同时开启三色灯闪烁。进入待机模式。
- 2: 短按开关按键, 切换震动模式。共9个频段。
- 3:长按2秒关机。所有灯光熄灭。
- ☆ 三色爆闪灯---开机后自动无规律闪烁
- 当工作指示灯—-白色工作指示灯、随工作模式闪烁

## ■ 充电操作说明:



- 1: 将充电线磁吸接头与产品底部的磁 吸接口对应,充电线的另一头与常用 的电源接头链接。
- 2: 充电过程中,产品底部会出现呼吸 灯闪烁状态,充满以后,呼吸灯会出 现常亮状态。

### 遥控器的使用操作说明:

— 频率切换键

1: 使用遥控器之前, 先打开遥控器的后 盖, 取出电池下面的绝缘胶片, 然后安装 好电池,盖 好遥控器后盖。

2: 开启产品上的电源开关以后,即可开 始正常使用遥控器。

3: 电源键功能:

①长按3秒,产品进入关机状态。 ②点按一下,产品开启震动功能,再次点 按一下,产品震动功能暂停。

4:发光键功能:

①点按一下,产品开启灯光闪烁功能,再 次点按一下,产品震动灯光闪烁功能。 5: 频率切换键功能:

①每点按一下,产品开启震动频率切换, 产品共9种震动频率。

## APP操作说明

#### ①下载APP

1. 在APP STORE里搜索"暮瑟"下载 安装和更新

2. 用手机扫描右侧的二维码。根据 提示安装"暮瑟"APP



#### Android系统

1. 可以在各大安卓应用市场(如应用宝等)搜索"暮瑟"下载安装和更新 2. 用手机扫描右侧的二维码, 根据提示安装"暮瑟"APP

### 注册及登陆

②长按开关按钮2秒启动设备。

③点击"暮瑟"app图标进入,首次登录需要先用手机号码注册暮瑟账号。



④新用户注册完成,以后再次登录可使用"一键登录"更便捷。 ⑤V.3.6版本之前注册的用户点击"老用户登录"输入邮箱和密码登录, 同时绑定手机号。





①包装盒或者说明书上印有设备二维码,进入app首页,点击"+"进行扫 码绑定。(以下多个步骤需要手机访问权限,根据提示开启或稍后在手机设 置里手动打开。例如:此处需要暮瑟需要访问您的相机、相册-允许访问。



设备绑定

①手动输入设备编号(心型底座: 7250)进行绑定。 ②扫二维码进行绑定;





扫二维码可绑定

## 设备绑定

①绑定成功后, "+" 旁边的位置会显示设备图标支持绑定多个设备, 同个设备也可绑定至多个手机,长按图标可删除设备。



## ■ 经典模式

①经典模式有模式1和模式2

②模式1:震动功能,共有9种震动频率,模式1内的9宫格内任意图标进行 震动功能的选择,同一个图标,点击一下开启震动功能,再次点击关闭震

模式2: 灯光控制功能功能,模式2内的9宫格内任意图标可以控制发光功 能的开启以及关闭,点击一下开启发光功能,再次点击关闭发光功能。



# 互动模式

①互动模式即远程控制,控制方与设备方没有距离限制,设备方与设备不超 讨10米距离。

注意:控制方也需要开启蓝牙、定位权限,并且打开手机蓝牙。 (1)每个用户都有一个激请码/ID。在"互动模式"页面输入对方的激请码搜 索添加好友。成为好友后选择语音或视频形式发起诵话。对方同意后诵话页 面会显示控制面板,可进行远程控制。下次进入互动模式,你可以直接在" 连接记录"发起诵话。

(2) 在丁县首页点击左上角讲入"我的"页面在"我的消息"查看消息和好友列表。





② 目前互动支持经典、划一划、摇一摇三种模式。 ③ 在工具首页点击左上角进入"我的"页面在"我的消息"查看消 息和好友列表。







■ APP还有游戏模式--视频模式--音乐模式--声控模式--凯格尔模式 您可以尽情探索!

















View 3

## FCC Warnning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection againstharmful interference in a residential installation. This equipment generates, uses and can radiateradio frequency energy and, if not installed and used in accordance with the instructions, maycause harmful interference to radio communications. However, there is no guarantee thatinterference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipmentoff and on, the user is encouraged to try to correct the interference by one or more of thefollowing measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.