


70X70mm

DM06



真无线蓝牙耳机

* 特别声明:本产品禁止使用快充充电头,使用不当引起的产品损坏制造商概不负责。

产品规格:

真正无线连接 (TWS) 实现无线立体声, 左右声道分离, HiFi 音效。左右耳均具有完整蓝牙功能, 可单独使用, 也可以成对使用。

产品型号	DM06
产品类型	无线蓝牙耳机
声道系统	无线立体声
控制方式	触摸
蓝牙有效距离	≥10米
耳机功放类型	内置芯片
频率响应	15~20000Hz
蓝牙版本	V5.4
喇叭规格	13MM (32R)
耳机电池容量	30mAh
仓电池容量	230mAh

功能说明:

1. 开机: ①取出耳机自动开机, 5S后会提示“du”
2. 关机: ①把耳机放入充电仓关机充电②未连接手机时, 5分钟后自动关机, 会提示“dududu”
3. TWS配对成功: 当左右耳机开机后, 左右耳机立即进行互配配对成功后, 进入配对模式, 会提示“du”
4. 蓝牙已连接: ①耳机进入配对状态, 手机搜索到蓝牙配对名, 点击连接即可②已连接过蓝牙设备, 开机后左右耳机自动回连, 主机自动回连到最后一台连接过的设备, 回连不成功耳机进入配对状态, 会提示“du”
5. 蓝牙已断开: ①手动关闭手机蓝牙端, 耳机进入配对模式②耳机与手机超距后断开, 3分钟内回到有效距离范围, 能正常回连手机, 超过5分钟会自动关机, 会提示“dudu”
6. 暂停/播放: 单击任意耳机MFB键
7. 上/下曲: 双击任意耳机MFB键
8. 加/减音量: 三击任意耳机MFB键, 最大音量会提示“dududong”
9. 语音助手: 长按2S任意耳机MFB键, 会提示“dong”
10. 游戏模式: 4击任意耳机MFB键, 会有“Game Mode/MusicMode”

11. 来电: 对方打电话来, 会有来电播报
12. 接听/挂断: 单击任意耳机
13. 拒接: 长按任意耳机MFB键
14. 电池电量低: 20%电量时, 30秒提示一次, 会提示“dudu”

耳机充电中: 耳机红灯长亮, 充电仓绿灯长亮
耳机充满电: 耳机红灯灭, 充电仓绿灯灭
充电仓充电中: 红灯慢闪
充电仓充满电: 红灯长亮

警告事项及注意事项

1. 切勿使用具有腐蚀性的清洁剂清洁本产品。
2. 切勿让本产品加热或靠近火源。
3. 切勿让本产品长时间受阳光直接照射。
4. 切勿将本产品弃置于火中, 避免发生爆炸。
5. 切勿尝试拆出本产品做任何修改。
6. 如长时间不使用本产品, 请将它储存于干燥的环境中, 并每月至少为耳机充电一次以延长寿命, 避免极端的温度和灰尘。

DM06



Special announcement: this product is forbidden to use the quick charging head, The manufacturer shall not be liable for product damage caused by improper use.

Product specifications:

True wireless connectivity (TWS) enables wireless stereo, left-right channel separation, and HiFi sound. Both the left and right ears have full Bluetooth function, which can be used alone or in pairs.

Model	DM06
Product type	Wireless Bluetooth headset
Vocal tract system	Wireless Stereo
Control mode	Touch
Bluetooth effective distance	≥10M
Headset amplifier type	Built-in chip
Frequency response	15~20000Hz
Bluetooth version	V5.4
Horn specifications	13MM(32R)
Headphone battery capacity	30mAh
Storage battery capacity	230mAh

Function description:

1. Power on: After removing the earphones, it will automatically turn on, and after 5 seconds, it will prompt “du”
2. Shutdown: ①Put the earphones into the charging compartment and shut down for charging.②When the phone is not connected, it will automatically shut down after 5 minutes and the message “Poweroff” will appear.
3. TWS matching success: when the left and right headphones boot, the left and right headphones immediately for matching, matching success, into the matching mode, Will prompt “du”
4. Bluetooth has been connected: 1 earphone into the matching state, the phone search to Bluetooth matching name, click on the connection can be connected to 2 Bluetooth devices have been connected, after the start of the headphone automatically back to connect, the host automatically reconnects to the last connected device. If the reconnection is unsuccessful, the headset will enter a matching state, which will prompt “du”
5. Bluetooth disconnected: 1 manually turn off the Bluetooth end of the phone, headset into pairing mode 2. The headset will disconnect from the phone after a long distance, return to the range within 3 minutes, can return to the phone normally, more than 5 minutes will automatically shut down, will prompt “dudu”
6. Pause/play: click the MFB key on the right headset
7. Next track: Double-click the right ear MFB key
8. Increase/decrease volume: Three clicks on any headphone MFB button, the maximum volume will prompt “du du dong”
9. Voice Assistant: Long press any earphone MFB button for 2 seconds, and it will prompt “dong”

10. Game mode: 4 clicks on any headphone MFB button will display “Game Mode/MusicMode”
11. Incoming call: When the other party calls, there will be a call announcement
12. Answer/hang up: Click on the right headset
13. Reject: press the MFB key on the right earphone
14. Low battery life: at 20% battery life, a 30s reminder will indicate “dudu”

Headphone charging: The red light of the earphones remains on, and the green light of the charging compartment remains on
Earphones fully charged: The red light on the earphones is off, and the green light on the charging compartment is off
Charging in the charging compartment: red light flashing slowly
The charging compartment is fully charged: the red light remains on for a long time

Warnings and precautions

1. Do not use corrosive detergents to clean this product.
2. Do not use corrosive detergents to clean this product.
3. Do not expose this product to direct sunlight for long periods of time.
4. Do not dispose of this product in fire to avoid explosion.
5. Do not attempt to remove this product for any modification.
6. If you don't use this product for a long time, store it in a dry environment and charge the headphones at least once a month to prolong life and avoid extreme temperatures and dust.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.