




Bobcat B

Vision Enhancement Imager

Quickstart Guide

Thank you for purchasing this product.



Please read this Guide first and keep it properly for future reference. We hope this product will meet your expectations.


Important

This Guide is a general guide for a series of products, which means that the product you receive may differ from the description in the Guide. The actual product you receive shall prevail.

This Guide is prepared to introduce our products to the users. We will try our best to ensure the accuracy of the Guide, but the completeness of the Guide still cannot be guaranteed, because our products have been continuously upgraded. We reserve the right to modify at any time without prior notice.

Illustrations





P2



iOS



Android

P3

1. Appearance (P1~P2)

No.	Description	Function
1	Power Switch	Short press: shutter compensation/wake-up/exit menu Long press: power on/off
2	MENU	Short press: bring up the shortcut menu/confirm to save the settings Long press: bring up the main menu/exit the current menu without saving
3	UP	Short press: photography/menu option switching Long press: video recording/menu option switching
4	DOWN	Short press: quick pseudo color switching/ menu option switching Long press: exit shortcut pseudo color menu/ menu option switching
5	Lens cap	Lens protection
6	Battery compartment	Space to accommodate battery
7	Left focusing knob	Turn toward the eyepiece lens for close focus regulation  Turn toward the objective lens for far focus regulation 
8	Right focusing knob	Turn toward the eyepiece lens for far focus regulation  Turn toward the objective lens for close focus regulation 

No.	Description	Function
9	MIC	Sound recording port
10	Type-C port	Connection with PC and external screen via type-C cable
11	Regulating ring	Rotating the fixable optical sight
12	Adapter ring	Connection with the devices and the optical sight

2. Battery Installation (P2)

1. Push the battery compartment cover buckle to open the battery compartment cover;
2. Insert 2 batteries according to the "+" and "-" indications;
3. Close the battery compartment cover;

3. Data transmission (P2)

1. Turn on the device to a power-on state;
2. Connect the device to the PC via USB-Type C cable;
3. Access the data stored in the device from the PC side;

4. Mobile APP connection (P3)

1. Turn on the device to a power-on state;
2. Open the WiFi Hotspot in the device;

3. Search the device's WiFi hotspot name with the mobile phone and connect the WiFi hotspot;
4. Open the TargetIR APP on the mobile phone to see the real-time screen of the device, allowing device control and access;

5. Detailed operation

Scan the QR code for more instructions.



1. Apariencia (P1~P2)

N.º	Componente	Función
1	Botón de encendido	Pulsar: calibración de obturador / activar / salir del menú Mantener pulsado: conectar / desconectar la fuente de alimentación
2	Botón de menú	Pulsar: abrir el menú de acceso directo / confirmar y guardar la configuración Mantener pulsado: abrir el menú principal / salir del menú actual sin guardar
3	Arriba	Pulsar: tomar fotos / cambiar opciones del menú Mantener pulsado: grabar vídeos/ cambiar opciones del menú
4	Aabajo	Pulsar: cambio rápido del pseudocolor / cambiar opciones del menú Mantener pulsado: salir del menú de pseudocolor de acceso directo / cambiar opciones del menú
5	Tapa de lente	Protección de la lente
6	Compartimiento de la batería	La batería se instala aquí
7	Perilla de enfoque izquierda	Gírela hacia el ocular para acercar el zoom  Gírela hacia el objetivo para alejar el zoom 
8	Perilla de enfoque derecha	Gírela hacia el ocular para alejar el zoom  Gírela hacia el objetivo para acercar el zoom 

N.º	Componente	Función
9	MIC	Conector de micrófono
10	Interfaz Type - C	Conectar la PC a la pantalla externa utilizando un cable type-C
11	Anillo de ajuste	Gírelo para fijar el visor óptico
12	Anillo adaptador	Conectar el dispositivo al visor óptico

2. Instalación de la batería (P2)

1. Empuje la hebilla de la tapa del compartimiento de la batería y abra la tapa;
2. Instale las dos (2) baterías teniendo en cuenta las marcas de los terminales positivo y negativo;
3. Cierre la tapa del compartimiento de la batería;

3. Transmisión de datos (P2)

1. Encienda el dispositivo;
2. Conecte el dispositivo a la PC utilizando un cable USB-TypeC;
3. Acceda a los datos almacenados en el dispositivo en el lado de la PC;

4. Conexión de la aplicación del teléfono móvil (P3)

1. Encienda el dispositivo;
2. Active el punto de acceso WiFi en el dispositivo;
3. Busque el nombre del punto de acceso WiFi del dispositivo usando el teléfono móvil y conéctelo;
4. Inicie la aplicación TargetIR en su teléfono para obtener imágenes del dispositivo en tiempo real, controlarlo y acceder al mismo;

5. Operación detallada

Escanee el código QR para conocer más métodos de uso.



- FCC WARNING -

This equipment may generate or use radio frequency energy. Changes or modifications to this equipment may cause harmful interference unless the modifications are expressly approved in the instruction manual. The user could lose the authority to operate this equipment if an unauthorized change or modification is made.

This unit complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This unit may not cause harmful interference, and (2) this unit must accept any interference received, including interference that may cause undesired operation.

The unit has been evaluated to meet general RF exposure requirement. The unit can be used in portable exposure condition without restriction.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital unit, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful

interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- The rating information is located at the bottom of the unit.



Providence Enterprise (Vietnam) Company Limited

Special statement: the version of the guide will be updated after the technical improvement of the product.