

(Fold Inward) - - - - ▶

(Back Cover)

(Front Cover)

### Compliance Information

**FCC Information**  
This device complies with Part 15 of the FCC Rules.

**Caution:** Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**Radiation Exposure Information**  
The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.

**WARNING Li-Ion Battery Inside**  
This product is fitted with a Li-ion battery. Do not damage, open, or dismantle the battery and do not use it in damp and/or corrosive conditions. Use only with compatible chargers. Never dispose of batteries in a fire, and never expose them to high temperatures. Do not expose the product to temperatures exceeding 60°C (140°F).

**Rating Label Definitions**

- ☰ Direct current symbol.
- ⚡ This symbol signifies the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health.
- ♻️ This symbol signifies and declares that this equipment has battery charging which complies with California CEC and energy efficiency.
- Bluetooth This symbol signifies that this is a wireless device powered by Bluetooth technology.
- FCC This symbol represents FCC Declaration of Conformity and compliance.



### Warranty Information

**1-Year Limited Warranty**  
Territory: United States/Canada

**LIMITED WARRANTY TO ORIGINAL CONSUMER**  
This product as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc. to the original consumer purchaser against defects in materials and workmanship ("Warranty") as follows:

**To obtain warranty service:**

- Visit our customer support portal: [www.customersupport123.com](http://www.customersupport123.com) and select "Support"
- Select the brand, fill out the corresponding form (exchanges require dated proof of purchase from an authorized retailer) then submit your request.

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.

**Warranty service not provided**  
This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorized modification including software modifications such as the installation of custom firmware. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

**NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR/FURTHER RECLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR, REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR OR ITS MANUFACTURERS BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT, EXCEPT AS STATED HEREIN. NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.**

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.

**All product names, trademarks, and registered trademarks are property of their respective owners. All company, product, and service names used in this document are for identification purposes only. Use of these names, trademarks, and brands does not imply endorsement.**

Designed in US  
Printed in China  
v1.05/2024



**HELLO KITTY**  
by Sanrio®

© 2024 SANRIO CO., LTD.  
Used Under License.  
[www.sanrio.com](http://www.sanrio.com)



SIL-35047  
Southern Telecom Inc.  
5601 1st Ave.  
Brooklyn, NY 11220



**HELLO KITTY**  
Bluetooth  
**WIRELESS HEADPHONES**

Instruction Manual  
HKBTHP01

### Before You Begin...

**READ CAREFULLY AND KEEP THIS MANUAL**

**⚠️ Caution**  
To ensure safe and proper use, read all safety information before using the device. Only use with manufacturer-approved batteries, chargers, accessories, and supplies.

- **THIS DEVICE IS NOT A TOY**, keep away from children and pets.
- Do not disassemble, modify, or repair the device.
- Do not expose to extreme temperatures (heat or cold), open flames, humid, or wet conditions.
- Do not submerge in water.
- Low power may cause poor Bluetooth connection or sound distortion.
- Do not overcharge battery.
- If using with a USB adapter, make sure the adapter is not damaged.
- Do not allow the USB port or the connectors of the supplied USB cable to be exposed to dust or water, or to come into contact with any conductive materials such as liquids, metallic powders, etc.
- The headphones contain a built-in battery and should not be disposed of with regular household waste. Please consult the local authorities on the correct way to dispose of this device.

**In the Box**

- Wireless Headphones (x1)
- USB Charging Cable (x1)
- User Manual (x1)

### Operation Guide

1. **Turning Headphones On/Off:** Long press the POWER / M Key for two seconds
2. **Mode Switch:** Short press the POWER / M Key
3. **Previous Song / Volume Down:** Short press / Long press the PREV / V- key
4. **Next Song / Volume Up:** Short press/Long press the NEXT / V+ Key
5. **Play/Pause:** Short press the PP/Phone key
6. **Callback:** Double click the PP/Phone key
7. **Answer a Call:** Single click the PP/Phone Key  
Hang up: press the PP/Phone key  
Decline a call: Long press the PP/Phone key
9. **FM Auto Search:** Single click the PP/Phone Key

### Getting Started

**LED Indicator**

- When the headphones are on, the BLUE Light will be on.
- When the headphones are off, the RED Light will be off.
- When Bluetooth is NOT connected, the RED and BLUE lights will flash alternately.
- When Bluetooth is connected, the BLUE light will be always on.
- During Bluetooth Playback, the BLUE light will flash every four seconds.
- When the TF-Card is paused, the RED light will be on.
- While the TF-Card is playing, the RED light will slowly flash.
- When FM is auto-searching, the RED light will quickly flash.
- When FM is playing, the RED light will be always on.

While your headphones are charging, the RED light will stay on. When the charge is full, the BLUE light will turn on, and stay on.

### Bluetooth Pairing

1. Power the headphone ON. The Led indicator will turn BLUE.
2. Set your mobile device to search for Bluetooth devices. When it appears, select "HKBTHP01" from the list of found devices.
3. After a successful pairing, the LED indicator will flash BLUE every four seconds. You should be able to play music on the headphone.

(Fold Inward) - - - - ▶

(Back Cover)

(Front Cover)

### Compliance Information

**FCC Information**  
This device complies with Part 15 of the FCC Rules.

**Caution:** Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**Radiation Exposure Information**  
The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure condition without restriction.

**WARNING Li-Ion Battery Inside**  
This product is fitted with a Li-ion battery. Do not damage, open, or dismantle the battery and do not use it in damp and/or corrosive conditions. Use only with compatible chargers. Never dispose of batteries in a fire, and never expose them to high temperatures. Do not expose the product to temperatures exceeding 30°C (86°F).

**Rating Label Definitions**

- ☰ Direct current symbol.
- ⚡ This symbol signifies the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health.
- ♻️ This symbol signifies and declares that this equipment has battery charging which complies with California CEC and energy efficiency.
- Bluetooth This symbol signifies that this is a wireless device powered by Bluetooth technology.
- FC This symbol represents FCC Declaration of Conformity and compliance.



### Warranty Information

**1-Year Limited Warranty**  
Territory: United States/Canada

**LIMITED WARRANTY TO ORIGINAL CONSUMER**  
This product as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc. to the original consumer purchaser against defects in materials and workmanship ("Warranty") as follows:

**To obtain warranty service:**

- Visit our customer support portal: [www.customersupport123.com](http://www.customersupport123.com) and select "Support"
- Select the brand, fill out the corresponding form (exchanges require dated proof of purchase from an authorized retailer) then submit your request.

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.

**Warranty service not provided**  
This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorized modification including software modifications such as the installation of custom firmware. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR/FURTHER RECLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTEE GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR, REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE + AT DISTRIBUTOR'S SOLE DISCRETION + ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR OR ITS MANUFACTURERS BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT, EXCEPT AS STATED HEREIN. NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.

**All product names, trademarks, and registered trademarks are property of their respective owners. All company, product, and service names used in this document are for identification purposes only. Use of these names, trademarks, and brands does not imply endorsement.**

Designed in US  
Printed in China  
v1. 05/2024



**HELLO KITTY® AND FRIENDS**  
by Sanrio®

© 2024 SANRIO CO., LTD.  
Used Under License.  
[www.sanrio.com](http://www.sanrio.com)

**HELLO KITTY® AND FRIENDS**

Bluetooth®

**WIRELESS HEADPHONES**



Instruction Manual  
HKBTHP01

### Before You Begin...

**READ CAREFULLY AND KEEP THIS MANUAL**

**⚠️ Caution**  
To ensure safe and proper use, read all safety information before using the device. Only use with manufacturer-approved batteries, chargers, accessories, and supplies.

- **THIS DEVICE IS NOT A TOY**, keep away from children and pets.
- Do not disassemble, modify, or repair the device.
- Do not expose to extreme temperatures (heat or cold), open flames, humid, or wet conditions.
- Do not submerge in water.
- Low power may cause poor Bluetooth connection or sound distortion.
- Do not overcharge battery.
- If using with a USB adapter, make sure the adapter is not damaged.
- Do not allow the USB port or the connectors of the supplied USB cable to be exposed to dust or water, or to come into contact with any conductive materials such as liquids, metallic powders, etc.
- The headphones contain a built-in battery and should not be disposed of with regular household waste. Please consult the local authorities on the correct way to dispose of this device.

**In the Box**

- Wireless Headphones (x1)
- USB Charging Cable (x1)
- User Manual (x1)

### Operation Guide

1. **Turning Headphones On/Off:** Long press the POWER / M Key for two seconds
2. **Mode Switch:** Short press the POWER / M Key
3. **Previous Song / Volume Down:** Short press / Long press the PREV / V- key
4. **Next Song / Volume Up:** Short press/Long press the NEXT / V+ Key
5. **Play/Pause:** Short press the PP/Phone key
6. **Callback:** Double click the PP/Phone key
7. **Answer a Call:** Single click the PP/Phone Key  
Hang up: press the PP/Phone key  
Decline a call: Long press the PP/Phone key
9. **FM Auto Search:** Single click the PP/Phone Key

### Getting Started

**LED Indicator**

- When the headphones are on, the BLUE Light will be on.
- When the headphones are off, the RED Light will be off.
- When Bluetooth is NOT connected, the RED and BLUE lights will flash alternately.
- When Bluetooth is connected, the BLUE light will be always on.
- During Bluetooth Playback, the BLUE light will flash every four seconds.
- When the TF-Card is paused, the BLUE light will be on.
- While the TF-Card is playing, the RED light will slowly flash.
- When FM is auto-searching, the RED light will quickly flash.
- When FM is playing, the RED light will be always on.

While your headphones are charging, the RED light will stay on. When the charge is full, the BLUE light will turn on, and stay on.

### Bluetooth Pairing

1. Power the headphone ON. The Led indicator will turn BLUE.
2. Set your mobile device to search for Bluetooth devices. When it appears, select "HKBTHP01" from the list of found devices.
3. After a successful pairing, the LED indicator will flash BLUE every four seconds. You should be able to play music on the headphone.

(Fold Inward) - - - - ▶

(Back Cover)

(Front Cover)

### Compliance Information

**FCC Information**  
This device complies with Part 15 of the FCC Rules.

**Caution:** Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**Radiation Exposure Information**  
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

**WARNING Li-Ion Battery Inside**  
This product is fitted with a Li-Ion battery. Do not damage, open, or dismantle the battery and do not use it in damp and/or corrosive conditions. Use only with compatible chargers. Never dispose of batteries in a fire, and never expose them to high temperatures. Do not expose the product to temperatures exceeding 60°C (140°F).

**Rating Label Definitions**

- ☰ Direct current symbol.
- ♻️ This symbol signifies the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health.
- ♻️ This symbol signifies and declares that this equipment has battery charging which complies with California CEC and energy efficiency.
- Bluetooth This symbol signifies that this is a wireless device powered by Bluetooth technology.
- FC This symbol represents FCC Declaration of Conformity and compliance.



### Warranty Information

**1-Year Limited Warranty**  
Territory: United States/Canada

**LIMITED WARRANTY TO ORIGINAL CONSUMER**  
This product as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc. to the original consumer purchaser against defects in materials and workmanship ("Warranty") as follows:

**To obtain warranty service:**

- Visit our customer support portal: [www.customersupport123.com](http://www.customersupport123.com) and select "Support"
- Select the brand, fill out the corresponding form (exchanges require dated proof of purchase from an authorized retailer) then submit your request.

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.

**Warranty service not provided**  
This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorized modification including software modifications such as the installation of custom firmware. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR/FURTHER RECLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR, REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR OR ITS MANUFACTURERS BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT, EXCEPT AS STATED HEREIN. NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.

**All product names, trademarks, and registered trademarks are property of their respective owners. All company, product, and service names used in this document are for identification purposes only. Use of these names, trademarks, and brands does not imply endorsement.**

Designed in US  
Printed in China  
v1.05/2024



**HELLO KITTY®**  
by Sanrio®

© 2024 SANRIO CO., LTD.  
Used Under License.  
[www.sanrio.com](http://www.sanrio.com)



SIL-35047  
Southern Telecom Inc.  
5601 1st Ave.  
Brooklyn, NY 11220

# HELLO KITTY® AND FRIENDS

Bluetooth®

## WIRELESS HEADPHONES



Instruction Manual  
HKBTHP01

### Before You Begin...

## READ CAREFULLY AND KEEP THIS MANUAL

**⚠️ Caution**  
To ensure safe and proper use, read all safety information before using the device. Only use with manufacturer-approved batteries, chargers, accessories, and supplies.

- **THIS DEVICE IS NOT A TOY**, keep away from children and pets.
- Do not disassemble, modify, or repair the device.
- Do not expose to extreme temperatures (heat or cold), open flames, humid, or wet conditions.
- Do not submerge in water.
- Low power may cause poor Bluetooth connection or sound distortion.
- Do not overcharge battery.
- If using with a USB adapter, make sure the adapter is not damaged.
- Do not allow the USB port or the connectors of the supplied USB cable to be exposed to dust or water, or to come into contact with any conductive materials such as liquids, metallic powders, etc.
- The headphones contain a built-in battery and should not be disposed of with regular household waste. Please consult the local authorities on the correct way to dispose of this device.

**In the Box**

- Wireless Headphones (x1)
- USB Charging Cable (x1)
- User Manual (x1)

### Operation Guide

1. **Turning Headphones On/Off:** Long press the POWER / M Key for two seconds
2. **Mode Switch:** Short press the POWER / M Key
3. **Previous Song / Volume Down:** Short press / Long press the PREV / V- key
4. **Next Song / Volume Up:** Short press/Long press the NEXT / V+ Key
5. **Play/Pause:** Short press the PP/Phone key
6. **Callback:** Double click the PP/Phone key
7. **Answer a Call:** Single click the PP/Phone Key
8. **Hang up:** press the PP/Phone key
9. **Decline a call:** Long press the PP/Phone key
9. **FM Auto Search:** Single click the PP/Phone Key

### Getting Started

#### LED Indicator

- When the headphones are on, the BLUE Light will be on.
- When the headphones are off, the RED Light will be off.
- When Bluetooth is NOT connected, the RED and BLUE lights will flash alternately.
- When Bluetooth is connected, the BLUE light will be always on.
- During Bluetooth Playback, the BLUE light will flash every four seconds.
- When the TF-Card is paused, the RED light will be on.
- While the TF-Card is playing, the RED light will slowly flash.
- When FM is auto-searching, the RED light will quickly flash.
- When FM is playing, the RED light will be always on.

While your headphones are charging, the RED light will stay on. When the charge is full, the BLUE light will turn on, and stay on.

#### Bluetooth Pairing

1. Power the headphone ON. The Led indicator will turn BLUE.
2. Set your mobile device to search for Bluetooth devices. When it appears, select "HKBTHP01" from the list of found devices.
3. After a successful pairing, the LED indicator will flash BLUE every four seconds. You should be able to play music on the headphone.