

<p>65 mm</p> <p>65 mm</p> <p>感谢您选用KVHB_Pro, 请在使用前仔细阅读本说明书, 以避免因使用不当而造成的损坏。</p>	<p>使用说明</p> <ol style="list-style-type: none"> 设备开机 长按设备背面的“静音”按钮5秒钟, 设备发出声音响铃。 绑定设备 打开手机自带的“查找”App, 将设备靠近您的iPhone, 轻点“物品”标签, 点击“+”, 选择添加其他物品, 将KVHB_Pro与您的设备, 轻点“连接”。 配对设备 打开手机自带的“查找”App, 点击屏幕最顶部的“物品”, 然后点击物品的名称, 在“丢失模式”下方, 点击“启用”。 删除设备 打开手机自带的“查找”App, 点击屏幕最顶部的“物品”, 然后点击物品的名称, 在“丢失模式”下方, 点击“删除”。 	<p>产品主要功能</p> <ol style="list-style-type: none"> 查找设备 手机与设备在蓝牙范围内(约15米左右), 在查找App中, 点击播放声音, 设备发出声音, 帮助您快速定位设备。 定位设备 打开手机自带的“查找”App, 将设备靠近您的iPhone, 轻点“物品”标签, 点击“+”, 选择添加其他物品, 将KVHB_Pro与您的设备, 轻点“连接”。 配对设备 打开手机自带的“查找”App, 点击屏幕最顶部的“物品”, 然后点击物品的名称, 在“丢失模式”下方, 点击“启用”。 删除设备 打开手机自带的“查找”App, 点击屏幕最顶部的“物品”, 然后点击物品的名称, 在“丢失模式”下方, 点击“删除”。 	<p>常见问题</p> <ol style="list-style-type: none"> 设备什么时候可以被别的苹果手机定位? 当设备与您的苹果手机断开一段时间后, 设备可以开始接收别的苹果手机定位, 您可以开始获得设备的定位。 如何确认设备是否已开机? 双击设备背面的“静音”按钮, 设备响铃, 说明设备在工作, 如果设备不响, 说明设备处于关机状态, 请长按按钮5秒, 开机。 如何防止设备被用于恶意跟踪? 双击设备背面的“静音”按钮, 设备响铃, 说明设备在工作, 如果设备不响, 说明设备处于关机状态, 请长按按钮5秒, 开机。 如何防止设备被用于恶意跟踪? 双击设备背面的“静音”按钮, 设备响铃, 说明设备在工作, 如果设备不响, 说明设备处于关机状态, 请长按按钮5秒, 开机。 	<p>设备按键使用说明</p> <ol style="list-style-type: none"> 静音/静音 长按设备背面的“静音”按钮5秒钟, 设备发出声音响铃。 定位设备 打开手机自带的“查找”App, 将设备靠近您的iPhone, 轻点“物品”标签, 点击“+”, 选择添加其他物品, 将KVHB_Pro与您的设备, 轻点“连接”。 配对设备 打开手机自带的“查找”App, 点击屏幕最顶部的“物品”, 然后点击物品的名称, 在“丢失模式”下方, 点击“启用”。 删除设备 打开手机自带的“查找”App, 点击屏幕最顶部的“物品”, 然后点击物品的名称, 在“丢失模式”下方, 点击“删除”。 	<p>重要提示</p> <p>设备与您的Apple配对时, 需要连接互联网, 如果出现无法配对的情况, 一般是您使用的网络暂时无法连接苹果服务器, 建议您可操作:</p> <ol style="list-style-type: none"> 重新连接到网络, 当网络恢复正常后再尝试配对。 关闭设备上的“设置”->“设备名称”, 关闭设备名称, 设备响铃, 点击上方设备名称旁边的秒表, 直到设备发出声音, 继续按照步骤操作, 设备发出声音, 断开连接, 修复出厂设置完成。 与查找App重新配对。 <p>固件升级</p> <p>在“查找”App页面内, 轻触您的设备, 往上滑动设备信息页面, 如果有新的固件发布或接近最新可以看到“有可用更新”, 点击后会弹出设备信息, 再点击设备信息中的“更新”按钮, 等待更新完成, 固件版本会自动更新。</p> <p>注意事项</p> <p>注册或使用Apple Find My应用程序查找设备时, 请使用最新版本的iOS、iPadOS、watchOS或macOS, Apple Apple Watch, watchOS, iPad, iPadOS, iPod touch, Mac和macOS是Apple软件和服务在您的设备上运行的前提条件。iOS是苹果在美国和其他国家的注册商标或服务标志。</p>
--	---	--	---	--	---

<p>Works with Apple Find My</p> <p>KVHB_Pro</p> <p>User Manual</p> <p>Thank you for choosing KVHB_Pro. Please read this manual carefully before use to avoid damage caused by improper use.</p>	<p>Quick instructions</p> <ol style="list-style-type: none"> Equipment startup Press and hold the device button for 5 seconds, and the device will be twice to prompt sound. Binding devices Open the built-in "Find" app on Apple. Bring the device closer to your iPhone, tap the "Items" tab, click "+", and select "Add Other Items". For devices with the words KVHB_Pro, tap "Connect". Fill in "Custom Name" to name your device and select a emoji. Agree to register the device with your Apple ID. Tap "Finish" to bind successfully. At this point, enter the item list, click on play sound, and you can hear the device alarm. Clickable "Lost Mode" Open the built-in "Find" app on Apple, click on "Items" at the bottom of the screen, and then click on the name of the item. Delete device Open the built-in "Find" app on Apple, click on "Items" at the bottom of the screen, and then click on the name of the item. 	<p>Main Functions</p> <ol style="list-style-type: none"> Find devices The phone and device are within Bluetooth range (usually around 15 meters). When searching for an app, click play sound, and the device will emit music to help you quickly find nearby items. Global positioning Open the Apple Search app and select the "Items" tab. Device enters pairing mode again Double-click the device button twice, the device will sound, indicating that the device is working. If the device does not sound, it indicates that the device is in a shutdown state. Press and hold the button for five seconds to turn on the device. The device enters pairing mode again Double-click the device button twice, the device will sound, indicating that the device is working. If the device does not sound, it indicates that the device is in a shutdown state. Press and hold the button for five seconds to turn on the device. 	<p>Common problem</p> <ol style="list-style-type: none"> When can the device be located by other Apple phones? After the device is disconnected from your iPhone for a period of time, the device can be located by other iPhones, and you can begin to get the location of the device. How to confirm if the device is turned on? Please double-click the device button twice, the device will sound, indicating that the device is working. If the device does not sound, it indicates that the device is in a shutdown state. Please press and hold the button for five seconds to turn on the device. How to prevent devices from being used for malicious tracking? When another device is mixed into your belongings and tracked for more than a period of time, you will be alerted in the following ways: If you have an iPhone, iPad, or iPod touch or other Apple device, you will receive a reminder on the Apple device. This feature is available on Apple devices on iPad 16.5 and later versions. 	<p>4. How to protect my privacy? When it's your device, only you can see it yourself. Your location data and history will never be stored on Apple's servers. The device that transmits your device's location data always remains anonymous, and the location data is encrypted and protected at every step of the search. Therefore, Apple is unaware of the location of your device and the identity of the device that helped locate it.</p> <p>5. How to replace the battery of the device?</p> <ol style="list-style-type: none"> Press open the casing from the hand buckle position on the side of the device. Remove the old battery and insert the new battery button with the positive pole facing upwards (standard battery, can be purchased at the supermarket). Once the device casing is installed, it can be connected and used. 	<p>Important reminder</p> <p>When pairing a device with a search app, it is necessary to connect to the Apple server. If pairing is not possible, it is usually because the network you are using is temporarily unable to connect to the Apple server. It is recommended to do the following:</p> <ol style="list-style-type: none"> Change mobile network, such as switching between WiFi and mobile network, or restart your phone. Remove device in factory settings: After the device is turned on, double-click the device button and the device will sound. Immediately press and hold the device button for five seconds until the device emits a prompt sound. Continue to press and hold the button for three seconds until the device plays the prompt sound. Release the button and the factory settings are restored. Re-pair with the search app. <p>Firmware update</p> <p>In the "Find" app page, find the corresponding device and slide up the device information page. If there is a new firmware release approaching the bottom, you can see "Available Update". After clicking, a pop-up window will prompt you. Then click on "Update". In the pop-up window and wait for about 15 minutes. After the update is completed, the firmware version will automatically refresh.</p> <p>Notes</p> <p>Attention: When using the Apple Find My application to search for this device, please use the latest version of iOS, iPadOS, watchOS, or macOS, Apple, Apple Watch, watchOS, iPad, iPhone, iPod touch, Mac, and macOS are trademarks or registered trademarks of Apple Inc. in the United States and other countries. iOS is a trademark or registered trademark of Cisco in the United States and other countries, and is authorized for use.</p>
---	--	--	---	--	--

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.