

Model: PPZW092 User Manual

Key Function:



1.Power

2.Four Shortcuts

3.Format

Adjust the picture size on the TV screen

4.SAP

Select audio

mode(MONO/STEREO/SAP)/audio language

5.Info

6.TV GUIDE

Access to the Electronic Program Guide (EPG) It allows you to find channels and content easily

7.NetTV

8.OPTIONS

Display a list of menu options applicable to the active screen

9.OK and Navigation Buttons

10.Back

11.Home

12.PREV.CH Returns to the previous channel

13.Color Buttons

14.Adjust the Voice

15.Turns the Sound on or off

16.Adjust the Channel

17.18 Enter a channel number

19.Display the audio portion of programming as text superimposed over the video

20.HDMI-CEC keys

Pairing New Remote method:

1. Press **[Power]** Key to turn on the **[TV]**
2. Press and Hold **[VOL-]** key and **[●•]** key together for 3-5 seconds, the indicator light flashes and enters the pairing state. After the pairing is successful, the indicator light will go out.

Connected new remote with a Paired Remote:

1. Press the **[Home]** key, then select **[Setting – Remotes & accessories]**
2. Select **[Add accessory]**, then Press **[OK]** key to confirm to pair.
3. Press and Hold **[VOL-]** key and **[●•]** key together for 3-5 seconds, the indicator light flashes and enters the pairing state. After the pairing is successful, the indicator light will go out.

FCC Caution.

(1) § 15.19 Labelling requirements.

This device **complies with** part 15 of the FCC Rules. Operation is subject to the following **two conditions**: (1) This device **may not** cause harmful interference, and (2) this device **must** accept any interference received, including interference that **may** cause undesired operation.

§ 15.21 Changes or modification **warning**

Any Changes or **modifications not** expressly approved by the party responsible for **compliance could void** the user's authority to operate the equipment.

§ 15.105 Information to the user.

Note: This equipment has been tested and **found to comply with** the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance **with** the instructions, **may** cause harmful interference to radio **communications**. **However**, there is **no** guarantee that interference **will not** occur in a particular installation. If this equipment **does** cause harmful interference to radio or television reception, **which** can be determined by turning the equipment **off** and **on**, the user is encouraged to try to correct the interference by **one or more of** the **following** measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.