

# User Manual

## Dual Mode Wireless Keyboard



Model: RT021

DECLARATION OF CONFORMITY TO EUROPEAN STANDARDS  
 This product is in conformity with the CE mark.  
 Made in China  
 www.ritek.com

### FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: The Granite is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment.


The device has been evaluated to meet general RF exposure requirement.

This equipment complies with FCC's RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or in conjunction with any other antenna or transmitter.

### CONTENTS

English 01-10  
 Deutsch 11-20

### Parts In Package




- 1 -

### Product Features

- Compatible with iPad, iPhone, Surface, Android Tablet, PC, Laptop, Smart TV, Android TV Box, Windows, Android and Mac.
- Battery Capacity: 850mAh
- TX Power: less than +5dBm
- Operational voltage: 3.7V
- Operational current: <120mA
- Charging voltage: 5V
- Charging current: <350mA
- Sleep current: <50uA
- Product weight: 510g
- Product size: 364.5x134x17.8mm


- 2 -

### Media Keys and Indicator



- 3 -

### Shortcut Keys



- When the FN key is locked, the FN lock indicator light is on:
- 1, F1 – Back
  - 2, F2 – Mute
  - 3, F3 – Volume –
  - 4, F4 – Volume +
  - 5, F5 – Music Player
  - 6, F6 – Home
  - 7, F7 – Search
  - 8, F8 – Menu
  - 9, F9 – Multi page
  - 10, F10 – Calculator
  - 11, F11 – Reduced screen brightness
  - 12, F12 – Increase screen brightness
  - 13, Del
  - 14, Prt Sc
  - 15, Scroll Lock
  - 16, Fn Lock
  - 17, Screen Lock

- 4 -

### Media Keys Functions In Different System

	Windows	Android	iOS	Mac
Previous	✓	✓	✓	✓
Play/Pause	✓	✓	✓	✓
Next	✓	✓	✓	✓
Back	✓	✓	✓	✓
Mute	✓	✓	✓	✓
Volume –	✓	✓	✓	✓
Volume +	✓	✓	✓	✓
Music Player	✓	✓	✓	✓
Home	✓	✓	✓	✓
Search	✓	✓	✓	✓
Menu	✓	✓	✓	✓
Multi page	✓	✓	✓	✓
Calculator	✓	✓	✓	✓
Reduced screen brightness	✓	✓	✓	✓

- 5 -

	Windows	Android	iOS	Mac
Screen brightness increase	✓	✓	✓	✓
Lock	✓	✓	✓	✓


### Operation Instruction

**2.4G Pairing**

1. Turn on the keyboard, press the "Mode" button until the BT/RF indicator into Green and flashing.

- 6 -


### 2. Open the cover, take out the USB receiver from the battery compartment.



3. Insert the USB receiver into the USB port of your device, the driver will be installed automatically.

- 7 -

### 4. In 2.4G Mode, the Green light been on. When the indicator flashing quickly, that means the keyboard need repairing. The Repairing operation: Press PWR button, reinsert the USB receiver into your device's USB port until the Green light keeps on, which means repairing succeeded.



### Backlight Setting

Keyboard Backlight has two colors: Blue, Green. Press **⏏** to switch the backlight colors.

### Auto Sleep Mode

Keyboard has 2 Auto Sleep modes: 30mins and 2hours. Press **FN + ESC** to switch the modes. The default mode is 30mins. If there is no any operation in 30mins/2hours, the keyboard will into sleep mode to save power. Press any button to wake up.

- 8 -

### Warning

1. The USB cable only for charging, it can not be used for data transfer.
2. When charging fully, pull out the charging cable please.
3. Do not try to open or repair this product by yourself please.
4. Keep this device away from fluids, such as water.

### Recycling

The disposal and recycling must be done as per local area or country regulation. We strive for continued research and development. Thus, we reserve the right to amend this User manual without prior notification.


- 9 -

### After-Sale Service

Thanks for your support of our RI products! We provide 12months warranty and 7\*24 service and if you have any problems with the product, you could contact us directly and we will help you soon. Contact Service: support@ritek.com

- 10 -

### Teile im Paket




- 11 -

### Produktmerkmale

- Dualmodus-Tastatur: 2,4GHz
- Kabellose Steuerung Entfernung: <10m
- Kompatibel mit iPad, iPhone, Surface, Android Tablet, PC, Laptop, Smart TV, Android TV Box, Windows, Android und Mac.
- Batteriekapazität: 850mAh
- Sendeleistung: weniger als +5dBm
- Betriebsspannung: 3,7V
- Betriebsstrom: <120mA
- Ladespannung: 5V
- Ladesstrom: <350mA
- Strom im Ruhezustand: <50uA
- Produktgewicht: 510g
- Produktgröße: 364,5x134x17,8mm


- 12 -

### Medientasten und Indikator



- 13 -

### Tastenkombinationen



- Wenn die FN-Taste gesperrt ist, leuchtet die FN-Lock:
- 1, F1 = Zurück
  - 2, F2 = Stummenschaltung
  - 3, F3 = Lautstärke –
  - 4, F4 = Lautstärke +
  - 5, F5 = Musik-Player
  - 6, F6 = Home
  - 7, F7 = Suche
  - 8, F8 = Menü
  - 9, F9 = Mehrere Seiten
  - 10, F10 = Taschenrechner
  - 11, F11 = Reduzierte Bildschirmhelligkeit
  - 12, F12 = Erhöhte Bildschirmhelligkeit
  - 13, Entf
  - 14, Druck
  - 15, Rollen
  - 16, Fn Lock
  - 17, Screen Lock

- 14 -

### Funktionen der Tasten In Jedem System

	Windows	Android	iOS	Mac
Vorherige	✓	✓	✓	✓
Play/Pause	✓	✓	✓	✓
Nächste	✓	✓	✓	✓
Zurück	✓	✓	✓	✓
Stummgeschalten	✓	✓	✓	✓
Lautstärke –	✓	✓	✓	✓
Lautstärke +	✓	✓	✓	✓
Musik-Player	✓	✓	✓	✓
Home	✓	✓	✓	✓
Suche	✓	✓	✓	✓
Menü	✓	✓	✓	✓
Mehrere Seiten	✓	✓	✓	✓
Taschenrechner	✓	✓	✓	✓
Reduzierte Bildschirmhelligkeit	✓	✓	✓	✓

- 15 -

	Windows	Android	iOS	Mac
EINGANGS-Beleuchtung	✓	✓	✓	✓
Screen Lock	✓	✓	✓	✓


### Anleitung zur Bedienung

**2.4GHz-Kopplung**

1. Schalten Sie das Tastatfeld ein und drücken Sie die "Mode"-Taste, bis die "BT/RF"-Anzeige grün leuchtet und blinkt.

- 16 -


### 2. Öffnen Sie den Deckel und nehmen Sie den USB-Empfänger aus dem Batteriefach.



3. Stecken Sie den USB-Empfänger in den USB-Anschluss Ihres Geräts. Der Treiber wird automatisch installiert.

- 17 -

### 4. Im 2,4GHz-Modus leuchtet das grüne Licht. Wenn die Anzeige schnell blinkt, bedeutet dies, dass die Tastatur repariert werden muss. Der Reparaturvorgang: Drücken Sie die "Pair"-Taste und stecken Sie den USB-Empfänger erneut in den USB-Anschluss Ihres Geräts, bis das grüne Licht wieder leuchtet, was bedeutet, dass die Reparatur erfolgreich war.



### Einstellung der Hintergrundbeleuchtung

Die Hintergrundbeleuchtung der Tastatur hat zwei Farben: Blau und Grün. Drücken Sie **⏏**, um die Farbe der Hintergrundbeleuchtung zu ändern. Automatische Ruhemodus.

### Automatischer Ruhemodus

Die Tastatur verfügt über 2 automatische Ruhemodi: 30 Minuten und 2 Stunden. Drücken Sie "FN + ESC", um die Modi zu wechseln.

- 18 -

Der Standardmodus ist 30 Minuten. Wenn innerhalb von 30 Minuten/2 Stunden keine Bedienung erfolgt, schaltet die Tastatur in den Ruhemodus, um Energie zu sparen. Drücken Sie eine beliebige Taste zum Aufwachen.

### Warnung

1. Das USB-Kabel dient nur zum Aufladen, es kann nicht zur Datenübertragung verwendet werden.
2. Wenn das Gerät vollständig aufgeladen ist, ziehen Sie bitte das Ladekabel heraus.
3. Versuchen Sie bitte nicht, dieses Produkt selbst zu öffnen oder zu reparieren.
4. Halten Sie dieses Gerät von Flüssigkeiten, wie z.B. Wasser, fern.

- 19 -

### Service nach dem Verkauf

Vielen Dank für Ihre Unterstützung von RI Produkten! Sollten Sie Probleme bei der Nutzung haben, können Sie uns gerne kontaktieren: support@ritek.com

Importiert durch: GreeTek Limited  
 Adresse: FUJI/RM 1309 13/F KING'S COMMERCIAL BUILDING NO 2-4 CHIAWAN COURT, S.S.1, KONGKONG

After-Sales-Adresse:  
 Firma: Henrik & Hans GmbH  
 Address: Odder Straße 117 53117 Bonn, Germany  
 Telefon: 0228-68958900  
 E-Mail: RI@henrikhans.de

EC/REP: CET PRODUCT SERVICE SR Z.O.O.(for authorities only)  
 Ul. Długa 33 102 Zgierz 95-100 Polen

- 20 -



www.ritek.com  
 Made in China

说明书黑白装订 105g铜板纸  
 说明书装订后成品尺寸: 90X90mm

项目名称	RT021	备注
物料名称	RT021 双模说明书-英-德语	版本 VER: 1.0
物料编号	06021001000	制作 Ben
物料尺寸	90*90mm	日期 2024/07/10