


60mm

85mm


DIRECTORY

Product composition/Product schematic description 1
 Guidelines for Safe and Effective Use/LED indicator status 2
 Product operating instructions 3
 Wearing method/touch operation instruction 4
 Product specifications/Precautions for products 5

PRODUCT COMPOSITION



PRODUCT SCHEMATIC DESCRIPTION



GUIDELINES FOR SAFE AND EFFECTIVE USE

Note: Please read this information before using the Bluetooth headset. Users who modify or modify this Bluetooth headset without permission will lose the right to continue to enjoy the services included in the device.


- ① Electromagnetic interference: Electronic equipment: To avoid the effects of electromagnetic interference or configuration incompatibilities, switch off your Bluetooth device as directed in a clearly marked location. CAAC: After boarding, please turn off your Bluetooth headset according to the instructions of the cabin crew. It is strictly prohibited to use Bluetooth headset in flight to avoid interference to the aircraft communication system.
- ② Security matters: Placement: It is recommended that you place the Bluetooth headset in a place where it is not squeezed when you are not using it. Squeezing may cause product damage or personal injury. Children: Do not let children play with the Bluetooth headset. Some of the small parts are detachable and can be swallowed and become dangerous.

LED INDICATOR STATUS


Headphone compartment indicator	
• Charge the earphone compartment (not fully charged): white light flashes	
• Earphone compartment is fully charged: the white light is always on	
• Charge the headset (not fully charged): the white light is always on	
• Fully charge the headset: the light is off	

PRODUCT OPERATING INSTRUCTIONS

- 1. Power-on**
 Mode one: Open the upper cover of the earphone compartment, take out the earphone and turn it on automatically.
 Mode two: Press and hold the headset function key for about 5 seconds to turn on the headset.
- 2. Shutdown**
 Mode one: Put the earphone back into the earphone compartment and turn off the earphone.
 Mode two: When the left and right earphones are turned on, press and hold the earphone function key for about 5 seconds, and then the earphone will be turned off.
- 3. Pairing**
 Step one: Open the upper cover of the earphone compartment, take out the earphone, turn it on automatically and form a team.
 Step two: Open the Bluetooth list of smart devices, search for TA410 and connect (monaural use is supported).



HOW TO WEAR IT



TOUCH THE OPERATING INSTRUCTIONS

Music playback mode—left/right headphone operation
 ① Last song: Double-click the left headset (L) Function key
 ② Next song: Double-click the right headset (R) Function key
 ③ Pause/ play: Tap any of the headset function key
 The phone is hands-free—In the state of incoming call (Left and right earphone operation)

① Listen: Tap any of the headset function keys
 ② Reject: Click any headset function key three times
 ③ Hang up: Click any headset function key

Activate the voice assistant(Smart devices support voice assistants)
 Left and right earphone operation
 Activate: Press and hold any headset function key for about 3 seconds to activate the voice assistant

PRODUCT SPECIFICATIONS

Product name	Open True Wireless Bluetooth Headset
Product model	TA410
Headset size	28.3mm×17.6mm×26.2mm
Rated capacity of earphone lithium battery	25mAh
Headphone rated input	5V --- 25mA
Horn size	10mm
Bluetooth version	Bluetooth V5.4
Working distance	≥10M
Headphone compartment size	61.2mm×30.6mm×49mm
Rated capacity of lithium battery in earphone compartment	250mAh
Headphone compartment rated input	5V --- 250mA
Signal to noise ratio	103dB
Microphone sensitivity	-42dB±3dB
Frequency response	20Hz-20KHz

PRECAUTIONS FOR PRODUCTS

Security information
 Before using this product, please read the safety instructions and follow all general safety preventive measure. Any operation inconsistent with this manual may cause damage to the product.

! Alert

- Do not attempt to disassemble or replace any part of the product except as specifically indicated in the instructions.
- This product contains a built-in rechargeable battery. Do not squeeze the product or place it in a place where it can be easily dropped; Do not impact, squeeze, puncture or short-circuit the battery. In case of abnormal phenomena such as excessive temperature, deformation, bulging and leakage, please stop using the battery. Do not place the equipment near a heat source or an exposed fire source, or other places where high temperatures may be generated. Do not put the battery in open fire, sunlight, heater, stove and other high temperature and high pressure environment. Do not use the battery after soaking in water. After using the earphone, do not put the earphone in the environment of high temperature and high pressure, such as damp, full of dust, lampblack, steam, direct sunlight, etc so as to avoid damage to the earphone and battery. The battery can be charged and discharged for a limited number of times and will eventually age. When the battery is used abnormally, it can be replaced with a new one, but do not replace the battery by yourself, otherwise it will cause the battery to explode or the liquid in the battery to leak. Non-specified batteries or batteries that have been removed and modified are not covered by the warranty. If the battery is replaced improperly, there will be a risk of explosion, and it can only be replaced by the same type or equivalent type of battery through the after-sales service provider.
- After the product is used and scrapped, do not throw the product into the fire, and the waste treatment shall be carried out in strict accordance with the garbage classification. Please use this product reasonably and correctly to avoid causing certain harm and environmental damage.
- In the process of using the headset, due to a long distance, obstacles in the middle or a series of interference such as other radio signals, Bluetooth signals, WiFi signals, the headset will occasionally stutter, voice asynchronization or disconnection when listening to music, watching videos and playing games. If this happens, please reconnect the headset or stay away from the interference.
- When charging, please use the charging equipment with the output voltage of DC5V/1A. The charging equipment with CCC safety certification from the regular manufacturer must be selected. Please do not use the fast charger, so as not to cause too much battery load and damage to the battery. The continuous charging time should not exceed the specified charging time, and do not use it during charging to avoid damage.

Open True Wireless Bluetooth Headphones

FCC STATEMENT
 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 (1) This device may not cause harmful interference, and
 (2) This device must accept any interference received, including interference that may cause undesired operation.
 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 Reorient or relocate the receiving antenna.
 Increase the separation between the equipment and receiver.
 Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

PRODUCT DESCRIPTION

TA410

Note: Please read the instruction manual before using the product. The warranty card is included. The picture is for reference only.