






























客户品牌: DDPW	项目名称: MINUS (海外版 V4)	折叠样式: 风琴折叠式	产品料号: 75401000249	版本类型: V1.0	日期日期: 20240903								
<div><div><div>BV1001</div><div>User Guide</div></div></div>	<div><div><div>1 SPECIFICATIONS</div><div>Product Name: Foldable Product Model: BV1001 Size: 100*120mm Weight: 20g Material: ABS+PC Usage: Indoor/Outdoor Power: 5V/1A Storage: 1000mAh High-Speed Flash, Long-Lasting</div></div></div> <div><div><div>2 PACKAGE CONTENTS</div><div><div></div><div></div><div></div><div></div></div><div><div></div><div></div><div></div><div></div></div><div><div></div><div></div><div></div><div></div></div></div></div> <div><div><div>3 PRODUCT OVERVIEW</div><div></div></div></div> <div><div><div>4 LED INDICATOR INSTRUCTION</div><div><table><tr><th>Indicator</th><th>Meaning</th></tr><tr><td>Red</td><td>Power On / Charging / Low Battery</td></tr><tr><td>Green</td><td>Full Charge / Standby</td></tr><tr><td>Blue</td><td>Bluetooth / Wi-Fi / NFC</td></tr><tr><td>Yellow</td><td>Warning / Error</td></tr><tr><td>White</td><td>Normal Operation</td></tr></table></div></div></div> <div><div><div>5 INSTALLATION</div><div><div><div>1. Remove the protective film from the back of the device.</div><div></div></div><div><div>2. Peel off the adhesive tape from the back of the device.</div><div></div></div><div><div>3. Peel off the adhesive tape from the back of the device.</div><div></div></div><div><div>4. Peel off the adhesive tape from the back of the device.</div><div></div></div><div><div>5. Peel off the adhesive tape from the back of the device.</div><div></div></div><div><div>6. Peel off the adhesive tape from the back of the device.</div><div></div></div><div><div>7. Peel off the adhesive tape from the back of the device.</div><div></div></div><div><div>8. Peel off the adhesive tape from the back of the device.</div><div></div></div><div><div>9. Peel off the adhesive tape from the back of the device.</div><div></div></div><div><div>10. Peel off the adhesive tape from the back of the device.</div><div></div></div></div></div></div> <div><div><div>6 APP INSTRUCTION</div><div><div><div>1. Download the BV1001 App from the App Store or Google Play.</div><div></div></div><div><div>2. Open the BV1001 App and log in with your account.</div><div></div></div><div><div>3. Tap the 'Device' button to add a new device.</div><div></div></div><div><div>4. Tap the 'Connect' button to connect to the device.</div><div></div></div></div></div></div> <div><div><div>7 PLAYBACK</div><div></div></div></div> <div><div><div>8 DOWNLOAD FILES</div><div></div></div></div> <div><div><div>9 FCC STATEMENT</div><div><p>This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment does cause harmful interference to radio or other communications, which can be determined by turning the equipment off and on, the user is encouraged to take the following steps to correct the interference:</p><ul style="list-style-type: none"><li>Reorient or relocate the receiving antenna.</li><li>Increase the separation between the equipment and receiver.</li><li>Connect the equipment into a different power outlet or a different circuit.</li><li>Consult the dealer or an experienced radio/TV technician for help.</li></ul><p>This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:</p><ol style="list-style-type: none"><li>This device may not cause harmful interference.</li><li>This device must accept any interference received, including interference that may cause undesired operation.</li></ol><p>Changes or modifications not expressly approved by the party responsible for compliance may void the user's authority to operate the equipment.</p><p>FCC Radiation Exposure Statement</p><p>This equipment complies with FCC radiation exposure limits as follows for uncontrolled environments. This equipment should be used and powered only when necessary to achieve the intended purpose.</p></div></div></div>	Indicator	Meaning	Red	Power On / Charging / Low Battery	Green	Full Charge / Standby	Blue	Bluetooth / Wi-Fi / NFC	Yellow	Warning / Error	White	Normal Operation
Indicator	Meaning												
Red	Power On / Charging / Low Battery												
Green	Full Charge / Standby												
Blue	Bluetooth / Wi-Fi / NFC												
Yellow	Warning / Error												
White	Normal Operation												