



DESERT SAFARI

SIX DRIVE CROSS COUNTRY CLIMBING VEHICLE

2.4
GHz

AGE 8+




CAUTION


- If the stunt car is not in use, please remove the battery from the stunt car and the controller.
- When using stunt car, please keep away from heat and avoid exposing the stunt car for a long time in direct sunlight.
- Do not pick up the stunt car while it is moving.
- Hands, hair and loose clothing should be kept away from the tires when the stunt car starts.

BATTERY SAFETY

- Keep batteries away from children.
- The battery must be replaced by an adult.
- The battery can only be charged under adult supervision, do not leave the rechargeable battery unattended.
- Do not cover the battery while charging. Do not expose the battery to direct sunlight.
- Do not allow the fully charged battery to connect to the charger; Overcharging can shrink Short battery life.
- Do not handle batteries in fire, as batteries may explode if batteries Damaged or could explode.



The remote uses a 2x1.5V "AA" battery



1. The USB charging line
2. Rechargeable battery pack (included)







USB charging instructions

1. Charge the battery string properly before using it for the first time to ensure sufficient power. If the battery string is not used for a long time, it will automatically discharge. Can shorten battery life.
2. The user should check the wire, plug, shell and related parts regularly. If any damage occurs, stop using it until it is repaired.
3. Toys cannot be connected to power sources that are not recommended for use. Charging conditions: Connect the USB intelligent charging cable and the output is 4.8V, electric USB related power medium with current >700mA, charging time: 3-5 hours (USB cable light is steady on when charging, and off when charging saturation) Use time: 15-20 minutes.
4. Charging instructions: The charging battery is connected to the intelligent USB charging cable. The intelligent USB charging cable can be connected to the power medium with USB socket. Charge the battery, such as desktop computer, laptop computer, portable power supply, USB power socket or USB adapter plug. Plug it into the power supply to charge.

PRODUCT CONFIGURATION PARAMETERS

RECEIVING MODE	BATTERY CAPACITY	USE YOUR TIME	CHARGING TIME	CHARGING WAY	REMOTE CONTROL BATTERY	REMOTE CONTROL DISTANCE
2.4G	4.8v 700mAh	15-20 minutes	3-5 hours	USB(5V/1A)	No.5 battery *2 (self-provided)	50-70meter

REMOTE OPERATION DIAGRAM



* Please read the instructions carefully before operation and keep them for future reference

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.