

User Manual

ANDROID TV-Box

Ultra HD Octa-core
UHD 4K Android TV BOX

1. Instructions for use


1. Power up the device: Connected to the external power supply, Hold down the right power button of the device, which is located at the lower right corner. At the same time, digital tube display information such as the working state of the machine and time.
2. Turn on the TV, use the TV remote control or mouse, operating TV menu
3. After booting into the main system interface, as shown below:



4. Through the remote control or move the mouse cursor, press the remote control to confirm key or click left mouse button, open the program.
5. In the main interface, click on the button, enter all application interface.


2. A Connectors

- 1.Time and operation status display 2. IR receive 3.Power LED
4.Power key 5.TF Slot 6.antenna 7.USB OTG 8.USB host
9.S/PDIF 10.AV Output 11.HDMI Output 12.RJ-45
13.DC 5V 14.Reset




3. Connector


A Connection diagram:



B Connection diagram:



4. Key Illustration of IR RC



5. Network Connection

1. Open the Applications tab In the main interface, then click "Settings"
2. After Choose: "Wireless network" click "Wi-Fi", click on "Wi-Fi settings".
3. Click connect to network, that will be can connected, if the network requires a password, enter the correct password in the password bar, WALN shows "Connected."
4. Network settings after completion, return to the main interface, then, you can use the network, and can be in the browser's address bar, enter the desired website address.
5. Open the webpage, click or sliding webpage, click the link to open the linked page.



6. Browse the file or folder

1. In Desktop state, click the application bar icon, enter into the application field, click into the" resource manager."
2. In the file list can be clickable sliding, rolling.
3. Click on the required file or folder, can open the file or folder.
4. Click the status bar of the back button to return to the level folder.
5. Click the Home button on the status bar, you can return to the home page.
6. Long press a file or folder, can popup a menu, for example: "Copy, delete, move, paste, rename" and other additional options. If you do not execute the operation, click on the Cancel button. directly



7. USB Connection

1. A point of USB line is inserted in the machine of OTG USB interface, the other point is inserted in the computer USB interface connection, drag down the status bar, and then show USB connection status, that will be appear " USB connection" , prompting USB connection.
2. If successful, your computer will be appear a new removable disk.
3. On the computer desktop to open "My Computer", double-click the new removable disk, where the data can be copied, deleted by machine.
4. Disconnect: Click the bottom left of the screen arrow to the removable disk icon, pop up a small window safe deletion mobile disk.



8. Install / uninstall software


1. Operating system default for Android 5.1.1 version, install the software required to process the format is*. Apk format.
2. Supports many popular third-party application software formats
3. Machine can be installed or uninstalled you need software.
4. To install an application, the need to*. Apk format copied to your machine, then open" resource manager",click to install*. Apk file.
5. Installed application, will appear in the application bar.
6. To uninstall the software, click "Settings" to enter the setup menu, click into the "Applications" tab, then click: "Manage Applications", click on the software you want to uninstall, and click "Uninstall."



9. Other application

Multimedia

1. Can support photograph and taking pictures.
2. Can support HD video playback, photo viewing, and music.
3. Firstly. need to play music, video, photos copy to the mini SD card or storage in mobile hard disk.
4. Click the application icon, after enter, click on the corresponding icon, such as "video" "picture" "music" into the corresponding interface.
5. Click the file of play, it can be play. file.



10. Network Requirement

Test network

Minimum bandwidth requirements: 2 m dedicated broadband recommended in parts of China telecom, China unicom, China railcom, Is not recommended, and the Great Wall broadband local radio and television widescreen and urban villages Shared networking way.

Prepare the router

Routers must be with the function of automatic dial-up Internet access, China telecom and Chinaunicom combined wireless ADSL cats no routing, use PPPOE dial function to surf the internet.

Wired network connection

Local connection through a router, plug and play, as the plug in cable, in set to obtain IP address automatically, Local connection, LAN Shared or online video to watch.

Wireless network connection

Refers to through a router, search the WIFI hotspot signal network connection, realize the online play, LAN to be Shared operations, such as in the use of a wireless connection, need to be set network—choose wireless—search to the player router name—type router passwords—enter the router passwords—the connection is successful.

11. Trouble shooting

Unable to boot

1. Power poor contact, please check the adapter, and ensure the adapter in good contact
2. Disable machine for electrostatic phenomenon, please press the power button to restart the machine

HDMI can't work

1. Check the default HDMI signal system
2. Check whether the HDMI is connected well, or in a line

AV video connection is not normal

1. Verify the AV video output and display device to connect
2. Confirm that the output of the machine model and your display device

12. FCC 15.19 Warning

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. The user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into and outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment. The distance between user and products should be no less than 20cm. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.