

Instruction manual

1. Turn on the power switch, and the bottom shows the light red.
2. Press the bottom CONNECT button (black matching button), enter the code mode, at this time the back of the Bluetooth connection display lights flashing (blue light).
3. Before pairing is used, make sure your computer is equipped with bluetooth. Note: if the computer does not have a Bluetooth function, you will need to purchase an external Bluetooth adapter.

Method: "Computer" button, open the "control panel", find other Bluetooth devices in the device, click the Bluetooth icon, click the "add equipment" system to start the search, click the Bluetooth mouse icon next to "not use key" automatically installed after the completion of the next system!

Mouse performance profile:

Surface: left, middle and right keys, charging display light (red)

At the bottom: DPI key, CONNECT key, DPI800 display light (green), DPI1200 display (green), DPI1600 display (green), Bluetooth connection display light (blue)

Battery: 3.7V 500mAh (1.85Wh)

Voltage: 3.3V

Operating current: 8mA

Standby current: 2mA

Sleep current: 1mA

Bluetooth distance: More than 10m

Frequency: 2.402GHz-2.480GHz

The value of DPI: 800,1200,1600

