

# BTH005

## Product Description Over Ear Wireless Headphone


### Instruction manual

Congratulations for your purchasing. For a better use of your new device, we recommend you to read this user manual carefully and keep it for record.

### PACKAGE CONTENTS

- Bluetooth Stereo Headphone
- USB charging cable
- Instruction manual
- 3.5mm Audio Cable
- Invitation card

## - OVERVIEW OF THE HEADPHONE



## Before first use

### Unpacking

■ Remove all packaging

■ Please reserve the packaging. The appliance can be stored in it if not used for a long period of time.

### Charging the appliance

■ This appliance is powered by a built-in rechargeable battery and need to be fully charged before first use.

■ To start recharging, switch off the headphones (refer to section "switch off the earphones") and connect the USB connector of the charging cable (10) to the USB port (7) on the headphone. Then connect the USB connector to a USB port of a computer or the like.

■ The charging indicator lights up in red to indicate the battery is being charged.

■ After the battery is fully charged, the charging indicator (6) turns off. Disconnect the headphone from the USB cable (10).

■ Now the appliance is ready for use.

## **Function overview**

### **A. ON / OFF Switch**

1. Switch On, the power will be turn on.
2. Switch Off, the power will be turn off.



pls switch off the headphone when external input or Sound quality will be worse

### **B. ►/▮ Multi-function button (pairing, play/pause, answer/end calls)**

1. When you turn the Switch to On position, press and hold the button (4 seconds), the headphone would automatically enter boot status
2. When you turn the Switch to On position, press and hold the button (6 seconds), the headphone would automatically enter pairing mode
3. When you turn the Switch to On position, press and hold the button (3 seconds), the headphone would automatically enter standby mode
4. When the music is playing, short press the button, the music will stop. And when you short press the button again, the music will continue to play again
5. When the phone call is coming, short press is can pick up the phone, press and hold (2seconds) is to refuse the phone call
6. Short press the button to hang up the phone call after finished.

### **C. ▲ Volume up (Next track)**

1. Short press once to replay the music, short press twice to play the next song.
2. Press and hold the button to enlarge the volume of the sound

### **D. ▼ Volume down (Last track)**

1. Short press once to play the last song.
2. Press and hold the button to reduce the volume of the sound.



Bluetooth function keys vary by different Bluetooth devices

## **TECHNICAL SPECIFICATION**

Bluetooth Version: Bluetooth Version 4.1

Function: Headphone, Microphone for calling

Driver Unit: 40 mm

Sensitivity: 100+/-3dB S.P.L at 1KHz

Impedance: 32Ω

Frequency Range: 20Hz - 20kHz

Maximum input Power: 50 mW

Bluetooth working range: up to approx.10 metres (measured in open space, walls and structures may affect range of appliance. Distance may vary depending on different Bluetooth devices. (Within 1 meter whilst pairing with Bluetooth device)

Battery

-Li-polymer battery: 450mAh

-Charging time: Approx. 2.5 hrs

-Music playing time: Approx. 15 hours

## **TROUBLE SHOOTING**

<b>Problem</b>	<b>Possible cause</b>	<b>Solution</b>
The appliance does not work	The appliance is out of power	Charge the appliance (refer to section "charging the appliance" )
Bluetooth connection cannot be established or poor music playback/phone calling	Out of detection range. Transmission conditions not optimal (for example: thick walls) .	Move closer to the Bluetooth device (less than 10 meters) .Remove/bypass obstacles, check the Bluetooth setting of the device to be paired
No Sound	Headphone not switched on. Volume too low or muted.	Switch on Headphone. Adjust volume on the headphone and, if necessary, on the Bluetooth device.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.