
5 Tracker Hardware Specifications


5.1 Sensors

Tundra Tracker has 18 sensors as shown in the picture. Please avoid covering any of the sensors during use.



5.2 Where to place your label or sticker

If you want to affix your label or sticker on a tracker, please use the blue area in the picture, avoiding sensors inside.



5.3 Base Plates

Tundra Tracker has two types of base plates.

• Base plate with ¼ inch female screw for camera mount and a hole for stabilizing pin:

127.0.0.1:8000/print_page/ 11/24