

Instructions for Switch Wireless Controller

Wireless Game Controller

Model No.: SP5226

Manufacturer: Shenzhen CHT Technology Co., Ltd.

Button Descriptions:

1. Direction Pad (D-pad)
2. Action Buttons
3. Left Analog Stick (L2)
4. Right Analog Stick (R2)
5. HOME Button(Power on/off)
6. LED Indicator 1,2,3,4,
7. Turbo Button
8. Capture
9. Menu selection -
10. Menu selection +
11. Left triggers
12. Right triggers
13. Reset(Power off)



Main Features:

1. Use with Nintendo Switch console
2. Dual Shock
3. With turbo function, Capture function, Home function.
4. With 0.8m charging cable
5. Two high quality analogue sticks come without any dead zone
6. Bluetooth version: 2.1+EDR
7. Built-in 500mAh Li-ion battery, support 6 hours working time.
8. With sensor, no NFC, no awake-up function


Turbo Feature:

- 1). Press and hold one action button, then press the Turbo button, Turbo feature will be valid. For an example, Press and hold A, then press T, action order of A will keep going.
- 2). Based on above 1) state, press T to stop Turbo function.

Pairing Methods:

First time to connect:

1. Press and hold the HOME button for 5 seconds and 4 indicators blink fast.
2. Go to Switch's controller pair settings. Choose "Controller"→ "Change Grip/ Order"→Press "L + R "on Controller.
3. Press the "A" button to start working. If the connection is successful, the corresponding channel light keeps on.



Second time to connect: Press the HOME button on any page, and 4 indicators blink slowly.

Functions of LED indicators:

1. Corresponding Indication for the connected controller :

- 1). The 1st LED indicator is on as soon as the 1st controller is connected.
- 2). The 2nd LED indicator is on as soon as the 2nd controller is connected.
- 3). The 3rd LED indicator is on as soon as the 3rd controller is connected.
- 4). The 4th LED indicator is on as soon as the 4th controller is connected.

2. Charging Indication:

- 1). 4 LED indicators blink slowly during charging under unconnected state with console.
- 2). Matched LED indicator blinks slowly during charging under connected state with console.

3. Low voltage indication:

- 1) . Matched LED indicator blinks slowly at low voltage under connected state with console.

4. Pairing indication:

- 1) . Press and hold HOME button 5 seconds, 4 LED indicators blink fast during pairing. Matched LED indicator keeps ON after successful pairing.
- 2) . Press and hold HOME button 5 seconds, 4 LED indicators blink slowly if unsuccessful pairing.

FCC COMPLIANCE STATEMENT:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.

IC WARNING

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device

ADVERTENCIA IC

Cet appareil contient des émetteurs / récepteurs exemptés de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes :

- (1) Cet appareil ne doit pas causer d'interférences.
- (2) Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil.