


K75 Lite多国语言说明书折页: 128g双铜四色印刷



BASIC INFORMATION

- Manual
- Switch Puller
- Keyboard
- Type-C Cable
- Receiver

● Size: 335.8x155.5x41.5mm
● Backlight: RGB
● Layout: 83Keys
● Edition: USB2.4G/BT
● Switch: Mechanical switch

INDICATOR LIGHT

- Cap Lock
- Num Lock
- Win Lock
- Scroll Lock
- Blue Backlight
- Red Backlight

● Low voltage indicator: Red light flashing. Charging indicator: Flashing on charging, off when fully charged.

Wired Mode

- Toggle switch to OFF for Wired Mode.
- Fully charge keyboard before first use.

2.4GHz Mode

- Turn the toggle switch to the 2.4G position.
- Short press FN+Q/W/E to change BT Channel.
- Long press FN+Q/W/E entry pairing mode.

BT Mode

Toggle switch to BT for BT Mode.

BT Device 1 BT Device 2 BT Device 3

BASIC INFORMATION

- Manual
- Switch Puller
- Keyboard
- Type-C Cable
- Receiver

● Size: 335.8x155.5x41.5mm
● Backlight: RGB
● Layout: 83Keys
● Edition: USB2.4G/BT
● Switch: Mechanical switch

INDICATOR LIGHT

- Cap Lock
- Num Lock
- Win Lock
- Scroll Lock
- Blue Backlight
- Red Backlight

● Low voltage indicator: Red light flashing. Charging indicator: Flashing on charging, off when fully charged.

Wired Mode

- Toggle switch to OFF for Wired Mode.
- Fully charge keyboard before first use.

2.4GHz Mode

- Turn the toggle switch to the 2.4G position.
- Short press FN+Q/W/E to change BT Channel.
- Long press FN+Q/W/E entry pairing mode.

BT Mode

Toggle switch to BT for BT Mode.

BT Device 1 BT Device 2 BT Device 3

BATTERY REMINDER

In BT 2.4G mode, Press and hold FN+ENTER to view the battery level indicator.

For Example:

1! The backlight is on at the same time, indicating that the keyboard power is 10% at this time.

1! ~ 2@ The backlight is on at the same time, indicating that the keyboard power is 20% at this time.

1! ~ 0) Similarly, the backlight is on at the same time, indicating that the keyboard power is 100% at this time.

BATTERY REMINDER

In BT 2.4G mode, Press and hold FN+ENTER to view the battery level indicator.

For Example:

1! The backlight is on at the same time, indicating that the keyboard power is 10% at this time.

1! ~ 2@ The backlight is on at the same time, indicating that the keyboard power is 20% at this time.

1! ~ 0) Similarly, the backlight is on at the same time, indicating that the keyboard power is 100% at this time.

THE SECOND COMBINATION OF FUNCTION KEYS

- Switch to windows system
- Switch to mac system
- Pause
- Last song
- Play/pause
- Next song
- Mute
- Volume-
- Volume+
- Insert
- Sort/L
- PrintSc

BACKLIGHT CONTROL

- Switch backlight Mode
- Backlight Brightness-
- Backlight Brightness+
- Backlight Speed-
- Backlight Speed+
- Backlight Brightness-
- Backlight Brightness+
- Backlight Speed-
- Backlight Speed+
- Restore to factory settings

THE SECOND COMBINATION OF FUNCTION KEYS

- Switch to windows system
- Switch to mac system
- Pause
- Last song
- Play/pause
- Next song
- Mute
- Volume-
- Volume+
- Insert
- Sort/L
- PrintSc

BACKLIGHT CONTROL

- Switch backlight Mode
- Backlight Brightness-
- Backlight Brightness+
- Backlight Speed-
- Backlight Speed+
- Backlight Brightness-
- Backlight Brightness+
- Backlight Speed-
- Backlight Speed+
- Restore to factory settings

CUSTOMIZED BACKLIGHT

Non-customizable

Computer, Browser, MailBox, Desktop, Navigation, Phone, Music, Calculator, Player, Stop, Ctrl, Alt, Fn, Esc, Del, Win, Home, End, Print, Scroll, Arrow, Tab, Caps, Enter, Space, Shift, Back, Forward, F1-F12, Win, Home, End, Print, Scroll, Arrow, Tab, Caps, Enter, Space, Shift, Back, Forward, F1-F12

MULTIMEDIA KEY FOR WINDOWS

Screen Brightness, Keyboard Backlight Brightness

CUSTOMIZED BACKLIGHT

Non-customizable

Computer, Browser, MailBox, Desktop, Navigation, Phone, Music, Calculator, Player, Stop, Ctrl, Alt, Fn, Esc, Del, Win, Home, End, Print, Scroll, Arrow, Tab, Caps, Enter, Space, Shift, Back, Forward, F1-F12, Win, Home, End, Print, Scroll, Arrow, Tab, Caps, Enter, Space, Shift, Back, Forward, F1-F12

MULTIMEDIA KEY FOR MAC

Screen Brightness, Keyboard Backlight Brightness