



FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.



GUARANTEE
Non-human damage
12-month warranty

BASIC INFORMATION

Manual	Switch Puller	Keyboard	Type-C Cable	Receiver
• Size: 335.8(L)×155.5(W)×41.5(H)±2	• Backlight: RGB	• Edition: USB/2.4G/BT		
• Layout: 82keys	• Switch: Mechanical switch			

INDICATOR LIGHT

100% IN WIRELESS MODE BATTERY LEVEL En modo inalámbrico: Nivel de batería
En mode sans fil: Niveau de batterie

Caps Lock Bloq Mayús	Win Lock Bloq Win	ScrLk Lock Bloq Mayús	Indicateur Tension Faible Indicación de baja tensión

WIRED MODE

-
-

Toggle switch to OFF for Wired Mode.
Basculez le commutateur sur OFF pour passer en mode câblé
Interruptor de palanca a la posición de APAGADO

Fully charge keyboard before first use.
Rechargez complètement le clavier avant sa première utilisation
Cargue completamente el teclado antes de utilizarlo por primera vez

2.4GHZ MODE

-
-

Turn the toggle switch to the 2.4G position
Basculez l'interrupteur en position 2.4G
Commutador a la posición 2.4G

BT MODE

Toggle switch to BT for BT Mode.
Commutateur BT pour le mode Bluetooth
Commutador en posición BT

Short press Fn+Q/W/E to change BT channel.
Appuis Bref sur Fn+Q/W/E pour changer de canal Bluetooth
Pulsación corta Fn+Q/W/E para canal Bluetooth.

Long press Fn+Q/W/E entry pairing mode.
Appuis long sur Fn+Q/W/E pour entrer dans le mode d'appariage
Pulsación larga Fn+Q/W/E al modo de emparejamiento

THE SECOND COMBINATION OF FUNCTION KEYS

Switch to windows system Basculer en mode système windows Cambiar a Windows	Switch to mac system Basculer en mode système mac Cambiar a sistema mac	Pause Pause Pausa
Last song Musique Précédente Canción anterior	Play / pause Lecture / Pause Reproducir/pausar	Next song Musique Suivante Canción siguiente
Mute Sourcine Silenciar	Volume- Diminuer le Volume Volumen-	Volume+ Augmenter le Volume Volumen+
Insert Insérer Insertar	ScrLk ScrLk ScrLk	PrtSc PrtSc (Impression D'écran) PrtSc

BACKLIGHT CONTROL

Switch Backlight Mode Changement du mode de rétro-éclairage Cambiar el modo de retroiluminación	Backlight Brightness- Diminution de la Luminosité du rétroéclairage- Brillo de la retroiluminación-
Switch the backlight color Changer la couleur du rétroéclairage Cambiar el color de la retroiluminación	Backlight Speed- Diminution de la Vitesse du rétroéclairage- Velocidad de retroiluminación-
Backlight Brightness+ Augmentation de la Luminosité du rétroéclairage+ Brillo de la retroiluminación+	Window Lock Verrouillage Win Bloquear tecla WIN
Backlight Speed+ Augmentation de la Vitesse du rétroéclairage+ Velocidad de retroiluminación+	Restore to factory settings Rétablir les paramètres d'usine Restaurar valores de fábrica

CUSTOMIZED BACKLIGHT

Non-customizable
Non personnalisable
No personalizable

↓

↓

e.g.

Repeat key presses can change backlit colors
La pression répétée sur les touches peut modifier les couleurs du rétroéclairage
Las pulsaciones repetidas de las teclas cambian el color de la retroiluminación.

↓

MULTIMEDIA KEY FOR WINDOWS

Computer Ordinateur Ordenador	Browser Navigateur Navegador	Mailbox E-Mail Buzón
Calculator Calculatrice Calculadora	Player Lecture Reproductor	Stop Arrêt Detener

MULTIMEDIA KEY FOR MAC

Screen Brightness- Diminution de la Luminosité de l'écran- Brillo de la pantalla-	Screen Brightness+ Augmentation de la Luminosité de l'écran+ Brillo de la pantalla+
Keyboard Backlight Brightness- Diminution de la Luminosité du rétroéclairage du clavier - Brillo de la retroiluminación del teclado -	Keyboard Backlight Brightness+ Augmentation de la Luminosité du Rétroéclairage du clavier + Brillo de la retroiluminación del teclado +

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates noise and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure condition without restriction.



GUARANTEE
Non-human damage
12-month warranty

BASIC INFORMATION

Manual	Switch Puller	Keyboard	Type-C Cable	Receiver
• Size: 335.8(L)×155.5(W)×41.5(H)±2	• Backlight: RGB	• Edition: USB/2.4G/BT		
• Layout: 82keys	• Switch: Mechanical switch			

INDICATOR LIGHT

100% 无线模式下 电池电量
Im drahtlosen Modus: Batteriestand
In modalità wireless: livello della batteria

○ Caps Lock	○ Win Lock	○ ScrLk Lock	○ 低电压指示
A Feststellaste Caps Lock	🔒 Win-Sperre Win Lock	↓ ScrLk-Sperre ScrLk Lock	⚡ Anzeige der niedrigen Spannung Indicazione di bassa tensione

WIRED MODE

1

2

3

拨动开关到OFF位置
Kippschalter auf die Position OFF
Portare l'interruttore in posizione OFF

首次使用前请为键盘充满电
Bitte laden Sie die Tastatur vor dem ersten Gebrauch vollständig auf
Caricare completamente la tastiera prima del primo utilizzo

2.4GHZ MODE

1

2

拨动开关到2.4G位置
Kippschalter auf die Position 2.4G
Commutare l'interruttore in posizione 2.4G

BT MODE

拨动开关到BT位置
Kippschalter auf die Position BT
Commuta l'interruttore sulla posizione BT

短按Fn+Q/W/E至蓝牙频道
Kurzes Drücken von Fn+Q/W/E zum Bluetooth-Kanal
Premere brevemente Fn+Q/W/E per passare al canale Bluetooth

长按Fn+Q/W/E进入配对模式
Langes Drücken von Fn+Q/W/E zum Pairing-Modus
Premere a lungo Fn+Q/W/E per passare alla modalità di accoppiamento

THE SECOND COMBINATION OF FUNCTION KEYS

切换到windows系统 Schalter Im Windows-System Passa a Windows	切换到mac系统 Schalter Im MAC-System Passare al sistema Mac	停止 Pause Pause
上一曲 Letzter Song Canzone precedente	播放 / 暂停 Wiedergabe/Pause Riproduzione/pausa	下一曲 Nächster Song Canzone successiva
静音 Stummschaltung Silenzioso	音量- Lautstärke Verringern Volume-	音量+ Lautstärke Erhöhen Volume+
Insert Einfügen Inserire	ScrLk ScrLk ScrLk	PrtSc PrtSc PrtSc

BACKLIGHT CONTROL

切换背光模式 Umschalten des Hintergrundbeleuchtungsmodus Commutazione della modalità di retroilluminazione	背光亮度- Helligkeit der Hintergrundbeleuchtung- Luminosità della retroilluminazione-
切换背光颜色 Farbe der Hintergrundbeleuchtung wechseln Cambiare il colore della retroilluminazione	背光速度- Geschwindigkeit der Hintergrundbeleuchtung- Velocità retroilluminazione-
背光亮度+ Helligkeit der Hintergrundbeleuchtung+ Luminosità della retroilluminazione+	锁定WIN键 WIN-Taste sperren Blocco del tasto WIN
背光速度+ Geschwindigkeit der Hintergrundbeleuchtung+ Velocità retroilluminazione+	恢复出厂设置 Werkseinstellungen wiederherstellen Ripristino delle impostazioni di fabbrica

CUSTOMIZED BACKLIGHT

不可自定义
Nicht anpassbar
Non personalizzabile

e.g.

重复按键可以改变背光颜色
Durch wiederholtes Drücken der Taste ändert sich die Farbe der Hintergrundbeleuchtung.
La pressione ripetuta dei tasti cambia il colore della retroilluminazione.

MULTIMEDIA KEY FOR WINDOWS

计算机 Computer Computer	浏览器 Browser Browser	邮箱 Mailbox Cassetta postale
计算器 Taschenrechner Calcolatrice	播放器 Spieler Lettore	停止 Anhalten Arresto

MULTIMEDIA KEY FOR MAC

屏幕亮度- Bildschirmhelligkeit- Luminosità dello schermo-	屏幕亮度+ Bildschirmhelligkeit+ Luminosità dello schermo+
键盘背光亮度- Helligkeit der Hintergrundbeleuchtung der Tastatur - Luminosità della retroilluminazione della tastiera -	键盘背光亮度+ Helligkeit der Hintergrundbeleuchtung der Tastatur + Luminosità della retroilluminazione della tastiera +

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.