








# BATTERY CONNECTOR





# OTG Power




# Handset Microphone 1




# Earphone Audio



# 1xSpeaker




# Earphone MICPHONE







WiFi  
 802.11b/g/n(HT20)  
 2412MHz to 2462MHz  
 802.11n(HT40)  
 2422MHz to 2452MHz




















# NAND Flash








# MT8127A








# Camera




# G-Sensor




# Common Debug


## UART




# Power Key



# Volume Up



# Volume Down



# USB HS IF

