


### 17. Antenna Locations & Separation Distances



## 18. Setup Photos


### Laptop Mode

with the bottom of the PC in direct contact against a flat phantom and the display open to the perpendicular (90°) position. (w/ 7.2 mm separation from antenna-to-phantom)



### SAR Linearity test configuration

with the bottom of the PC in direct contact against a flat phantom and the display open to the maximum angle possible. (w/ 3.5 mm separation from antenna-to-phantom)



(For the purpose of evaluation but not consider as normal SAR test configuration)

## 19. Host Device Photo



**END OF REPORT**