


External photos of EUT



Class II Permissive Change:

When assembling the BLE module, the connector position moves 1 mm due to mechanical interference.



1mm ↑

