


Attachment 8.


- DUT Antenna Information and SAR Test SETUP PHOTOGRAPHS

DUT Antenna Information


* Placement of each antenna




* Diagonal dimension of display and device



* Distance between Main antenna and edge



* Distance between BT/WLAN antenna and edge




SAR Test Setup Photographs

■ **Test Setup Photo(Left All)**




■ Test Setup Photo(Left Touch/Tilt)




■ **Test Setup Photo(Right All)**



■ **Test Setup Photo (Right Touch/Tilt)**



■ **Test Setup Photo (Body All)**




■ **Test Setup Photo (Rear)**




[Distance of 10 mm from the EUT]

■ **Test Setup Photo (Rear)**




[Distance of 15 mm from the EUT]

■ **Test Setup Photo (Front)**




[Distance of 10 mm from the EUT]

■ **Test Setup Photo (Front)**




[Distance of 15 mm from the EUT]

■ **Test Setup Photo (Left)**



[Distance of 10 mm from the EUT]

■ **Test Setup Photo (Right)**




[Distance of 10 mm from the EUT]

■ **Test Setup Photo (Top)**



[Distance of 10 mm from the EUT]

■ **Test Setup Photo (Bottom)**



[Distance of 10 mm from the EUT]