




Attachment 8.

- DUT Antenna Information and SAR Test SETUP PHOTOGRAPHS


DUT Antenna Information




* Distance between main antenna and edge



Distance between BT/WLAN antenna and edge





SAR Test Setup Photographs

■ **Test Setup Photo(Left All)**



■ Test Setup Photo(Left Touch)



■ **Test Setup Photo(Left Tilt)**



■ Test Setup Photo(Right All)




■ Test Setup Photo(Right Touch/Tilt)



■ **Test Setup Photo(Body All)**




■ **Test Setup Photo (Rear)**




[Distance of 15 mm from the EUT]

■ **Test Setup Photo (Rear)**



[Distance of 10 mm from the EUT]

■ **Test Setup Photo (Front)**



[Distance of 15 mm from the EUT]

■ **Test Setup Photo (Front)**




[Distance of 10 mm from the EUT]

■ **Test Setup Photo (Right)**




[Distance of 10 mm from the EUT]

■ **Test Setup Photo (Left)**



[Distance of 10 mm from the EUT]

■ **Test Setup Photo (Top)**



[Distance of 10 mm from the EUT]

■ **Test Setup Photo (Bottom)**



[Distance of 10 mm from the EUT]