



Antenna and Device Information



* Distance between Main antenna and edge



SAR Test Setup Photographs


■ Test Setup Photo (Left All)



■ Test Setup Photo(Left Touch/Tilt)



■ Test Setup Photo(Right All)




■ Test Setup Photo (Right Touch/Tilt)



■ **Test Setup Photo (Body All)**




■ Test Setup Photo (Rear)




[Distance of 1.0 cm from the EUT]

■ **Test Setup Photo (Front)**




[Distance of **1.0 cm** from the EUT]

■ Test Setup Photo (Left)




[Distance of 1.0 cm from the EUT]

■ Test Setup Photo (Right)



[Distance of 1.0 cm from the EUT]

■ Test Setup Photo(Top)




[Distance of 1.0 cm from the EUT]

■ **Test Setup Photo(Bottom)**




[Distance of 1.0 cm from the EUT]

■ Test Setup Photo (Rear)



[Distance of 1.5 cm from the EUT]

■ Test Setup Photo (Front)



[Distance of **1.5 cm** from the EUT]

■ **Test Setup Photo (Body All for Extremity SAR)**




■ **Test Setup Photo (Rear for Extremity SAR)**



[Distance of 0 cm from the EUT]

■ **Test Setup Photo (Front for Extremity SAR)**



[Distance of **0 cm** from the EUT]

■ **Test Setup Photo (Left for Extremity SAR)**



[Distance of 0 cm from the EUT]

■ **Test Setup Photo(Top for Extremity SAR)**



[Distance of 0 cm from the EUT]