



Attachment 8.

- DUT Antenna Information and SAR Test SETUP PHOTOGRAPHS


DUT Antenna Information

* Placement of each antenna







* Distance between BT/WLAN antenna and Main antenna



Distance between BT/WLAN antenna and edge







SAR Test Setup Photographs

■ Test Setup Photo(Left All)




■ Test Setup Photo(Left Touch/Tilt)




■ Test Setup Photo(Right All)



■ **Test Setup Photo (Right Touch/Tilt)**



■ **Test Setup Photo (Body All)**




■ **Test Setup Photo (Rear)**



[Distance of 1.0 cm from the EUT]

■ **Test Setup Photo (Front)**




[Distance of 1.0 cm from the EUT]

■ **Test Setup Photo (Left)**



[Distance of 1.0 cm from the EUT]

■ **Test Setup Photo (Right)**



[Distance of 1.0 cm from the EUT]

■ **Test Setup Photo (Top)**



[Distance of 1.0 cm from the EUT]

■ **Test Setup Photo (Bottom)**




[Distance of 1.0 cm from the EUT]

■ **Test Setup Photo (Rear)**



[Distance of 1.5 cm from the EUT]

■ **Test Setup Photo (Front)**



[Distance of 1.5 cm from the EUT]