



Attachment 8.



- DUT Antenna Information and SAR Test SETUP PHOTOGRAPHS



- DUT Antenna Information





Distance between ANT+/BT/WLAN antenna and Main antenna(1/3)











1. Head
1.1 Left All



1.2 Left Touch / Left Tilt



1.3 Right All




1.4 Right Touch / Right Tilt




2. Body


2.1 Body All



2.2 Body Rear




Distance of 10 mm from the EUT




Distance of 15 mm from the EUT

2.3 Body Front




Distance of 10 mm from the EUT




Distance of 15 mm from the EUT

2.4 Body Left




Distance of 10 mm from the EUT

2.5 Body Right



Distance of 10 mm from the EUT

2.6 Body Bottom




Distance of 10 mm from the EUT

2.7 Body Top



Distance of 10 mm from the EUT


2.7 Body Rear




Distance of 10 mm from the EUT (DUT)

3. Phablet

3.1 Phablet SAR Test Setup Rear




Distance of 0 mm from the EUT




Distance of 8 mm from the EUT

3.2 Phablet SAR Test Setup Front




Distance of 0 mm from the EUT



Distance of 7 mm from the EUT

3.3 Phablet SAR Test Setup Left



Distance of 0 mm from the EUT

3.4 Phablet SAR Test Setup Right



Distance of 0 mm from the EUT

3.5 Phablet SAR Test Setup Top



Distance of 0 mm from the EUT

3.6 SAR Test Setup Bottom



Distance of 0 mm from the EUT