



## **Attachment 8.**

### **- DUT Antenna Information and SAR Test SETUP PHOTOGRAPHS**


## DUT Antenna Information




\* Diagonal dimension of display and device



\* Distance between Main antenna and edge




\* Distance between BT/WLAN antenna and edge




## SAR Test Setup Photographs

■ **Test Setup Photo(Left All)**





■ Test Setup Photo(Left Touch/Tilt)



■ **Test Setup Photo(Right All)**



■ Test Setup Photo (Right Touch/Tilt)






■ **Test Setup Photo (Body All)**



■ **Test Setup Photo (Rear)**




**[Distance of 10 mm from the EUT]**

■ **Test Setup Photo (Rear)**




**[Distance of 15 mm from the EUT]**

■ **Test Setup Photo (Front)**



**[Distance of 10 mm from the EUT]**

■ **Test Setup Photo (Front)**



**[Distance of 15 mm from the EUT]**

■ **Test Setup Photo (Left)**



**[Distance of 10 mm from the EUT]**

■ Test Setup Photo (Right)



[Distance of 10 mm from the EUT]

■ **Test Setup Photo (Top)**



**[Distance of 10 mm from the EUT]**



■ **Test Setup Photo (Bottom)**



**[Distance of 10 mm from the EUT]**