




NR Band 66




40 MHz




30 MHz






15 MHz




10 MHz




5 MHz




NR Band 71




20 MHz




15 MHz





5 MHz

NR Band 77 (Lower)



100 MHz

