


YEZZ



#YEZZMOBILE

www.sayyezz.com/manuals

5



EN Insert USB cable and charge for 8 hours
ES Inserte el cable USB y cargue por 8 horas
PT Insira o USB e carregue durante 8 horas

6




EN Turn on phone and access manual
ES Encienda el teléfono y acceda el manual
PT Ligue o telefone e aceda ao manual


YEZZ




EN Quick Start Guide
ES Guía de Inicio Rápido
PT Guia de Inicio Rápido

1


EN Remove battery cover
ES Remueva la cubierta trasera
PT Remova a capa de bateria

2

EN Insert SD memory card
ES Inserte la tarjeta de memoria SD
PT Insira o cartão de memória SD

3

EN Insert SIM card(s)
ES Inserte la(s) tarjeta(s) SIM
PT Insira o(s) cartão(ões) SIM

4

EN Insert battery
ES Inserte la batería
PT Insira a bateria

Keys

The following table offers you a quick description about the phone's keys:

Key	Function
Power button	Allow you to turn on/off the device and to lock the screen.
Volume	Allow you to adjust the volume of ringing and notifications. Also allows you to adjust the volume of multimedia content playback.
Back	Allow you to return to the previous menu or screen. Also allow you to close some applications.
Home	It takes you directly to the home screen, leaving any application open.
Menu	Allow you to access to the functions menu of the application or screen you are.

















Screen

The screen of your mobile phone is designed as follows:



Icons




Learn about the icons that are displayed on the top of the screen, indicating the status of the phone:

	Signal strength		Wi-Fi connection
	GPRS connected		EDGE connected
	4G connected		HSPA connected
	Bluetooth On		New message
	USB connected		New email
	Battery meter		Alarm active
	Vibration profile		Silent profile
	Roaming indicator		Headset connected



Use basic call functions

Learn to make or answer calls in this section.

Make a call:

1. At the home screen or applications menu, touch the Phone icon  .
2. Dial the area code and phone number.
3. Touch  to start the call.
4. To end a call, touch .

To answer a call:




1. When you receive a call, slide the phone icon to the right to answer it or slide it to the left to reject it  .
2. To end the call, touch .

Send and view messages

In this section, learn how to send and receive:



- Text Messages (SMS).
- Multimedia Message (MMS).

Steps to send Text and Multimedia Messages:

1. Touch  Messages at the application list, then touch  on the corner.
2. Type in the phone number or contact name on the field or touch  to access to Contacts.
3. Type in your message.

To send as text message go to step 5.



To attach a multimedia object (audio, image, etc.) continue to step 4.


4. Touch  on the top right corner, select the attach type then choose the item.
5. Touch  to send the message.

Add contacts



Learn the basics of using the phonebook feature.

Add a new contact:

1. In the application list touch Contacts , then touch  on the bottom to add a new contact.
2. Fill the contact information (Name, Last name and phone number). You can add more fields such as, email, address.

3. Touch  on the top of the screen to save.

Search for a contact


1. In the application list touch  Contacts.
2. Slide your finger from bottom to top to scroll the list or touch the search button  and type in the first letters of the name or last name.
3. To see the contact details touch the name or the picture of the contact.

If you want to call a contact touch the phone number.

Listen to music


Learn how to listen to music via the music player or FM radio.

Listen to the FM radio:

1. Plug in the earphones in your phone.
2. In the application list touch  FM Radio.
3. Use the tool bar at the bottom to change of station.


Listen to music files:

First, copy the music files into your phone internal memory or a MicroSD card.

1. In the application list, touch  Music.
2. Select an order at the top of the screen and touch the song that you want to listen to.
3. You can Pause, Loop, or change of song using the tool bar at the bottom.

Browse the web




Learn how to access to your favorites Web Sites.

1. In the application list, touch  Browser.
2. Touch the address bar and type in the address of the web site you want to go.



USING THE CAMERA

Learn the basics to capture and view photos.

Capture pictures

1. In the applications list, touch  Camera.
2. Adjusts the lens at the photo target and make the desired adjustments by touching the settings button .
3. Touch the shot button  on the screen to capture the picture. It will be saved automatically.


See the captured pictures

In the applications list, touch  Gallery and then select the Camera folder  to access and visualize all the pictures captured by your phone.

CONNECTING TO INTERNET

Learn the basics to configure your phone and connect to Internet.

Add a new connection


1. In the applications list, touch  Settings to access to the device configuration.
2. Touch the option “More...”, then touch Mobile networks and touch Access Point Names. Now select the SIM Card that you want to configure.
3. Touch the Menu key and select New APN then, type in the parameters according with your Carrier.

The basic parameters are:

- Name
- APN
- Username
- Password

Some carriers use Proxy Servers, refer to your carrier configuration for more information.



4. When you finish typing in the parameters needed, touch Menu then Save.

If you have multiples APN Configurations for the same SIM card, choose which one you want to use touching the radio button  at the right side of the name.

To add another connection, repeat from step 3.

Switch between carriers (SIM cards)




If you use multiple SIM cards and want to switch to another one, follow these steps:

1. In the applications list, touch  Settings to access to the device configuration.
2. Touch  SIM cards .
3. Choose the option Data connection and select the SIM Card that you want to use.

USING THE BLUETOOTH

Learn about your phone's ability to connect to other wireless devices for exchanging data.

Turn on the Bluetooth wireless feature




1. In the applications list, touch  Settings to access to the device configuration.
2. Touch the Bluetooth option  Bluetooth .
3. To turn the Bluetooth touching the button  on the right top corner.

Find and pair with other Bluetooth enabled devices

1. When you turn the Bluetooth on, the list will show all the available devices near you.
2. Touch the device that you want to pair with your phone.
3. Enter a PIN for the Bluetooth wireless feature or the other device's Bluetooth PIN, if it has one, and press OK.


When the owner of the other device enters the same code or accepts the connection, the pairing will be complete.

Send images using the Bluetooth wireless feature

1. Open Gallery .
2. Choose a picture and press Share  on the top right corner of the screen and select Bluetooth  Bluetooth .
3. Touch the device that you want to send the picture then accept the file in the receiver.

Receive images using the Bluetooth wireless feature




1. Turn on the Bluetooth at System Settings.
2. Type in the Bluetooth PIN or accept it (if it is needed).
3. Accept the receiving file if you want to receive data from the other device.

When the transferring is finished you can see the picture using the Gallery Application .




USING THE WI-FI

Learn to use the phone's wireless capabilities to connect to any wireless local area network compatible.



Connect to a wireless network

1. In the applications list, touch  Settings to access to the device configuration.
2. Touch the Wi-Fi option  Wi-Fi .
3. To turn the On the Wi-Fi touching the button  on the right top corner.
4. Choose a wireless network and enter the security password if it is needed.

Disconnect from a wireless network

1. In the applications list, touch  Settings to access to the device configuration.
2. Touch the Wi-Fi option  Wi-Fi .
3. To turn the Wi-Fi off touch the button  on the right top corner.

View the technical details of a wireless network

1. In the applications list, touch  Settings to access to the device configuration.
2. Touch the Wi-Fi option  Wi-Fi .
3. Touch the active wireless network to see details such as Link Speed, Signal strength and more.

FCC

Please take time to read this important section.

FCC Caution

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance

with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Specific Absorption Rate (SAR) information

SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value, in general, the closer you are to a wireless base station antenna, the lower the power output.

Before a new model phone is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC, Tests for each phone are performed in positions and locations (e.g. at the ear and worn on the body) as required by the FCC.

For body worn operation, this model phone has been tested and meets the FCC RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that contains no metal and that positions the handset a minimum of 1.0 cm from the body.

Non-compliance with the above restrictions may result in violation of RF exposure guidelines.