




PANTONE
424 C




PANTONE
299 C

FRONT COVER



INSIDE



INSIDE

1 Assemble the charger

2 Plug it into a power outlet

3 Position the center of your Nexus device on the charger

4 Lightning bolt in the status bar indicates charging in progress

Works with Nexus devices that support wireless charging

4000-00157-01

BACK COVER

