

Safety Card - Placed under power cable in bottom tray

2012-04-09 / rev5

PN# - TBD

DESCRIPTION:

Size: 140mm x 120mm

Shape: Rectangle with 3mm RAD's

Color: See PMS call-outs to the right

Finish: Matte

Material: Paper

Rear: Printed black on rear

Placed in bottom of power cable tray.

Important Safety Instructions

Please recycle
this packaging



1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with a dry cloth.
7. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
8. Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
9. Unplug this apparatus during lightning storms or when unused for long periods of time.
10. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.



PMS White c



PMS 310 U



PMS Black U