

User Manual Draft

- Earbuds
- Charging case
- Charging Cable

Setup Instruction:

1. Open the earbuds case and keep the earbuds inside.
2. Press and hold the pairing button until the light starts pulsing.
3. Go to Bluetooth settings on your device and make sure the Bluetooth is on.
4. Tap "Earbuds" and connect.

EMC Compliance

Important: This product has demonstrated EMC compliance under conditions that included the use of compliant peripheral devices and shielded cables between system components. It is important that you use compliant peripheral devices and shielded cables between system components to reduce the possibility of causing interference to radios, televisions, and other electronic devices.

United States Federal Communications Commission (FCC) Regulatory Compliance

FCC ID:

Left earbud: A4RG1007

Right earbud: A4RG1008

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does

cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications to this product not authorized by the manufacture could void the electromagnetic compatibility (EMC) and wireless compliance and negate your authority to operate the product.

Model Number: G1007, G1008, G1013

Responsible Party: Google LLC, 1600 Amphitheatre Parkway, Mountain View, CA 94043.

For help, please use the link below:

<https://support.google.com/googlepixelbuds#topic=7544331>

Radio Frequency Exposure

This device meets the U.S. Federal Communications Commission's (FCC) requirements for exposure to radio waves and is designed and manufactured not to exceed the FCC's emission limits for exposure to radiofrequency (RF) energy. To comply with FCC RF exposure compliance requirements, this device must not be co-located or operating in conjunction with any other antenna or transmitter.