




### Ant4 Freq. 6175 MHz:




### Ant4 Freq. 6700 MHz:



### Ant4 Freq. 6475 MHz:




### Ant4 Freq. 7000 MHz:




### Ant3:


#### Ant3 Freq. 2402 MHz:



#### Ant3 Freq. 2437 MHz:



#### Ant3 Freq. 2412 MHz:



#### Ant3 Freq. 2462 MHz:

