



Ant3:


Ant3 Freq. 2412 MHz:




Ant3 Freq. 5280 MHz:




Ant3 Freq. 2437 MHz:




Ant3 Freq. 5500 MHz:




Ant3 Freq. 2462 MHz:




Ant3 Freq. 5820 MHz:




Ant3 Freq. 5180 MHz:




Ant3 Freq. 5887 MHz:




Ant3 Freq. 6175 MHz:



Ant3 Freq. 6475 MHz:



Ant3 Freq. 6700 MHz:



Ant3 Freq. 7000 MHz:

