

IMPORTANT INFORMATION

Safety Rules

- 1) Please follow the rules depicted in this manual closely to ensure your safety. Before using the product, we would strongly encourage you to read through this user manual.
- 2) Avoid any sharp edges, uneven surfaces, metal parts, accessories and its packaging so as to prevent any possible injury or damage.
- 3) Keep this product out of reach of children. Take note that this product is not stable and should not be placed in your mouth.
- 4) Do not modify, repair or dismantle the product. Doing so may result in electric shock, complete breakdown of the speaker, etc. All of which are not covered under warranty.
- 5) Do not use any diluents or volatile liquid to clean the product. Keep in mind that the surface of the product should only be wiped with a clean dry cloth.
- 6) Do not use the product in locations whereby there are high-temperatures or high location free of dust and exposure to direct sunlight. Product should be used in a location free of fire and objects, such as pins, into this product.
- 7) Do not rest foreign objects, such as pens, into the product.
- 8) Do not touch this product when your hands are wet as this may result in electric shocks.
- 9) Avoid the volume before/while using this product, as sudden loud sounds may occur.
- 10) Refrain from dropping the product, as well as any collision with other objects.
- 11) Do not use the product when in hazardous locations.
- 12) Should any abnormal situations or problems occur while using the product, discontinue use immediately.

WARRANTY AND SUPPORT

Limited Warranty

- 1) If this product, or any part thereof is proven to be defective by reason of faulty workmanship or defects in materials within 12 months of purchase, we will at our option repair or replace the product free of charge, on condition that the original receipt, together with the product, is presented to us. The repair or replacement will be at our discretion.
- 2) The warranty does not cover product failures which have been caused by use of accessories or other peripheral devices are not original X-mini™ branded accessories intended for use with the product.
- 3) The warranty does not cover any damage caused by modifications, repairs and disassembly by or part shall be not authorised by the manufacturer. The warranty does not cover any damage caused by misuse, drop, hit or neglect.
- 4) Any defective unit or part shall become property of the manufacturer. The warranty does not cover any damage caused by misuse, drop, hit or neglect.

The name "X-mini", "Capsule Speaker" and "X-mini logo" are trademarks or registered trademarks of Xmi Pte Ltd. This product is covered by patents/patents pending and are property of Xmi Pte Ltd.

FCC STATEMENT

X-mini™ EVOLVE 2 Speaker Headphones

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, which means that it can cause radio frequency interference that may not be noticeable when the equipment is used in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. You are cautioned that interference will not occur if a particular installation, if this equipment does cause harmful interference to radio or television reception, it can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF Exposure Statement: This device has been evaluated to meet general RF exposure requirements. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID : A4VXAM26

DECLARATION OF CONFORMITY




X-mini™ EVOLVE 2 Speaker Headphones

We, Xmi Pte Ltd, declare under our sole responsibility as authorized representative that the following product:

Brand Name: X-mini™
Model Name: EVOLVE 2
Model Number: XAM26
WEEE02/19/EU, RoHS 2011/65/EU & REACH (EC) No 1907/2006

This declaration is based on the full compliance of the product with the following standards: RED Directive 2014/53/EU
EMC 2014/30/EU
EN60950-1:2006+A11:2009+A12:2011+A2:2013
EN301489-1 V3.0 (2017-03)
EN301489-1 V2.2.0 (2007-03)
EN300 328 V2.1.1 (2006-11)

The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc and any use of such marks by Xmi Pte Ltd is under license. Other trademarks and trade names are those of their respective owners.


INFORMATION IMPORTANTE

- 1) Veuillez bien suivre les précautions inscrites dans ce manuel afin d'assurer votre sécurité. Avant d'utiliser le ce produit, nous vous suggérons fortement de lire ce manuel.
- 2) Faites attention aux coins, surfaces inégales, objets métalliques, accessoires et leur emballage afin d'éviter tout risque de blessure ou dommage.
- 3) Gardez hors de la portée des enfants. Notez que ce produit n'est pas comestible et ne devrait pas être mis dans la bouche.
- 4) Ne modifiez pas, ne réparez pas et ne démontez pas le produit. Ce faisant, vous risquez des chocs électriques, une défaillance complète du ce produit, etc. Tout ceci n'est pas couvert par la garantie.
- 5) Ne pas utiliser de diluants ou liquide volatil pour nettoyer ce produit. Notez que la surface du ce produit ne devrait qu'être essuyée avec un linge sec propre.
- 6) Ne pas utiliser le produit dans des endroits où il y a des températures élevées ou une location libre de poussière et d'exposition à la lumière directe du soleil.
- 7) Ne restez pas assis sur le produit. Ce faisant, vous risquez des chocs électriques, une défaillance complète du ce produit, etc. Tout ceci n'est pas couvert par la garantie.
- 8) Ne rien insérer dans ce produit, comme des aiguilles par exemple.
- 9) Évitez de toucher ce produit, lorsque vos mains sont mouillées car vous risquez de vous électrocuter.
- 10) Ne pas taper le produit, ainsi que toute collision avec d'autres objets.
- 11) Ne pas utiliser ce produit dans des endroits dangereux.
- 12) Si des situations anormales ou des problèmes surviennent lors de son fonctionnement, veuillez immédiatement cesser de l'utiliser.

GARANTIE ET SUPPORT

- 1) Si, dans les 12 mois suivants son achat, il y a preuve que ce produit, en tout ou en partie, soit défectueux, nous nous engageons à le réparer ou à le remplacer gratuitement, à condition que la facture originale ou le reçu de vente montrant la date d'achat, ou d'étape de la part du fournisseur, soit présenté avec le modèle défectueux.
- 2) Les bris causés par utilisation d'accessoires ou autres périphériques qui ne sont pas originaux X-mini™ ne sont pas couverts par la garantie. Les dommages X-mini qui sont causés pour ce produit ne sont pas couverts par la garantie.
- 3) La garantie ne couvre pas les bris du produit causés par toute modifications, réparation ou démontage effectué par une personne qui n'est pas autorisée par le fabricant.
- 4) La garantie ne couvre pas les dommages causés si le ce produit est mal utilisé, échappé, trappé ou négligé.

DECLARATION FCC POUR

X-mini™ EVOLVE 2 Portable Speaker

Cet appareil est conforme avec le Titre 15 des Règles FCC. Son fonctionnement est soumis aux conditions suivantes:

- (1) cet appareil ne peut causer des interférences radioélect et
- (2) cet appareil doit tolérer toute interférence reçue, y compris celle pouvant entraver son bon fonctionnement.

Les changements ou modifications non approuvés de façon explicite par la partie responsable de la conformité peuvent entraîner la capacité de l'utilisateur à être en conformité avec les Règles FCC.

REMARQUE: Cet appareil a été testé et jugé conforme aux limites d'un appareil numérique digital de Classe B, conformément au Titre 15 des Règles FCC. Ces limites sont supérieures dans le but de fournir une protection acceptable contre les interférences radioélect. Cet appareil génère, utilise et peut émettre de l'énergie pour les fréquences radio et, s'il n'est pas installé et utilisé conformément aux instructions, il peut causer des interférences au niveau des communications radio.

Remarque: Il n'y a aucune garantie que l'interférence ne surviendra pas dans une utilisation normale de ce produit. Si l'interférence est détectée, l'utilisateur doit essayer de corriger l'interférence par l'une des méthodes suivantes:

- Réorienter ou repositionner l'antenne de réception.
- Augmenter l'écart entre l'appareil et le récepteur.
- Brancher l'appareil à une prise sur un circuit différent de celui qui alimente le récepteur.
- Solliciter l'expertise du concessionnaire ou d'un technicien radio/TV expérimenté.

Declaration sur réception aux RF: L'appareil a été jugé conforme aux normes générales d'exposition aux RF. L'appareil peut être utilisé dans des conditions d'exposition des technologies portables, sans restriction.

DECLARATION DE CONFORMITÉ




X-mini™ EVOLVE 2 Portable Speaker

Nous, Xmi Pte Ltd, déclarons sous notre responsabilité en tant que les représentants autorisés que le produit suivant:

Marque de commerce: X-mini™
Nom du modèle: XAM26
Nom de la marque: X-MINI™

Cette déclaration est basée sur la conformité du produit selon les standards suivants: RED Directive 2014/53/EU
EMC 2014/30/EU
EN60950-1:2006+A11:2009+A12:2011+A2:2013
EN301489-1 V3.0 (2017-03)
EN301489-1 V2.2.0 (2007-03)
EN300 328 V2.1.1 (2006-11)

Le marque et les logos Bluetooth ® sont des marques déposées appartenant à Bluetooth SIG, Inc. et toute utilisation de ces marques par Xmi Pte Ltd sous licence. Les autres marques et noms commerciaux sont ceux de leurs propriétaires respectifs.

CAUTION READ BEFORE USING THE PRODUCT

PLEASE CHARGE THE PRODUCT FOR 2 HOURS FOR INITIAL USAGE

- Charge the product if you are unable to power it on
- Turn off the product after use for longer battery usage
- Only use the USB charging cable provided together with the product
- Keep the product in a cool and dry place
- Do not expose the product to extreme heat
- Do not attempt to assemble the product, as it will void the warranty

WARNING!

LISTENING TO AUDIO AT EXCESSIVE VOLUMES CAN CAUSE PERMANENT HEARING DAMAGE. USE AS LOW A VOLUME AS POSSIBLE.

Over exposure to excessive sound levels can damage your ears resulting in permanent noise-induced hearing loss (NIHL).

Please use the following guidelines established by the Occupational Safety Health Administration (OSHA). Maximum time exposure to sound pressure levels before hearing damage occurs.

SPL Level	Recommended Usage Duration
120 dB SPL	8 hours
115 dB SPL	2 hours
105 dB SPL	1 hour
100 dB SPL	30 minutes
95 dB SPL	15 minutes
90 dB SPL	Avoid or damage may occur

ENGLISH

TECHNICAL SPECIFICATIONS

Ear coupling: Semi-Circumaural
Driver (Internal): 40mm (1.60)
Frequency response (Internal): 20Hz - 20KHz
Sensitivity (Internal): 98dB / 1mW
Frequency response (External): 20Hz - 20KHz
Speaker output (External): 4W X 2
Plug type: 3.5mm male
Battery capacity: 1,040mAh
Microphone sensitivity: -42±3dB
Weight: 365g (without cable)

BLUETOOTH SPECIFICATIONS

Bluetooth version: Bluetooth 4.2
Wireless range: Up to 10 meters (33 feet)
Bluetooth compliant: CSR v4.1
Bluetooth profile support: A2DP, AVRCP, HFP, HSP
Headphones playback time: Up to 30 hours
Microphone playback time: Up to 30 hours
*Playback time varies according to volume and genre

FRENCH

SPECIFICATIONS TECHNIQUES

Couplage auriculaire: Semi-Circumaural
Driver (Interne): 40mm (1,60)
Réponse en fréquence (Interne): 20Hz - 20KHz
Sensibilité (Interne): 98dB / 1mW
Réponse en fréquence (Externe): 20Hz - 20KHz
Puissance Haut-parleur (Externe): 4W x 2
Connecteur: 3,5mm
Capacité de la batterie: 1,040mAh
Sensibilité du microphone: -42±3dB
Poids net: 365g

SPECIFICATIONS BLUETOOTH

Version Bluetooth: Bluetooth 4.2
Gamme sans fil: Jusqu'à 10 mètres (33 pieds)
Conforme Bluetooth: CSR v4.1
Profil Bluetooth soutenu: A2DP, AVRCP, HFP, HSP
Durée d'utilisation Casque: Jusqu'à 30 heures
Durée d'utilisation Casque: Jusqu'à 30 heures
*Le temps de lecture varie en fonction du volume et du genre

ESPAÑOL

ESPECIFICACIONES TÉCNICAS

Acoplamiento al oído: Semi-Circumaural
Controlador (Interno): 40mm (1,60)
Frecuencia de respuesta (Interno): 20Hz - 20KHz
Sensibilidad (Interno): 98dB / 1mW
Respuesta de frecuencia (Externa): 20Hz - 20KHz
Salida de altavoz (Externa): 4W x 2
Conector: 3,5mm
Batería: 1.040mAh
Sensibilidad del micrófono: -42±3dB
Peso: 365g

ESPECIFICACIONES BLUETOOTH

Version Bluetooth: Bluetooth 4.2
Alcance inalámbrico: Hasta 10 metros (33 pies)
Bluetooth compatible: CSR v4.1
Perfil Bluetooth apoye: A2DP, AVRCP, HFP, HSP
Tiempo modo de reproducción auricular: Hasta 30 horas
Tiempo modo de reproducción auricular: Hasta 30 horas
*El tiempo de reproducción varía según el volumen y el género

GERMAN

TECHNISCHE ANGABEN

Ankopplung an das Ohr: Semi-Circumaural
Fahrer-einheit (Intern): 40mm (1,60)
Empfindlichkeit (Intern): 98dB / 1mW
Auber-übertragungsbereich (Extern): 20Hz - 20KHz
Lautsprecher ausgabe (Extern): 4W X 2
Anschlusstecker: 3,5mm
Akku kapazität: 1,040mAh
Mikrofonempfindlichkeit: -42±3dB
Nettogewicht: 365g

BLUETOOTH-SPEZIFIKATION

Bluetooth Version: Bluetooth 4.2
Wireless-reichweite: Bis zu 10 Meter
Bluetooth-kompatibel: CSR v4.1
Kopfhörer-wiedergabezeit: A2DP, AVRCP, HFP, HSP
Kopfhörer-wiedergabezeit: Bis zu 30 Stunden
Kopfhörer-wiedergabezeit: Bis zu 30 Stunden
*Die wiedergabezeit variiert je nach laute und genre


AVERTISSEMENT

ÉCOUTER LA MUSIQUE À UN VOLUME ÉLEVÉ PEUT CAUSER DES LÉSIONS AUDITIVES PERMANENTES. RÉGLER LE VOLUME LE PLUS BAS POSSIBLE.

Une surexposition à des volumes sonores excessifs peut causer des lésions aux oreilles entraînant une perte auditive permanente due au bruit.


Se conformer aux directives ci-dessous, établies par l'Occupational Safety Health Administration (OSHA) pour les limites de durée d'exposition aux pressions acoustiques (SPL) avant de risquer des lésions auditives.

Niveau SPL	Durée d'utilisation recommandée
120 dB SPL	8 heures
115 dB SPL	2 heures
105 dB SPL	1 heure
100 dB SPL	30 minutes
95 dB SPL	15 minutes
90 dB SPL	Éviter ou risque de lésions auditives



x-mini™
EVOLVE 2

Buttons expanded view




1 Mode switch



Slide to switch between speaker and headphone modes.

*Slide to headphone mode when not in use to prevent drainage of internal battery in speaker mode.

2 Power button




Pairing devices:
Press and hold power button until power on prompt is heard. Search for new Bluetooth device and select X-mini™ EVOLVE 2. The connected prompt is heard once the headphone speaker is paired successfully.
*If pairing is unsuccessful, switch off and on X-mini™ EVOLVE 2 to reattempt.

*If sound continues to be played through the connected device's built-in speakers, set Bluetooth to preferred audio settings.
*AVRCP must be supported by the connected device in order to use the controls.

XConnect function:
Connect the first device to X-mini™ EVOLVE 2 and disconnect once connection is successful. Connect another device to X-mini™ EVOLVE 2, and reconnect the first device. Connected prompts are heard each time the devices are paired successfully with the speaker.

*A maximum of two devices can be paired to a X-mini™ EVOLVE 2.
*Pause music on one device before playing music from the other device.
*Music will play from one device each time.

3 Volume buttons



Volume control:
Press and hold ▲ volume button to increase volume
Press and hold ▼ volume button to decrease volume

Music control:
Press ▲ volume button once to change to next song
Press ▼ volume button once to change to previous song


4 Microphone



Redial: Press power button twice
Volume up: Press ▲ button
Volume down: Press ▼ button
Answering call: Press power button once
Rejecting call: Press and hold power button for 2s
Mute: Press ▲ volume and ▼ volume buttons together

*Functions and indication tones may vary between devices.

5 LED light



*Audio output gets softer and a warning tone is heard when the battery level of the speaker is low. Recharge before use.